

[Manuals.plus](#) /

› [Merax](#) /

› Merax Twin Over Full Bunk Bed with Slide User Manual

Merax MX01796

Merax Twin Over Full Bunk Bed with Slide User Manual

Model: MX01796

1. INTRODUCTION

Thank you for choosing the Merax Twin Over Full Bunk Bed with Slide. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: Assembled Merax Twin Over Full Bunk Bed with Slide in a room setting.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always supervise children when using the slide.
- Be cautious of sharp edges and ensure proper assembly to prevent instability.
- Do not exceed the maximum weight capacity of 400 pounds for the upper bunk and 600 pounds for the bottom bunk.
- Ensure all connections are tight before use. Periodically check and tighten hardware as needed.
- The top bunk is not suitable for children under 6 years of age.
- Use only mattresses that are 6 inches thick for the upper bunk and 8 inches thick for the bottom bunk.
- Always use the guardrails on the upper bunk.
- Prohibit more than one person on the upper bunk.

- Prohibit horseplay on or under the bed.
- Always use the ladder for entering and leaving the upper bunk.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the detailed parts list provided in the separate assembly instruction booklet included with your purchase. Key components include:

- Wooden frame components (pine wood, MDF boards for roof and windows)
- Slide assembly
- Ladder
- Guardrails
- Plywood slats for mattress support
- All necessary hardware (screws, bolts, nuts, etc.)
- Assembly instruction manual

4. SETUP (ASSEMBLY)

Assembly is required for this bunk bed. It is recommended that two adults perform the assembly. Please follow the step-by-step instructions in the dedicated assembly manual provided in the packaging. Ensure you have adequate space and the necessary tools (e.g., Phillips head screwdriver, Allen wrench) before starting.

1. Unpack all components and verify against the parts list.
2. Identify and separate hardware.
3. Assemble the main bed frames according to the diagrams.
4. Attach the house roof and window sections.
5. Install the ladder and slide securely.
6. Place the plywood slats onto the bed frames.
7. Tighten all connections firmly, but do not overtighten.



Image 4.1: Structural view of the bunk bed frame, slide, and ladder.

5. OPERATING (USAGE)

This Merax bunk bed is designed for sleeping and recreational use of the slide. Ensure proper mattress placement and adherence to weight limits for safe operation.

- **Sleeping:** Place a Twin size mattress on the upper bunk and a Full size mattress on the bottom bunk. Ensure mattresses fit snugly within the frame.
- **Slide Use:** The slide is intended for single-person use at a time. Children should slide feet first. Ensure the area around the slide exit is clear.
- **Ladder Use:** Always use the built-in 3-step ladder for accessing the upper bunk. Ensure a firm grip and stable footing.

6. MAINTENANCE

Regular maintenance will prolong the life and safety of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the painted finish.

- **Hardware Check:** Periodically (e.g., monthly) inspect all bolts, screws, and connections to ensure they are tight. Retighten as necessary to prevent wobbling or instability.
- **Structural Integrity:** Check for any signs of wear, cracks, or damage to the wooden components. Discontinue use if significant damage is found and contact customer support.
- **Slide Inspection:** Ensure the slide surface is smooth and free of splinters or obstructions.

7. TROUBLESHOOTING

If you encounter issues with your Merax bunk bed, consider the following common solutions:

- **Squeaking Noises:** This is often caused by loose hardware. Re-tighten all bolts and screws. Ensure the bed is on a level surface.
- **Wobbling/Instability:** Verify that all connections are securely tightened. Check if the bed is assembled correctly according to the manual. Ensure the floor is level.
- **Parts Missing/Damaged:** If you find any parts missing or damaged upon unboxing, do not proceed with assembly. Contact Merax customer support immediately for replacement parts.
- **Paint Odor:** A new furniture item may have a slight paint odor. Ensure good ventilation in the room. The odor should dissipate over time.

8. SPECIFICATIONS

Feature	Detail
Model Number	MX01796
Product Dimensions	80.8"L x 78.7"W x 82.3"H
Weight Capacity (Upper)	400 LBS
Weight Capacity (Bottom)	600 LBS
Recommended Mattress Thickness (Upper)	6 inches
Recommended Mattress Thickness (Bottom)	8 inches
Material	Solid Pine Wood, MDF
Finish Type	Painted (White)
Assembly Required	Yes
Special Feature	No Box Spring Needed

SIZE: INCH




Image 8.1: Product Dimensions Diagram.

9. WARRANTY AND SUPPORT

Merax is committed to providing quality products. While specific warranty details for this product should be referenced in your purchase documentation, general support information is provided below.

- **Returns:** This product typically offers a 30-day easy return policy. Please refer to your retailer's return policy for specific terms and conditions.
- **Customer Support:** For any questions, concerns, or assistance with parts, assembly, or troubleshooting, please contact Merax customer support. Contact information can usually be found on the Merax official website or through your purchase platform.
- **Protection Plans:** Extended protection plans may be available for purchase separately to cover your product beyond the standard return period.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question