

HONEY JOY Maserati GranCabrio

HONEY JOY Pink 12V Licensed Maserati GranCabrio Ride-On Car Instruction Manual

Brand: HONEY JOY | Model: Maserati GranCabrio (HJ-1366-US)

1. IMPORTANT SAFETY INFORMATION

For the safety of your child, please read and understand all instructions before assembly and operation. Keep this manual for future reference.

- **Parental Supervision:** Always supervise children when operating the ride-on car.
- **Safety Belt:** Ensure the child is securely fastened with the provided safety belt before operation.
- **Operating Environment:** Operate the vehicle on flat, dry surfaces. Avoid slopes, uneven terrain, public roads, near swimming pools, or other bodies of water.
- **Weight and Age Limits:** This ride-on car is designed for one child, with a maximum weight capacity of 55 lbs. Recommended for children aged 37-96 months (3-8 years).
- **Remote Control Safety:** The parental remote control allows adults to override child controls, providing an essential safety feature for younger or less experienced drivers.
- **Charging:** Only use the provided charger. Do not overcharge the battery.

2. PACKAGE CONTENTS

Please check that all components are present before beginning assembly:

- 1 x Ride-On Car Body
- 4 x Wheels
- 4 x Wheel Rims
- 1 x Steering Wheel
- 1 x Seat with Safety Belt

- 1 x Windshield
- 2 x Side Mirrors
- 2 x Brake Calipers
- 1 x Remote Control
- 1 x Charger
- Assembly Hardware (washers, nuts, screws)
- 1 x Instruction Manual

3. SETUP AND ASSEMBLY

Follow these steps to assemble your HONEY JOY Maserati GranCabrio ride-on car. For a visual guide, please refer to the assembly video below.

Your browser does not support the video tag.

Video Description: This video demonstrates the step-by-step assembly process for a Maserati ride-on car, including attaching wheels, connecting wiring, and installing the steering wheel and seat. While the car color may vary, the assembly steps are applicable to your HONEY JOY Pink Maserati GranCabrio.

1. **Prepare the Car Body:** Carefully remove the car body from the packaging. Place it upside down on a soft, stable surface to avoid scratches.
2. **Install Rear Wheels:** Attach the rear wheels to the axle. Secure each wheel with a washer and a nut, ensuring it is tightened properly. Snap the wheel rims into place.
3. **Install Front Wheels:** Attach the front wheels to the axle. Secure each wheel with a washer and a nut, ensuring it is tightened properly. Snap the wheel rims into place.
4. **Connect Battery:** Locate the battery compartment, usually under the seat. Connect the red and black wires to the corresponding terminals on the battery.
5. **Install Steering Wheel:** Connect the wiring from the steering column to the steering wheel. Carefully slide the steering wheel onto the steering column until it clicks into place. Secure it with the provided screw.
6. **Install Seat:** Place the seat into the car body. Push down firmly until it locks into position. Secure any additional fasteners if provided.
7. **Attach Windshield and Side Mirrors:** Snap the windshield into the designated slots on the car body. Attach the side mirrors by pushing them into their respective slots on the doors.
8. **Initial Charge:** Before first use, fully charge the battery for 8-12 hours.

4. OPERATING INSTRUCTIONS

Your Maserati GranCabrio ride-on car offers two modes of operation for versatile play.



Image Description: This image illustrates the two driving modes: parental remote control and manual mode. The remote control is shown with buttons for speed, direction, and emergency brake. A child is seen happily driving the pink Maserati GranCabrio.

4.1. Manual Driving Mode (Child Operated)

- **Power On:** Press the main power button on the dashboard.
- **Acceleration:** Press the foot pedal to accelerate. The car features a slow start function for smooth acceleration.
- **Steering:** Use the steering wheel to control direction (left/right).
- **Speed:** The car has 2 speed settings. Use the speed selector on the dashboard to choose between low and high speed.
- **Braking:** Release the foot pedal to engage the automatic brake.

4.2. Parental Remote Control Mode

The 2.4G remote control allows parents to safely guide the vehicle.

Your browser does not support the video tag.

Video Description: This video demonstrates the functionality of the parental remote control, showing how an adult can steer the car, move it forward and backward, and use the emergency stop feature. This is particularly useful for younger children who are still learning to drive.

- **Pairing the Remote:** Turn on the car. On the remote, press and hold the 'S' (speed) button until the indicator light flashes, then release. The light will become solid when paired.
- **Forward/Backward:** Use the up/down arrows on the remote to move the car forward or backward.
- **Steering:** Use the left/right arrows to steer the car.
- **Speed Control:** Press the 'S' button to cycle through the three available speed settings.
- **Emergency Stop:** Press the 'P' (park) button to immediately stop the car. Press 'P' again to release the brake.

4.3. Dashboard Features



Image Description: This image highlights the multifunctional dashboard panel, detailing buttons for horn, power, radio, music, high/low speed, lights, wireless connection, song selection, charging socket, power display, and USB port.

- **Music Player:** The car features an integrated MP3 player with pre-loaded music.
- **USB Port:** Connect a USB device to play your own audio files.
- **Lights:** Front and rear lights can be turned on/off via dashboard buttons.
- **Horn:** Press the horn button on the steering wheel for sound effects.

5. MAINTENANCE

- **Charging:** Charge the battery after each use. A full charge takes approximately 8-12 hours. Do not charge for more than 18 hours to prevent battery damage.
- **Cleaning:** Wipe the car's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Storage:** Store the car in a dry, cool place away from direct sunlight and moisture. If storing for extended periods, charge the battery monthly to prolong its lifespan.
- **Tire Inspection:** Regularly check the tires for wear and tear.

6. TROUBLESHOOTING

- **Car does not move:** Check if the battery is fully charged and properly connected. Ensure the power switch is ON. Verify the remote control is paired and not in 'P' (park) mode.
- **Reduced speed or power:** The battery may be low and require charging. If the issue persists after charging, the battery may need replacement.
- **Remote control not responding:** Ensure the remote control batteries are fresh and correctly inserted. Re-pair the remote control with the car.
- **Unusual noises:** Inspect the wheels and motor area for any obstructions (e.g., debris, loose wires). Tighten any loose screws or connections.
- **Lights not working:** Check the light button on the dashboard. Ensure all wiring connections are secure.

7. SPECIFICATIONS

- **Product Dimensions:** 40.5 x 24.5 x 17.5 inches
- **Item Weight:** 30 pounds
- **Weight Capacity:** 55 lbs (for 1 child)
- **Recommended Age:** 37-96 months (3-8 years)
- **Battery:** 12V
- **Speed:** 2-3 mph
- **Material:** Premium PP and Iron

- **Model Number:** HJ-1366-US







8. WARRANTY AND SUPPORT

Warranty information for the HONEY JOY Pink 12V Licensed Maserati GranCabrio Ride-On Car is not specified in the provided product data.

For detailed warranty terms, product support, or to inquire about replacement parts, please refer to the product packaging or contact HONEY JOY customer service directly.

Thank you for choosing HONEY JOY!

Related Documents - Maserati GranCabrio

| | |
|---|--|
|  | <p>HONEY JOY Inflatable Bounce House Château Gonflable: Safety, Assembly, and Maintenance Guide</p> <p>Comprehensive safety, assembly, maintenance, and disassembly instructions for the HONEY JOY Inflatable Bounce House Château Gonflable. This guide ensures safe play for children aged 3-12, detailing setup, usage restrictions, and care instructions.</p> |
|  | <p>Honey Joy BC10149 Balance Bike - Assembly, Safety, and Return Instructions</p> <p>A comprehensive guide for the Honey Joy BC10149 Balance Bike, detailing assembly steps, safety precautions, part lists, and instructions for returns or damage claims. This manual is designed for easy understanding and safe use of the product.</p> |
|  | <p>Honey Joy NP10766 3-in-1 Kids Swing Set - Assembly, Safety, and Maintenance Guide</p> <p>Comprehensive guide for the Honey Joy NP10766 3-in-1 kids swing set, covering assembly instructions, safety advice, fixing into the ground, maintenance, practical tips, and playground surfacing information. Includes parts list and diagrams described textually.</p> |
|  | <p>HONEY JOY Inflatable Bouncer/Water Park: Setup, Safety, and Maintenance Guide</p> <p>Comprehensive instruction manual for the HONEY JOY Inflatable Bouncer/Water Park. Includes setup, safety warnings, maintenance tips, and repair instructions for safe and enjoyable use.</p> |
|  | <p>HONEY JOY Air Blower User Manual - Safety, Maintenance, and Troubleshooting Guide</p> <p>Official user manual for the HONEY JOY Air Blower. Includes safety warnings, technical specifications, maintenance instructions, troubleshooting guide, and grounding procedures.</p> |
|  | <p>Honey Joy NP10765 Swing Set User Manual: Assembly, Safety, and Maintenance Guide</p> <p>Comprehensive user manual for the Honey Joy NP10765 swing set. Includes detailed assembly instructions, safety warnings, maintenance tips, and information on playground surfacing. Ensure safe and proper installation and use.</p> |