Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Logitech G 920-012122

Logitech G PRO X TKL LIGHTSPEED Wireless Gaming Keyboard User Manual

Brand: Logitech G | Model: 920-012122

Product Overview

The Logitech G PRO X TKL LIGHTSPEED Wireless Gaming Keyboard is an ultra-portable tenkeyless keyboard designed for competitive gaming. It features LIGHTSYNC RGB lighting, durable PBT keycaps, and responsive GX Red Linear Switches, offering a reliable and customizable experience for professional and enthusiast gamers alike.



Image: The Logitech G PRO X TKL LIGHTSPEED Wireless Gaming Keyboard, showcasing its compact tenkeyless design and RGB lighting.

Setup

What's in the Box

- PRO X TKL Gaming Keyboard
- USB LIGHTSPEED adapter
- Adapter extension

- USB-A to USB-C charging and data cable
- Carrying case

Initial Connection

The keyboard offers multiple connectivity options: LIGHTSPEED wireless, Bluetooth, and USB wired connection.

1. **LIGHTSPEED Wireless:** Insert the USB LIGHTSPEED adapter into an available USB port on your computer. For optimal signal, use the included adapter extension to position the receiver closer to the keyboard. The keyboard should automatically connect.
2. **Bluetooth:** Ensure the keyboard is in Bluetooth mode (refer to the operating instructions for mode switching). Pair the keyboard with your device via your device's Bluetooth settings.
3. **USB Wired:** Connect the USB-A to USB-C cable from your computer to the keyboard. This will also charge the keyboard.

Software Installation

For full customization and control, download and install the Logitech G Hub software from the official Logitech G website. This software allows for programmable keys, RGB lighting customization, and game mode control.

Operating Instructions

The PRO X TKL keyboard is designed for high-performance gaming with intuitive controls.

Key Features and Controls

- **LIGHTSYNC RGB:** Customize per-key RGB lighting effects and synchronize them with other Logitech G devices using G Hub.
- **Programmable Keys:** Assign custom macros and functions to various keys via the G Hub software for personalized gameplay.
- **Media Controls & Volume Roller:** Dedicated media control buttons and a volume roller provide convenient audio management without interrupting your game.
- **Game Mode Control:** Activate game mode to disable certain keys (like the Windows key) to prevent accidental presses during intense gaming sessions.
- **GX Red Linear Switches:** Experience smooth and quiet keystrokes with the linear switch type, ideal for rapid, repetitive presses.



Image: An overhead view of the Logitech G PRO X TKL keyboard, highlighting its media controls, volume roller, game mode button, and LIGHTSYNC RGB.

Connectivity Modes

Switch between LIGHTSPEED wireless, Bluetooth, and wired USB modes as needed for different scenarios.



Image: A close-up of the Logitech G PRO X TKL keyboard, emphasizing its LIGHTSPEED wireless capability and compact design.

Maintenance

Cleaning the Keyboard

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and chassis.
- Avoid spraying liquids directly onto the keyboard.
- For debris between keys, use compressed air.

Keycap Care

The keyboard features durable dual-shot PBT keycaps. While robust, avoid excessive force when removing or installing keycaps to prevent damage to the switches.

Battery Information

The keyboard uses a Lithium Polymer battery. For optimal battery life, avoid fully discharging the battery frequently. Recharge using the provided USB-A to USB-C cable. The keyboard has an auto-sleep feature to conserve power when not in use.

Troubleshooting

Connectivity Issues

- **Wireless Disconnection:** Ensure the USB LIGHTSPEED adapter is securely connected and within range. Try using the adapter extension. Check for interference from other wireless devices.
- **Bluetooth Pairing Failure:** Ensure the keyboard is in Bluetooth pairing mode. Remove previous pairings from your device and try re-pairing.
- **Keyboard Not Responding (Wired):** Verify the USB-C cable is properly connected to both the keyboard and the computer. Try a different USB port.

Lighting or Key Function Issues

- **RGB Lighting Malfunctions:** Check Logitech G Hub for lighting settings and profiles. Ensure the software is up to date.
- **Keys Not Registering:** Clean around the affected key. If using G Hub, ensure no macros or assignments are interfering with the key's normal function.

Software Updates

Regularly check for and install updates for the Logitech G Hub software. Updates often include bug fixes, performance improvements, and new features that can resolve various issues.

Specifications

Feature	Detail
Product Dimensions	5.91 x 13.86 x 1.34 inches
Item Weight	4.58 pounds
Model Number	920-012122
Batteries	1 Lithium Polymer batteries required. (included)
Connectivity Technology	RF, USB
Keyboard Description	Gaming
Recommended Uses	Gaming, Office
Special Features	Portable, Rechargeable, Wireless
Color	Black
Number of Keys	87
Keyboard Backlighting	RGB

Warranty and Support

For detailed warranty information and technical support, please visit the official Logitech G support website. You can find FAQs, troubleshooting guides, and contact information for customer service there.
Logitech G products are designed for durability and performance, backed by comprehensive support to ensure your gaming experience remains uninterrupted.

© 2025 Logitech G. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQBRPZ8M

More documents and user manuals: **https://manuals.plus/**