

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chicco](#) /

› [Chicco Semi-Soft Trainer Sippy Cup Instruction Manual \(7 oz, 6+ Months\)](#)

Chicco 00007043200070

Chicco Semi-Soft Trainer Sippy Cup Instruction Manual

Model: 00007043200070 | For Ages 6+ Months

[Introduction](#)

[Safety Information](#)

[Setup & Assembly](#)

[Operating Instructions](#)
[Warranty & Support](#)

[Care & Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

1. INTRODUCTION

Thank you for choosing the Chicco Semi-Soft Trainer Sippy Cup. This cup is designed to assist your child in transitioning from bottle to cup drinking, offering a comfortable and spill-free experience. It features a semi-soft, bite-resistant spout and removable non-slip handles, making it ideal for children aged 6 months and older.



Figure 1: Assembled Chicco Semi-Soft Trainer Sippy Cup.

2. SAFETY INFORMATION

- Always use this product with adult supervision.
- Never use feeding nipples as a soother.
- Continuous and prolonged sucking of fluids will cause tooth decay.
- Always check food temperature before feeding.
- Keep all components not in use out of children's reach.
- Before each use, inspect the product. Throw away at the first sign of damage or weakness.
- Do not leave the product in direct sunlight or heat, or leave in disinfectant ("sterilizing solution") for longer than recommended, as this may weaken the components.
- Do not allow children to run or walk with the cup.

3. SETUP & ASSEMBLY

The Chicco Semi-Soft Trainer Sippy Cup consists of several interchangeable parts for easy assembly and cleaning.

3.1 Components

- Cup body (7 oz / 200 ml)
- Semi-soft spout
- Lid/Collar
- Removable, one-piece silicone spill-free valve
- Removable non-slip handles
- Snap-on cap



Figure 2: All components of the Chicco Semi-Soft Trainer Sippy Cup.

3.2 Assembly Instructions

1. Ensure all components are clean and dry before assembly (refer to Section 5 for cleaning instructions).
2. Insert the one-piece silicone spill-free valve into the underside of the lid/collar, ensuring it is securely seated.



Figure 3: Inserting the spill-free valve.

3. Place the semi-soft spout into the top opening of the lid/collar, pulling it through until it is firmly in place.
4. Screw the assembled lid/collar onto the cup body until tight.
5. Attach the non-slip handles by sliding them onto the cup body until they click into place. The handles can be removed for cleaning or for practicing holding the cup directly.



Figure 4: Removable non-slip handles.

4. OPERATING INSTRUCTIONS

4.1 Filling the Cup

- Unscrew the lid/collar from the cup body.
- Fill the cup with your desired liquid (water, milk, juice) up to the 7 oz (200 ml) mark. Do not overfill.
- Screw the lid/collar back onto the cup body securely.

4.2 Drinking from the Cup

- The semi-soft spout is designed with a unique groove to guide lower lip placement, promoting proper drinking technique.
- The sip-activated flow valve ensures a spill-free experience. Liquid flows only when the child sips from the spout.



Figure 5: Spill-free design prevents leaks.

- For free-flow drinking, the one-piece silicone valve can be removed (refer to Section 3.2, step 2 for valve removal).
- The ergonomic indents on the cup body and non-slip handles are designed for tiny hands to hold comfortably.



Figure 6: Child using the sippy cup with handles.

4.3 Using the Snap-On Cap

- A snap-on cap is included to keep the spout clean when not in use or during travel.
- Simply press the cap firmly over the spout until it clicks into place.

Your browser does not support the video tag.

Video 1: Official Chicco video demonstrating the features of the Semi-Soft Spout Sippy Cup, including its spill-free design

and ease of use.

5. CARE & MAINTENANCE

5.1 Cleaning Instructions

- Disassemble all components before cleaning.
- All parts of the Chicco Semi-Soft Trainer Sippy Cup are top-rack dishwasher safe.
- Alternatively, wash by hand with warm, soapy water and rinse thoroughly. Use a soft brush for hard-to-reach areas if necessary.
- Ensure the one-piece silicone valve is thoroughly cleaned to prevent residue buildup.
- Allow all parts to air dry completely before reassembly or storage.

5.2 Storage

- Store the clean, dry cup in a cool, dry place away from direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cup is leaking	<ul style="list-style-type: none">◦ Lid not screwed on tightly.◦ Spill-free valve not properly seated or damaged.◦ Spout not fully inserted.	<ul style="list-style-type: none">◦ Ensure lid is securely tightened.◦ Check that the silicone valve is correctly inserted and free from damage. Replace if damaged.◦ Push the spout firmly into the lid opening.
Liquid not flowing easily	<ul style="list-style-type: none">◦ Spill-free valve is in place (designed for sip-activated flow).◦ Valve or spout is clogged.	<ul style="list-style-type: none">◦ Encourage child to sip to activate flow. For free-flow, remove the valve.◦ Clean the valve and spout thoroughly to remove any blockages.
Handles are loose	<ul style="list-style-type: none">◦ Handles not fully clicked into place.	<ul style="list-style-type: none">◦ Push handles firmly onto the cup body until they click.

7. SPECIFICATIONS

Feature	Detail
Brand	Chicco
Model Number	00007043200070
Capacity	7 Ounces (200 ml)
Recommended Age	6+ Months
Material	Polypropylene (BPA-Free, Latex-Free)
Special Features	Bite Resistant Spout, Spill-Free, Removable Non-Slip Handles, Ergonomic Indents, Interchangeable Parts

Feature	Detail
Care Instructions	Top-rack Dishwasher Safe
Product Dimensions	5"W x 5.75"H
Item Weight	2.89 Ounces
UPC	049796401233

8. WARRANTY & SUPPORT

8.1 Warranty Information

This Chicco product comes with a **1-year limited warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, please refer to the official Chicco website or contact customer support.

8.2 Customer Support

For any questions, concerns, or support regarding your Chicco Semi-Soft Trainer Sippy Cup, please contact Chicco customer service:

- **Website:** [Visit the Chicco Store on Amazon](#) (for general product information)
- Refer to product packaging for direct contact information (phone/email) or visit the official Chicco USA website.

© 2025 Chicco. All rights reserved. Information subject to change without notice.

Related Documents - 00007043200070

	<p><u>Chicco Customizable Cups: Lids, Features, and Usage Guide</u></p> <p>Explore the Chicco range of customizable cups, featuring interchangeable lids for different baby stages, from 4 months to 2 years. Learn about usage, safety tips, and cleaning instructions for Transition Cups, Straw Trainers, 360° Rim Trainers, and more.</p>
	<p><u>Chicco Baby Cups: Mix & Match Guide and Usage Instructions</u></p> <p>A comprehensive guide to Chicco's interchangeable baby cups, featuring different lid types for various stages, usage instructions, cleaning tips, and safety warnings.</p>
	<p><u>Chicco Mix It Up Cups: A Guide to Customization and Use</u></p> <p>Explore the Chicco Mix It Up system for creating custom baby cups. Learn about different spout and lid options for various stages, usage instructions, cleaning tips, and safety warnings.</p>

	<p>Chicco Training Cup 6M+ Ergonomic, Spill-Proof, BPA-Free</p> <p>Chicco Training Cup (6M+) for babies. Features a bite-proof, ergonomic spout and a 2-in-1 spill-proof/free-flow valve. BPA-free, ideal for developing drinking skills. Mix & Match system.</p>
	<p>Chicco Spazzolino Toothbrush for 6-36 Months - Extra Soft Tapered Bristles</p> <p>Chicco Spazzolino toothbrush designed for babies aged 6-36 months, featuring extra soft tapered bristles for gentle cleaning, BPA-free materials, and an ergonomic, slip-proof grip. Includes cap cover.</p>
	<p>Chicco Balloon Baby Bouncer Instructions</p> <p>Comprehensive instructions for the Chicco Balloon baby bouncer, covering assembly, usage, safety warnings, and maintenance for both bouncer and chair modes.</p>