

[manuals.plus](#) /

› [Vacmaster](#) /

› [Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner User Manual](#)

Vacmaster VBVB1223PF

Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner User Manual

Model: VBVB1223PF | Brand: Vacmaster

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner with Detachable Air Blower. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image: The Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner, showing its main unit with hose and floor nozzle attached.

PRODUCT FEATURES

- **Bagged or Bagless Operation:** Can be used with or without a dust bag for dry debris. Dust bag recommended for hygienic disposal of fine dust. For wet suction, do not use a dust bag.
- **Compact Design:** Features a durable, compact design with a foldable carry handle for easy transport.
- **1200W Bypass Motor:** Delivers 200 Air Watts of suction power, with a max airflow of 35 L/s and 18 kPa vacuum pressure. The bypass motor ensures efficient performance and motor cooling.
- **On-Board Accessory Storage:** All included accessories can be stored directly on the unit for convenience.
- **Accessories and Tools:** Includes a 35mm quick lock 1.8m suction hose, cartridge filter, foam filter, dust bag, universal 10" floor nozzle, crevice tool, and blower tube with adapter.
- **Easy Release Detachable Blower:** Converts to a powerful handheld blower with a single button push, ideal for clearing leaves and debris.

- **Wet or Dry Extraction:** Capable of vacuuming large volumes of wet or dry debris, from fine dust to liquids. Requires cartridge filter for dry use and foam filter for wet use.
- **2-in-1 High Performance Blower:** Offers a blowing speed of 172 MPH, making it a versatile tool for various cleaning tasks.



Image: The Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner disassembled, showing the main unit, detachable blower, hose, extension wands, and various cleaning attachments and filters.

SETUP AND ASSEMBLY

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all listed accessories are present.
2. **Attaching Casters:** Insert the four caster wheels into the designated slots on the base of the collection tank until they click into place.
3. **Filter Installation:**
 - For **Dry Vacuuming:** Ensure the cartridge filter is securely installed over the float cage. An optional dust bag

can be fitted inside the tank for easier disposal.

- For **Wet Vacuuming**: Remove the cartridge filter and install the foam filter over the float cage. Do not use a dust bag for wet suction.



Image: A person demonstrating the installation or removal of the filter inside the Vacmaster vacuum cleaner's tank.

4. **Securing the Power Head:** Place the power head onto the collection tank, aligning the latches. Secure the power head by pushing the latches down until they lock.
5. **Hose Connection:** Insert the large end of the suction hose into the vacuum port on the front of the collection tank until it locks securely.
6. **Accessory Attachment:** Attach the desired extension wands and floor nozzle or other tools to the end of the hose for your specific cleaning task.

OPERATING INSTRUCTIONS

Dry Vacuuming

For dry debris, ensure the cartridge filter is installed. You may also use a dust bag for easier disposal of fine dust.

1. Connect the hose and desired dry cleaning attachment (e.g., floor nozzle, crevice tool).
2. Plug the power cord into a suitable electrical outlet.
3. Turn the vacuum cleaner ON using the power switch located on the power head.
4. Guide the attachment over the dry debris to be collected.
5. When finished, turn the unit OFF and unplug it.



Image: A person using the Vacmaster vacuum cleaner to clean dry debris from a floor, demonstrating its dry vacuuming capability.

Wet Vacuuming

For liquid spills, ensure the foam filter is installed and the dust bag is removed. The float mechanism will automatically shut off suction when the tank is full.

1. Ensure the foam filter is in place and no dust bag is used.
2. Connect the hose and desired wet cleaning attachment (e.g., floor nozzle).
3. Plug the power cord into a suitable electrical outlet.

4. Turn the vacuum cleaner ON.
5. Carefully guide the attachment over the liquid spill.
6. When the tank is full or the task is complete, turn the unit OFF and unplug it. Empty the tank immediately after wet vacuuming.



Image: A person using the Vacmaster vacuum cleaner to clean up broken glass and liquid from a tiled patio, illustrating its wet vacuuming function.

Using the Detachable Blower

The power head can be detached and used as a powerful handheld blower.

1. Ensure the unit is unplugged.
2. Press the release button on the power head to detach it from the collection tank.
3. Attach the blower tube to the air outlet port on the detached power head.
4. Plug the blower into a suitable electrical outlet.

5. Turn the blower ON using the power switch.
6. Direct the airflow to clear leaves, dust, or other light debris.
7. When finished, turn the blower OFF and unplug it.



Image: A person detaching the power head of the Vacmaster vacuum cleaner from its tank, demonstrating the easy release mechanism for the blower function.



Image: A person using the detached power head of the Vacmaster as a handheld blower to clear leaves from a patio, showcasing its dual functionality.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

- **Emptying the Tank:** After each use, especially wet vacuuming, unlatch the power head and empty the collection tank. Clean the inside of the tank with water and mild detergent if necessary, then dry thoroughly.
- **Cleaning Filters:**
 - **Cartridge Filter (Dry Use):** Tap the filter gently to dislodge dust. For heavy dirt, rinse with water and allow to air dry completely before reinstallation.
 - **Foam Filter (Wet Use):** Rinse the foam filter with water and mild soap. Squeeze out excess water and allow to air dry completely before storage or next wet use.
- **Hose and Accessories:** Check the hose and all accessories for blockages. Clear any obstructions to maintain

suction power.

- **Cord Storage:** Wrap the power cord neatly around the designated cord wraps on the unit for storage.



Image: The Vacmaster vacuum cleaner stored compactly against a wall, with its hose and accessories neatly organized on the unit, demonstrating its on-board storage and portability.

TRUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not start.	No power supply; Power switch OFF; Faulty outlet.	Check power cord connection; Ensure switch is ON; Test outlet with another device.
Loss of suction.	Tank full; Clogged hose/filter/attachment; Incorrect filter for task.	Empty tank; Clear blockages; Ensure correct filter (cartridge for dry, foam for wet).

Problem	Possible Cause	Solution
Water/foam coming from exhaust.	Tank is overfilled during wet vacuuming; Foam filter not installed.	Empty tank; Ensure foam filter is correctly installed for wet use.
Blower function not working.	Blower tube not securely attached; Power head not properly detached.	Ensure blower tube is firmly attached; Verify power head is fully detached and latched for blower use.

SPECIFICATIONS

Feature	Detail
Brand	Vacmaster
Model Name	VBVB1223PF (VJK2270SW)
Special Feature	Bagless, Wet/Dry, Detachable Blower
Filter Type	Cartridge, Foam
Included Components	Brush, Hose, Filters, Nozzles, Blower Tube
Cordless?	No
Capacity	23 litres
Hose Length	1.8 Metres
Recommended Uses	Floor and carpet wet and dry vacuuming
Form Factor	Cannister
Colour	Blue And Black
Product Dimensions	34.5L x 34.5W x 49.5H Centimeters
Noise Level	76 dB
Motor Horsepower	1250 Watts
Item Weight	7 kg 460 g

WARRANTY AND SUPPORT

Your Vacmaster 2-in-1 Wet & Dry Vacuum Cleaner is covered by a **1 Year Warranty** from the date of purchase. For warranty claims, technical support, or service inquiries, please contact Vacmaster customer service. Retain your purchase receipt as proof of purchase for warranty validation.

For further assistance, refer to the contact information provided with your product packaging or visit the official Vacmaster website.

