Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RM-C3228-UV020

Instruction Manual

Azwok RM-C3228 Replacement Remote Control

Model: AU-RM-C3228-UV020

Introduction

This manual provides instructions for the Azwok RM-C3228 Replacement Remote Control, designed for various JVC TV models. This remote is a direct replacement and requires no programming.

Compatible JVC TV Models:

- LT32N3105A
- LT55N6105A
- LT55N7105A
- LT58N7105A
- LT65N7105A
- LT-32N3105A
- LT-55N6105A
- LT-55N7105A
- LT-58N7105A
- LT-65N7105A

Note: If your TV model is not listed or your original remote differs significantly, please contact customer support for assistance.

Package Contents

- 1 x Azwok RM-C3228 Replacement Remote Control

Batteries are not included. Two AAA batteries are required for operation.

Setup

1. **Install Batteries:** Locate the battery compartment on the back of the remote control. Slide the battery cover downwards to open. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.


MADE IN CHINA



Image: Back of the remote control with the battery compartment open, ready for battery insertion.

2. **Close Battery Compartment:** Slide the battery cover back into place until it clicks securely.
3. **Ready to Use:** The remote control is now ready for immediate use with your compatible JVC TV. No programming or pairing is required.

Operating Instructions

The Azwok RM-C3228 remote control replicates the functionality of your original JVC TV remote. Below is a general overview of common button functions.





Image: Front view of the RM-C3228 remote control, displaying all buttons and their labels.

Common Button Functions

Button	Function
Power (Red)	Turns the TV on or off.
Input	Selects the input source (HDMI, AV, etc.).
Number Buttons (0-9)	Direct channel selection.
Volume (+/-)	Adjusts the volume level.
Channel (CH +/-)	Changes the TV channel.
Home	Accesses the TV's home screen or smart TV menu.
Netflix	Direct access to the Netflix application.
YouTube	Direct access to the YouTube application.
Menu	Opens the TV's main menu.
Navigation (Up/Down/Left/Right/OK)	Navigates through menus and selects options.
Back	Returns to the previous screen or menu.
Exit	Exits the current menu or application.
Mute	Mutes or unmutes the TV audio.

Button	Function
Info	Displays program information.
Guide	Opens the electronic program guide.
Recall	Switches between the current and previously viewed channel.
Q.MENU	Accesses quick menu options.
Media Playback Controls	Includes Play/Pause, Stop, Fast Forward, Rewind, Next, Previous for media playback.
Subtitle	Toggles subtitles on/off.
Pg Up/Pg Dn	Page up/down functionality in menus or guides.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Disposal:** Dispose of old batteries according to local regulations. Do not dispose of batteries in general household waste.

Troubleshooting

Problem	Solution
Remote is not working.	◦ Ensure batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new AAA batteries. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Confirm the remote is pointed directly at the TV.
Some buttons are not responding.	◦ Check battery level and replace if necessary. ◦ Clean the remote's surface, especially around the unresponsive buttons, to remove any debris. ◦ Ensure your TV model is listed as compatible.
Remote works intermittently.	◦ Batteries may be low; replace them. ◦ Ensure consistent line of sight to the TV's IR receiver.

If troubleshooting steps do not resolve the issue, please refer to the Warranty and Support section.

Specifications

Feature	Detail
Model Number	AU-RM-C3228-UV020 (Replacement for RM-C3228)
Brand	Azwok
Compatible Devices	JVC Televisions (Specific models listed in Introduction)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	8.46 x 1.77 x 0.59 inches (21.5 x 4.5 x 1.5 cm)
Item Weight	2.57 ounces (72.86 grams)
Special Feature	No Programming Required

Warranty and Support

This Azwok RM-C3228 Replacement Remote Control comes with a**12-month replacement warranty** from the date of purchase.
Warranty Coverage: The warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.
Returns/Exchanges: Returns are accepted for refund or exchange if the remote control does not work with your devices, provided it is within the warranty period and conditions.
Customer Support: If you encounter any issues, have questions about compatibility, or require assistance, please contact the seller or manufacturer directly. Provide your product model number (AU-RM-C3228-UV020) and a detailed description of the issue for prompt support.
For specific contact information, please refer to your purchase documentation or the seller's platform.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQFK5FWR

More documents and user manuals: **https://manuals.plus/**