VECELO KHD-JYX-CST10-BRN-100-BC08

VECELO KHD-JYX-CST10-BRN-100-BC08 39.4-inch Console Table User Manual

Model: KHD-JYX-CST10-BRN-100-BC08

1. Product Overview

The VECELO KHD-JYX-CST10-BRN-100-BC08 is a versatile 39.4-inch console table designed for various uses, including as a couch side table, entryway table, or console table. It features integrated power outlets and USB ports for convenient device charging. The table is constructed with a metal frame and durable PVC wood, offering stability and durability. It includes a baffle to help prevent items from falling off the back edge.



Image 1.1: The VECELO 39.4-inch console table, showcasing its design with integrated power outlets and USB ports, and a long power cord.

2. Safety Information

- Always place the table against a wall or secure it to the wall using the provided anti-tipping hardware.
- Avoid placing heavy items on the top shelf to prevent tipping.
- Ensure all electrical connections are secure and comply with local electrical codes.
- Do not overload the power outlets or USB ports. Refer to the specifications for maximum load.
- Keep liquids away from the power outlets and USB ports to prevent electrical hazards.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- 1 x VECELO Console Table (disassembled components)
- 1 x Accessory Bag (containing screws, bolts, and anti-tipping hardware)
- 1 x Instruction Manual

- 1 x Screwdriver (for assembly)

4. Assembly Instructions

Please read these instructions carefully before beginning assembly. It is recommended that two adults assemble this product. Assembly typically takes less than one hour.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Frame:** Attach the metal frame components using the provided screws and the included screwdriver. Ensure all connections are finger-tight initially.
4. **Attach Tabletop:** Secure the PVC wood tabletop to the assembled metal frame. Pay attention to the orientation of the tabletop to ensure the power outlet module is correctly positioned.
5. **Install Power Module:** Insert the power outlet and USB port module into the designated slot on the tabletop and secure it if necessary.
6. **Tighten All Fasteners:** Once all components are in place, systematically tighten all screws and bolts. Do not overtighten.
7. **Install Anti-Tipping Hardware:** Attach the anti-tipping accessory to the table and secure it to a wall stud as per the instructions provided in the accessory bag. This is crucial for stability and safety.



Image 4.1: The assembled console table positioned in an entryway, demonstrating its potential use as an entrance table.




Image 4.2: Diagram illustrating the dimensions of the VECELO console table, including length, width, and height, and the 9.8-foot power cord length.

5. Operating Instructions (Power Outlets and USB Ports)

The console table is equipped with a built-in power strip for convenient charging of electronic devices.

- **Power Connection:** Plug the table's 9.8-foot power cord into a standard 120V AC wall outlet.
- **AC Outlets:** The table features two 120V/12A AC outlets. These are suitable for powering small appliances, lamps, or charging adapters.
- **USB Ports:** Two 5V/2A USB ports are provided for charging smartphones, tablets, and other USB-powered devices.
- **Baffle Function:** The integrated baffle along the back edge helps prevent items, including charging devices, from falling off the table.



Image 5.1: A detailed view of the integrated power module, showing two AC outlets and two USB ports, with devices connected for charging.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the versatility of the VECELO console table, showcasing its use as a sofa table, entryway table, and console table, highlighting the integrated power outlets and USB ports for convenient charging.

6. Maintenance

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust the table to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining, especially on the PVC wood surface.
- **Electrical Components:** Ensure the power outlets and USB ports remain free of dust and debris. Do not attempt to clean them with liquids.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

7. Troubleshooting

Problem	Possible Cause	Solution
Power outlets/USB ports not working	◦ Table power cord not plugged in. ◦ Wall outlet is not active. ◦ Overload on the power strip.	◦ Ensure the power cord is securely plugged into a live wall outlet. ◦ Test the wall outlet with another device. ◦ Unplug some devices to reduce the load.
Table feels unstable	◦ Loose fasteners. ◦ Anti-tipping hardware not installed or secured. ◦ Uneven floor.	◦ Tighten all screws and bolts. ◦ Install and properly secure the anti-tipping hardware to a wall stud. ◦ Place shims under the legs if the floor is uneven.

8. Specifications

Brand	VECELO
Model Number	KHD-JYX-CST10-BRN-100-BC08
Product Dimensions (L x W x H)	39.4" x 11.8" x 31.5"
Color	Brown
Material	Engineered Wood, Metal
Item Weight	17.41 Pounds
AC Outlets	2 (120V/12A)
USB Ports	2 (5V/2A)
Power Cord Length	9.8 Feet
Indoor/Outdoor Usage	Indoor

9. Warranty and Support

VECELO is committed to providing quality products and customer satisfaction. If you encounter any issues with your product or require assistance, please contact our professional after-sales team.
Email: support@vecelo.com
Please provide your model number and a detailed description of the issue when contacting support to ensure a prompt resolution.