Azwok BRC4C151

Azwok Replacement Remote Control Instruction Manual

For Daikin Air Conditioners (Compatible with BRC4C151, BRC4C152, BRC4C153, BRC4C156, BRC4C158)

1. Overview

This manual provides instructions for the Azwok replacement remote control designed for Daikin Air Conditioners. This remote is a direct replacement for the original BRC4C151 model and is also compatible with BRC4C152, BRC4C153, BRC4C156, and BRC4C158 units. It offers all major buttons and functions of the original remote control without requiring any programming.





Figure 1: Front view of the Azwok replacement remote control. This image displays the remote's main body, including the display screen, ON/OFF button, UP/DOWN temperature controls, and FAN button.

Key Features:

- Direct replacement for Daikin BRC4C151 remote control.
- Compatible with multiple Daikin models: BRC4C152, BRC4C153, BRC4C156, BRC4C158.
- No programming required; ready to use upon battery installation.
- Simple operation for essential air conditioner functions.

2. Setup

To begin using your Azwok replacement remote control, follow these simple steps for battery installation.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

The remote control is now ready for use. No additional programming or pairing is required.

3. Operating Instructions

This section details the functions of the buttons on your replacement remote control.



Figure 3: Front view of the remote control with the sliding cover open, revealing all operational buttons.

Table 1: Remote Control Button Functions

Button	Function
ON/OFF	Powers the air conditioner unit on or off.
UP (▲)	Increases temperature setting or adjusts other parameters upwards.

Button	Function
DOWN (▼)	Decreases temperature setting or adjusts other parameters downwards.
FAN	Cycles through fan speed settings (e.g., Low, Medium, High, Auto).
TEMP TIME	Used for setting temperature or timer functions.
RESERVE CANCEL	Activates or cancels a reserved operation or timer setting.
TIMER	Initiates or adjusts the timer function for scheduled operation.
MODE	Changes the operating mode (e.g., Cool, Heat, Dry, Fan, Auto).
SWING	Controls the louver swing function for air direction.
TEST	Used for diagnostic or test purposes (refer to your AC unit's manual for specific use).

Note: Some advanced functions or specific button behaviors may depend on your particular Daikin air conditioner model. Refer to your air conditioner's original manual for detailed information on specific features.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's display becomes dim or its response becomes inconsistent. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

- **Remote control is not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the air conditioner unit's receiver.
  - Ensure you are within the effective operating range of the air conditioner.
- **Display is dim or blank:**
  - This typically indicates low battery power. Replace the batteries.
- **Remote control functions are inconsistent:**
  - Ensure the remote control is clean and free from dirt or moisture.
  - Replace batteries.

If the problem persists after trying these solutions, please refer to the Warranty & Support section for further assistance.

6. Specifications

Feature	Detail
Brand	Azwok
Model Number (Replacement)	RM-BRC4C151-DK005
Compatible Daikin Models	BRC4C151, BRC4C152, BRC4C153, BRC4C156, BRC4C158
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6.1 x 2.36 x 0.59 inches (15.5 x 6 x 1.5 cm)
Item Weight	3.03 ounces (86 grams)
Special Feature	No Programming Required
Color	Black/White/Silver (as per product variant)

7. Warranty & Support

7.1 Warranty Information

This Azwok replacement remote control comes with a**12-month replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as intended. If the remote control does not work with your compatible device, returns are accepted for refund or exchange.

7.2 Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact Azwok customer support. If your specific Daikin model number is not listed as compatible or if you are unsure about suitability, please reach out to us for confirmation. We are available to help you find the correct remote control for your needs.
Please refer to your purchase documentation or the seller's contact information for specific support channels.