Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-ASW-H09A4-BW001

Azwok Replacement Remote Control for Blueway Air Conditioners User Manual

Models: ASW-H09A4, ASW-H12A4, ASW-H18A4, ASW-H24A4, KFR-35GW/HSZ, 32GW/HSZ, KFR-23GW/HSY

1. Introduction

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Azwok replacement remote control for Blueway Air Conditioners. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

2. Product Overview

The Azwok replacement remote control is designed to function as a direct substitute for the original Blueway Air Conditioner remote. It includes all primary buttons and functions necessary for controlling your air conditioning unit. No programming is required; simply insert batteries, and the remote is ready for use.





Figure 1: Front view of the Azwok replacement remote control. This image displays the remote's main body, LCD screen, and primary control buttons.



Figure 2: Angled view of the remote control, showing its ergonomic design and button layout from a side perspective.

3. Setup: Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote is now ready for use.



Figure 3: Rear view of the remote control with the battery cover removed, illustrating the battery compartment.

4. Operating Instructions

This section details the functions of the buttons on your replacement remote control.



Figure 4: Detailed view of the remote control, highlighting the various buttons and their positions.

- **Power Button ( ):** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Press repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto). The current mode will be displayed on the remote's LCD screen.
- **Temperature Adjustment Buttons (°C+ / °C-):** Use these buttons to increase or decrease the desired temperature setting.
- **Fan Speed Button (❁):** Press to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER Button:** Used to set the auto-on or auto-off timer function. Refer to your air conditioner's original manual for specific

timer programming details.

- **SET Button:** Typically used in conjunction with the TIMER function or for confirming settings.
- **CANCEL Button:** Used to cancel a set timer or other programmed functions.
- **Sleep Mode Button (☽):** Activates or deactivates the sleep mode, which often adjusts temperature and fan speed for comfortable sleep.
- **Swing/Louver Control Button (represented by an arrow icon):** Controls the horizontal or vertical swing of the air conditioner's louvers.

5. Compatibility

This Azwok replacement remote control is compatible with the following Blueway Air Conditioner models:

- ASW-H09A4
- ASW-H12A4
- ASW-H18A4
- ASW-H24A4
- KFR-35GW/HSZ
- 32GW/HSZ
- KFR-23GW/HSY

If your specific air conditioner model is not listed, or if your original remote control differs significantly in appearance, please contact customer support for assistance in verifying compatibility.

6. Maintenance

6.1. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or the display fades. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

6.2. Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

7. Troubleshooting

7.1. Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Obstructions can block the infrared signal.
- **Distance:** Operate the remote within the recommended range of the air conditioner.
- **Interference:** Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the infrared signal. Try operating the remote in a different lighting condition.

7.2. Air Conditioner Not Performing Expected Function

If the remote sends a signal but the air conditioner does not respond as expected (e.g., wrong mode, temperature not changing), consult your air conditioner's original user manual for specific operational details and troubleshooting steps related to the unit

itself.

8. Specifications

Brand	Azwok
Model Number	AU-ASW-H09A4-BW001
Compatible Devices	Blueway Air Conditioners (ASW-H09A4, ASW-H12A4, ASW-H18A4, ASW-H24A4, KFR-35GW/HSZ, 32GW/HSZ, KFR-23GW/HSY)
Connectivity Technology	Infrared
Power Source	2 x AAA Batteries (not included)
Product Dimensions	4.33 x 1.57 x 0.79 inches
Item Weight	1.45 ounces

9. Warranty and Support

9.1. Warranty Information

This Azwok replacement remote control comes with a 12-month replacement warranty. If the product fails to function with your compatible device within this period, please contact customer support for a replacement or exchange.

9.2. Customer Support

For any questions regarding compatibility, operation, or troubleshooting that are not covered in this manual, please contact Azwok customer support. Provide your product model number (AU-ASW-H09A4-BW001) and a detailed description of your issue for prompt assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQGYL5CW

More documents and user manuals: **https://manuals.plus/**