T4TREAM BDC6DRSC-ROWAW

T4TREAM Farmhouse 6-Drawer Dresser Instruction Manual

Model: BDC6DRSC-ROWAW

Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The T4TREAM Farmhouse 6-Drawer Dresser is designed to provide ample storage and enhance the aesthetic of your bedroom, living room, or hallway. Constructed from FSC-Certified wood, optimal MDF, and P2 engineered wood, this dresser offers durability and a rustic appeal. Its antique white finish complements various interior styles.



Figure 1.1: Front view of the T4TREAM Farmhouse 6-Drawer Dresser in Antique White, showcasing its six spacious drawers and rustic design.

2. Setup and Assembly

This dresser requires assembly. It is recommended to assemble the unit in the room where it will be used. Ensure all parts are present before beginning assembly. Detailed installation instructions, coded parts, and precise holes are provided to facilitate accurate and faster assembly.

2.1. Unpacking and Part Identification

- Carefully unpack all components from the packaging.
- Refer to the included parts list and diagrams to identify each piece. Verify that all hardware and panels are accounted for.
- Lay out components on a soft, clean surface to prevent scratches during assembly.

2.2. Assembly Steps

Follow the step-by-step instructions provided in the assembly manual included with your product. Pay close

attention to the orientation of each piece as indicated in the diagrams.

2.3. Anti-Tipping Device Installation

For safety, it is crucial to install the anti-tipping device. This device secures the dresser to the wall, preventing accidental tipping, especially in households with children or pets. Locate the anti-tipping hardware in your package and follow the specific instructions for its installation.




Figure 2.1: Illustration of the anti-tipping device, demonstrating how it secures the dresser to the wall for enhanced stability and safety.

3. Operating Instructions

The T4TREAM 6-Drawer Dresser is designed for convenient and organized storage of clothing and other personal items.

3.1. Drawer Usage

- Each drawer is equipped with metal sliding rails and double-coated metal handles for smooth operation.
- To open a drawer, gently pull the handle outwards. To close, push the drawer firmly until it is fully seated.
- The drawers are designed to hold a significant amount of items, with each 11.4-inch deep drawer capable of

holding approximately 20-25 T-shirts or 15-20 pairs of jeans.



Figure 3.1: View of the dresser with drawers open, illustrating the ample storage capacity suitable for various clothing items.

3.2. Weight Capacity

- The dresser top has a weight capacity of 150 lbs.
- Each individual drawer has a weight capacity of 50 lbs.
- Do not exceed these weight limits to ensure the longevity and stability of the dresser.

4. Care and Maintenance

Proper care and maintenance will help preserve the appearance and functionality of your T4TREAM dresser for years to come.

4.1. Cleaning

- For general cleaning, wipe the dresser surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the distressed finish.

- Immediately wipe up any spills to prevent staining or water damage.

4.2. General Care

- Avoid placing hot items directly on the dresser surface. Use coasters or protective pads.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or fading.
- Periodically check and tighten all assembly hardware to ensure stability.

5. Troubleshooting

This section addresses common issues you might encounter with your dresser.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	• Misaligned drawer slides. • Obstruction in the drawer track. • Loose hardware on drawer slides.	• Check that drawer slides are correctly installed and aligned. • Remove any debris or objects from the tracks. • Tighten all screws on the drawer slides and drawer boxes.
Dresser feels wobbly or unstable.	• Loose assembly hardware. • Uneven floor surface. • Anti-tipping device not installed or improperly secured.	• Retighten all screws and bolts according to the assembly instructions. • Place shims under the dresser legs to level it on uneven floors. • Ensure the anti-tipping device is correctly installed and anchored to a wall stud.
Damage to finish (scratches, discoloration).	• Impact or abrasion. • Exposure to direct sunlight or harsh chemicals.	• Use furniture markers or touch-up kits for minor scratches. • Relocate the dresser away from direct sunlight. • Use only recommended cleaning methods (damp cloth).

6. Product Specifications

Feature	Detail
Model Name	BDC6DRSC-ROWAW
Dimensions (Overall)	15.75"D x 54"W x 31.25"H
Drawer Dimensions (Internal)	Approximately 24.6"W x 11.4"D x 8.2"H (for each of the six drawers)
Color	Antique White
Material	FSC-Certified Wood, Optimal MDF, P2 Engineered Wood
Dresser Top Weight Capacity	150 lbs
Drawer Weight Capacity (Each)	50 lbs
Assembly Required	Yes

Feature	Detail

Item Weight	125.7 pounds
Furniture Finish	Distressed Finish
Drawer Type	European Slide



Figure 6.1: Detailed dimensions and weight capacities for the T4TREAM Farmhouse 6-Drawer Dresser.

7. Warranty and Customer Support

7.1. Warranty Information

The T4TREAM Farmhouse 6-Drawer Dresser comes with a **Lifetime Warranty**. This warranty covers manufacturing defects and ensures the quality of your product under normal use. Please retain your proof of purchase for warranty claims.

7.2. Customer Support

Should you have any questions regarding assembly, parts, operation, or any other concerns about your T4TREAM product, please do not hesitate to contact our customer support team. We are committed to providing a satisfactory answer within 24 hours.
For support, please visit the official T4TREAM store or contact us through the platform where you purchased the product. You can also find more information and contact details on the **T4TREAM Store on Amazon**.

© 2025 T4TREAM. All rights reserved.