

Night Cat US-ZP-32-AGN

Night Cat Upgraded Pop-Up Tent Instruction Manual

Model: US-ZP-32-AGN

INTRODUCTION

Thank you for choosing the Night Cat Upgraded Pop-Up Tent. This manual provides essential information for the safe and effective use, setup, and maintenance of your tent. Designed for quick deployment and compact storage, this tent is suitable for various outdoor activities.

SAFETY INFORMATION

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The tent is made of flame-resistant fabric, but it is not fireproof.
- **Ventilation:** Ensure adequate ventilation to prevent condensation and carbon monoxide buildup if using heating or cooking appliances nearby. Never use fuel-burning devices inside the tent.
- **Weather Conditions:** While designed for rain and wind, avoid using the tent in extreme weather conditions such as severe storms, heavy snow, or strong winds that could compromise its structural integrity.
- **Site Selection:** Choose a level, clear area free of sharp objects, rocks, and debris. Avoid setting up under trees with dead branches.
- **Children:** Keep children away from the tent during setup and folding to prevent injury from spring-loaded poles.

PACKAGE CONTENTS

Verify that all components are present before your trip:

- Night Cat Pop-Up Tent (1)
- Stakes (Included)
- Guylines (4)
- Carry Bag (1)

SETUP INSTRUCTIONS

Unpacking and Initial Setup

1. Remove the tent from its carry bag.
2. Locate a clear, flat area for setup.
3. Unfasten the strap holding the tent in its folded position.
4. Gently toss the tent onto the ground. The tent's internal frame will automatically expand, causing it to pop up into its full shape within approximately 3 seconds.
5. Once expanded, spread out the tent fabric and ensure all poles are fully extended.
6. Secure the tent to the ground using the provided stakes. Insert stakes through the tent's loops and into the ground at an angle for maximum hold.
7. Attach the guylines to the designated points on the tent and stake them out to provide additional stability, especially in windy conditions.



The Night Cat Pop-Up Tent fully set up and ready for use in an outdoor setting.

OPERATING YOUR TENT

Ventilation and Porch Use

The tent features two large doors and two wide windows to ensure excellent airflow and ventilation. This design helps to minimize condensation and keep the interior comfortable.

- **Doors and Windows:** Open the zippered doors and windows to allow air to circulate. Mesh screens are integrated

to keep insects out while maintaining ventilation.

- **Front Porch:** The front door can be extended using your own trekking poles or outdoor sticks (not included) to create a shaded porch area. This provides additional space and protection from sun or light rain while sitting outside the tent.



The tent on a beach with its front door extended to create a shaded porch, enhancing ventilation.

Capacity and Interior Space

With an inner size of 9.5 x 6.6 x 4 ft, this tent is designed to comfortably accommodate 2 adults. It can also fit a queen-size air mattress or Night Cat double sleeping air pads, leaving additional space for camping gear.



Interior view of the tent demonstrating ample space, comfortably fitting a queen-size air mattress.

Weather Resistance

The tent is constructed from waterproof 190T Polyester Taffeta with a PU 2000mm rating. All seams are sealed with waterproof tape to ensure the interior remains dry even during heavy rain or storms. The 6mm stretched poles, pegs, and guylines contribute to its windproof stability.

Fits Queen-size Mattress



The tent demonstrating its waterproof capabilities in a simulated rainy outdoor setting.

FOLDING AND STORAGE

Folding the Tent

Folding the Night Cat Pop-Up Tent is designed to be easier than traditional pop-up tents. Follow these steps:

1. Lay the tent flat on the ground.
2. Bring the two opposite sides of the tent together, forming a figure-eight shape.
3. Fold the figure-eight shape in half, creating a smaller circle.
4. Repeat the folding process once more, twisting the frame gently to form a compact circle.
5. Secure the folded tent with the attached strap.

Note: Practice may be required to master the folding technique. Refer to the visual guide below.

Easier Fold Back




Visual guide demonstrating the steps to fold the tent into a compact circle.

Compact Storage

The upgraded design allows the tent to fold into four circles, resulting in a package size that is 40% smaller than traditional pop-up tents. The package size is approximately 28 x 28 x 2.8 inches (71 x 71 x 7 cm) and weighs 6.6 pounds (3 kg). The integrated hand strap and two back straps make it convenient to carry.

Waterproof in Heavy Rain even Storm



Comparison of the Night Cat tent's compact folded size versus a larger traditional pop-up tent, demonstrating its space-saving design.

MAINTENANCE

Cleaning Your Tent

- **Spot Cleaning:** For minor dirt, use a soft brush or sponge with mild soap and lukewarm water. Gently scrub the affected area.
- **Hand Wash:** For more thorough cleaning, the tent can be hand washed. Avoid using harsh detergents, bleach, or washing machines, as these can damage the waterproof coating and fabric.
- **Rinsing:** Rinse the tent thoroughly with clean water to remove all soap residue.

Drying and Storage

- **Drying:** Always ensure the tent is completely dry before folding and storing. Air dry in a shaded area to prevent UV damage to the fabric. Storing a damp tent can lead to mildew and fabric degradation.
- **Storage:** Store the clean, dry tent in its original carry bag in a cool, dry place away from direct sunlight and extreme

temperatures.

TROUBLESHOOTING

- **Difficulty Folding:** If you find it difficult to fold the tent, review the folding instructions and the visual guide. The process often requires a specific twist and repetition. Practice a few times to get the knack.
- **Condensation Inside Tent:** Ensure proper ventilation by opening doors and windows (mesh screens) when weather permits. Condensation is natural when warm, moist air meets cooler surfaces.
- **Minor Leaks:** While the tent is waterproof, extreme conditions or prolonged exposure can sometimes lead to minor leaks. Inspect seams for any damage. Seam sealer products can be applied to reinforce waterproof integrity if needed.
- **Damaged Poles:** If a pole is bent or broken, contact customer support for replacement options. Avoid forcing bent poles, as this can cause further damage.

TECHNICAL SPECIFICATIONS

Model Number	US-ZP-32-AGN
Occupancy	2 Person
Inner Dimensions (L x W x H)	9.5 x 6.6 x 4 ft (2.9L x 2W x 1.15H Meters)
Item Weight	6.6 Pounds (3 kg)
Folded Package Size	Approx. 28 x 28 x 2.8 inches
Material Type	Polyester Taffeta
Water Resistance Level	Waterproof (PU 2000mm)
Number of Doors	2
Number of Windows	2
Included Components	Stakes
Assembly Time	3 Seconds (Pop-up)

WARRANTY AND SUPPORT

Night Cat products are manufactured to high-quality standards. For specific warranty details or support inquiries, please refer to the product packaging or contact Night Cat customer service directly through their official channels. You can visit the [Night Cat Store on Amazon](#) for more information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question