

[Manuals.plus](#) /

> [bion HEATING](#) /

> bion electrics Sarmiento Wall-Mounted Ceramic Fan Heater Instruction Manual, 2000W

bion HEATING Sarmiento (Model 8059304857218)

bion electrics Sarmiento Wall-Mounted Ceramic Fan Heater Instruction Manual

Model: Sarmiento (8059304857218)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your bion electrics Sarmiento Wall-Mounted Ceramic Fan Heater. Please read these instructions thoroughly before installation and use, and retain them for future reference.



Image 1: The bion electrics Sarmiento Wall-Mounted Ceramic Fan Heater. This image shows the front view of the white ceramic heater with a black control panel on the left, featuring a digital display showing "19:26" and blue indicator lights. A horizontal vent is visible at the bottom.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.

- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

3. PRODUCT OVERVIEW

The bion electrics Sarmiento heater is a wall-mounted ceramic fan heater designed for efficient heating. It features an LCD display, touch controls, and a remote control for convenient operation.

3.1 Components

- Main Heater Unit (with LCD display and touch controls)
- Remote Control
- Mounting Hardware (screws, wall anchors - typically included)

3.2 Control Panel and Display

The integrated LCD display shows current time, temperature, and selected modes. Touch-sensitive buttons allow direct control of the heater functions.

3.3 Remote Control

The remote control provides full functionality from a distance, including power, mode selection, temperature adjustment, timer, and oscillation.

4. SETUP AND INSTALLATION

This heater is designed for wall-mounting. Ensure the chosen location is away from flammable materials, water sources, and has a stable power outlet.

1. **Choose Location:** Select a suitable wall location, ensuring sufficient clearance around the heater (minimum 1 meter from furniture, curtains, etc.). Avoid mounting directly above or below power outlets.
2. **Mark Drilling Points:** Use the provided mounting template (if available) or measure the distance between the mounting holes on the back of the heater. Mark these points on the wall.
3. **Drill Holes:** Drill holes at the marked points using an appropriate drill bit for your wall type. Insert wall anchors if necessary.
4. **Secure Mounting Bracket:** Attach the mounting bracket (if separate) or the heater directly to the wall using the provided screws. Ensure it is securely fastened.
5. **Mount Heater:** Carefully lift the heater and align its mounting slots with the bracket or screws on the wall. Slide it into place until it locks securely.
6. **Power Connection:** Plug the heater into a grounded electrical outlet. Ensure the power supply matches the heater's

requirements (220-240V, 50Hz).



Image 2: The bion electrics Sarmiento heater mounted on a wall, with a Wi-Fi symbol overlaid. This image illustrates the wall-mounted design of the heater, suggesting potential connectivity features.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Press the **POWER** button on the control panel or remote control to turn the heater on or off.
- When powered on, the LCD display will illuminate and show the current time and room temperature.

5.2 Mode Selection

Press the **MODE** button to cycle through available heating modes:

- **Fan Only:** Circulates air without heating.
- **Low Heat (1000W):** Provides gentle heating.
- **High Heat (2000W):** Provides maximum heating power.

5.3 Temperature Adjustment

- In heating modes, use the **+** and **-** buttons on the control panel or remote to set your desired temperature.
- The heater will automatically adjust its operation to maintain the set temperature.

5.4 Oscillation Function

- Press the **OSC** button to activate or deactivate the automatic oscillation function, which distributes warm air more widely.

5.5 Timer Function

The heater features a 24-hour timer for automatic shut-off.

- Press the **TIMER** button.
- Use the **+** and **-** buttons to set the desired operating duration (e.g., 1-24 hours).
- The heater will turn off automatically after the set time expires.

5.6 Weekly Programming

For advanced scheduling, refer to the detailed instructions in the full manual for setting up weekly programs. This feature allows you to set specific on/off times and temperature settings for each day of the week.

5.7 Remote Control Operation

Ensure the remote control has working batteries. Point the remote control directly at the heater's receiver for optimal performance. All functions available on the control panel are also accessible via the remote.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning:** Before cleaning, always unplug the heater and allow it to cool completely. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.

- **Dust Removal:** Periodically use a vacuum cleaner with a brush attachment to remove dust from the air intake and exhaust vents.
- **Storage:** If storing the heater for an extended period, unplug it, clean it thoroughly, and store it in a cool, dry place, preferably in its original packaging.

7. TROUBLESHOOTING

If you encounter issues with your heater, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power button not pressed; Overheat protection activated.	Check power plug and outlet; Press power button; Unplug, wait 30 mins, then plug in again.
No heat output.	Fan Only mode selected; Temperature setting too low.	Select Low Heat or High Heat mode; Increase desired temperature setting.
Remote control not working.	Batteries depleted; Obstruction between remote and heater.	Replace batteries; Ensure clear line of sight to heater.
Unusual noise or smell.	Dust accumulation; Internal malfunction.	Unplug and clean vents; If problem persists, discontinue use and contact support.

8. SPECIFICATIONS

Feature	Detail
Brand	bion HEATING
Model Name	Sarmiento
Model Number	8059304857218
Power Source	Corded Electric
Power Output	1000W / 2000W (Adjustable)
Control Method	Remote, Touch Panel
Form Factor	Cassette (Wall-Mounted)
Features	LCD Display, Automatic Oscillation, 24-hour Timer, Weekly Programming
Item Weight	8 Kilograms
ASIN	B0BQJSL9R3

9. WARRANTY AND SUPPORT

This product comes with a limited warranty. For warranty claims or technical support, please refer to the retailer's return policy or contact bion HEATING customer service.

For information regarding returns within 30 days of receipt, or for defective/damaged products, please consult the retailer's help pages. Specific information for Marketplace purchases may also be available on the retailer's website.

For further assistance, please visit the official bion HEATING website or contact their customer support channels.

