

[Manuals.plus](#) /

> [JVC](#) /

> JVC Deep Bass Wireless Headphones User Manual

JVC HAS36WB

JVC Deep Bass Wireless Headphones

USER MANUAL - MODEL HAS36WB

Introduction

Thank you for choosing the JVC Deep Bass Wireless Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

What's in the Box

- JVC Deep Bass Wireless Headphones (Model HAS36WB)
- USB Charging Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your JVC Deep Bass Wireless Headphones.



Image: Overview of the JVC Deep Bass Wireless Headphones, highlighting their sleek black design.



3EQ



Mic Mute



Voice
assistant



JVC

Image: Detailed view of the headphone earcup, illustrating the location of the 3EQ button, microphone mute, and voice assistant controls.

Controls and Indicators:

- **Power Button:** Used to turn the headphones on/off and initiate pairing mode.
- **Volume Up/Next Track:** Increases volume, long press for next track.
- **Volume Down/Previous Track:** Decreases volume, long press for previous track.
- **Multi-function Button:** Play/pause, answer/end calls, activate voice assistant.
- **EQ Button (Sound Mode):** Cycles through Bass, Clear, and Normal sound modes.
- **Microphone:** For calls and voice assistant.

- **Charging Port (USB):** For connecting the charging cable.
- **LED Indicator:** Shows power status, pairing status, and charging status.

Setup

Initial Charging:

Before first use, fully charge your headphones. Connect the supplied USB charging cable to the charging port on the headphones and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status and turn off when fully charged. A full charge takes approximately 3 hours.

35 HOUR BATTERY LIFE

Rechargeable battery with
3-hour charging time



JVC

Image: Visual representation of the headphones' 35-hour battery life and 3-hour charging time.

Powering On/Off:

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes blue.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns red and then off.

Operating Instructions

Bluetooth Pairing:

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately. This indicates pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "JVC HAS36WB" from the list of found devices.
5. Once connected, the LED indicator on the headphones will slowly flash blue.

Multi-Point Connection:

Your JVC headphones support connecting to two Bluetooth devices simultaneously, such as a smartphone and a laptop. This allows you to seamlessly switch between audio sources.

MULTIPOINT CONNECTION

Simultaneously connect two devices




JVC

Image: Diagram showing the headphones simultaneously connected to a laptop and a smartphone via Bluetooth.

1. Pair the headphones with the first device as described above.
2. Disable Bluetooth on the first device. The headphones will re-enter pairing mode.
3. Pair the headphones with the second device.
4. Re-enable Bluetooth on the first device. The headphones should automatically connect to both devices.
5. Audio will play from the device that is actively transmitting sound.

Custom Sound Modes (EQ):

The headphones feature a built-in EQ with three sound modes: Bass, Clear, and Normal. Press the "SOUND" button on the earcup to cycle through these modes and find your preferred audio profile.



JVC

Image: A user enjoying the headphones, illustrating the availability of Bass, Normal, and Clear sound modes for a customized listening experience.

Voice Assistant Compatibility:

Activate your smartphone's voice assistant (e.g., Siri, Google Assistant) by pressing the Multi-function button twice quickly. You can then issue commands through the headphone's microphone.

Making and Receiving Calls:

- **Answer Call:** Press the Multi-function button once.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds.
- **Redial Last Number:** Press the Multi-function button twice quickly when not on a call.

Maintenance

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. The swivel design allows for flat storage, enhancing portability.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.




Image: The headphones demonstrating their swivel design, allowing them to lay flat for easy storage and portability.

Troubleshooting

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source and try again.
Cannot pair with device.	Ensure headphones are in pairing mode (flashing red/blue). Make sure Bluetooth is enabled on your device. Move headphones closer to the device. Forget "JVC HAS36WB" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Increase volume on both headphones and connected device. Ensure headphones are properly connected to the device. Check if the audio source is playing.

Problem	Solution
Sound quality is poor.	Try changing the EQ sound mode (Bass/Clear/Normal). Ensure there are no obstructions between the headphones and the device. Move away from other wireless devices that might cause interference.

Specifications

Feature	Detail
Model Name	HAS36W
Connectivity Technology	Bluetooth 5.2
Wireless Communication Technology	Bluetooth
Ear Placement	Over Ear
Noise Control	Sound Isolation
Frequency Response	20 - 20000 Hz
Battery Life	Up to 35 Hours
Charging Time	Approx. 3 Hours
Bluetooth Range	10 Meters
Impedance	32 Ohm
Item Weight	5.6 Ounces (158.7 grams)
Product Dimensions	8.9 x 7.4 x 2.17 inches
Material	Plastic
Included Components	Headphones

Warranty and Support

JVC products are designed and manufactured to the highest quality standards. For warranty information and technical support, please refer to the warranty card included with your product or visit the official JVC website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact JVC customer service through their official channels.

