

## Wasserstein 4895230319147

# Wasserstein Anti-Theft Mount for Google Nest Doorbell (Battery)

Model: 4895230319147

## INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Wasserstein Anti-Theft Mount for the Google Nest Doorbell (Battery). This mount is designed to secure your doorbell without requiring drilling, offering enhanced protection against theft and tampering.

## COMPATIBILITY

---

This Anti-Theft Mount is specifically designed for and compatible with the **Google Nest Doorbell (Battery)**. It is not compatible with other doorbell models such as Blink Video Doorbell, Arlo Essential Video Doorbell, or Ring Video Doorbell.

# No-drill installation



Image: Compatibility chart for the Wasserstein Anti-Theft Mount.

## KEY FEATURES

---

- **Anti-Theft Protection:** Designed to prevent your Google Nest Doorbell (Battery) from being stolen or tampered with.
- **No-Drill Installation:** Installs easily in minutes without the need for drilling or permanent modifications to your door.
- **Multiple Mounting Choices:** Can be mounted in two directions to accommodate different door configurations.
- **Durable Construction:** Made of high-grade materials to secure your doorbell reliably.
- **Weather-Resistant:** Built to withstand outdoor elements.

## SETUP AND INSTALLATION

---

### Door Requirements:

- Door thickness must be between 0.9 to 2.3 inches.
- There must be a minimum 1/8 inch gap between the door and the doorframe.

- Not suitable for inward-swinging or flush-fit doors.




Image: Door compatibility dimensions for the mount.

### Installation Steps:

1. Ensure your door meets the thickness and gap requirements.
2. Open your door.
3. Place the Wasserstein Anti-Theft Mount onto the edge of your door, ensuring the doorbell enclosure faces outwards.
4. Adjust the mounting direction if necessary. The mount is reversible to suit either side of your door.



Image: Reversible mounting options for the doorbell mount.

5. Tighten the adjustable screw on the inside of the door until the mount is firmly secured. Do not overtighten.

# Compatibility




Image: Adjustable screw for no-drill installation.

6. Insert your Google Nest Doorbell (Battery) into the mount's enclosure. Ensure the doorbell's metal plate is properly attached to the back of the doorbell before inserting it into the mount.

# Secure your doorbell



Image: Securing the doorbell within the mount.

7. Secure the doorbell within the mount using the provided screws.



Image: Wasserstein Anti-Theft Mount with Google Nest Doorbell (Battery) installed.

## OPERATING INSTRUCTIONS

---

Once installed, the mount provides a secure housing for your Google Nest Doorbell (Battery). The doorbell operates as normal within the mount.

### Charging the Doorbell:

Since the Google Nest Doorbell (Battery) requires periodic recharging, you will need to remove it from the mount for this process. To do so:

1. Unscrew the securing screws that hold the doorbell within the mount.
2. Carefully remove the doorbell from the enclosure.
3. Charge your Google Nest Doorbell (Battery) according to its manufacturer's instructions.
4. After charging, re-insert the doorbell into the mount, ensuring the metal plate is correctly positioned, and secure it with the screws.

## MAINTENANCE

---

The Wasserstein Anti-Theft Mount is constructed from durable, weather-resistant materials designed for long-lasting outdoor use. Regular maintenance is minimal:

- Periodically check the tightness of the adjustable screw to ensure the mount remains securely fastened to the door.
- Clean the mount with a soft, damp cloth as needed to remove dust or debris. Avoid abrasive cleaners.
- Inspect the mount for any signs of wear or damage, especially after severe weather conditions.

## TROUBLESHOOTING

- **Issue: Doorbell not functioning or showing 'Device Off - Device Not Mounted' after reinstallation.**  
**Solution:** Ensure the metal plate that comes with the Google Nest Doorbell is properly attached to the back of the doorbell before placing it into the Wasserstein mount. This plate is crucial for the doorbell's functionality and connection.
- **Issue: Screws for securing the doorbell within the mount are stripping or difficult to use.**  
**Solution:** The provided screws are standard. If you experience stripping, consider replacing them with M3 x 10mm machine screws, preferably with hex socket heads, for improved durability and ease of use with an Allen wrench.
- **Issue: Door does not close properly with the mount installed.**  
**Solution:** Verify that your door meets the specified thickness (0.9 to 2.3 inches) and gap (1/8 inch minimum) requirements. The mount may not be suitable for doors outside these specifications or for inward-swinging/flush-fit doors.









## SPECIFICATIONS

Attribute	Value
Manufacturer	Wasserstein
Part Number	4895230319147
Item Weight	11.7 ounces
Package Dimensions	7.2 x 3.98 x 3.74 inches
Item Model Number	4895230319147
Item Package Quantity	1
Batteries Included?	No
Batteries Required?	No
Date First Available	December 20, 2022

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Wasserstein website or contact their customer service directly. Keep your purchase receipt for warranty claims.

## Related Documents - 4895230319147

<p>Anti-Theft Mount for Google Nest Doorbell (battery) User Manual</p>  <p>W WASSERSTEIN</p>	<p><a href="#">Wasserstein Anti-Theft Mount for Google Nest Doorbell (battery) User Manual</a></p> <p>User manual and installation guide for the Wasserstein Anti-Theft Mount designed for the Google Nest Doorbell (battery). Provides step-by-step instructions, safety information, and product specifications.</p>
	<p><a href="#">Wasserstein Solar Panel for Google Nest Doorbell (Battery) User Manual</a></p> <p>User manual for the Wasserstein Solar Panel, designed to continuously charge the Google Nest Doorbell (Battery). Includes installation instructions for various mounting options, product contents, and frequently asked questions about battery performance and optimization.</p>
	<p><a href="#">Wasserstein Solar Charger for Nest Doorbell (battery) User Manual</a></p> <p>Comprehensive user manual for the Wasserstein Solar Charger designed for the Google Nest Doorbell (battery). Includes setup, installation, and troubleshooting guidance.</p>
	<p><a href="#">Wasserstein Doorbell Vinyl Siding Mount: Installation Guide &amp; User Manual</a></p> <p>Detailed user manual and installation guide for the Wasserstein Doorbell Vinyl Siding Mount. Learn how to easily install the mount for Wyze Video Doorbell Pro, Google Nest Doorbell (Battery), and Blink Video Doorbell. Includes product specifications and support contact.</p>
<p>Horizontal Adjustable Angle Mount For Google Nest Doorbell (battery) USER MANUAL</p>  <p>W WASSERSTEIN</p> 	<p><a href="#">Wasserstein Horizontal Adjustable Angle Mount for Google Nest Doorbell (battery) - User Manual</a></p> <p>Detailed user manual for the Wasserstein Horizontal Adjustable Angle Mount, designed for the Google Nest Doorbell (battery). Learn how to install and adjust your doorbell's viewing angle for optimal security.</p>
<p>Wall Plate USER MANUAL</p>  <p>W WASSERSTEIN</p> 	<p><a href="#">Wasserstein Wall Plate User Manual for Google Nest Doorbell (2nd Gen)</a></p> <p>This user manual provides installation instructions for the Wasserstein Wall Plate, designed to be compatible with the Google Nest Doorbell (Wired, 2nd Gen). It details the contents of the box, compatibility, and step-by-step installation procedures for both standard mounting and using the doorbell wedge. Learn how to securely mount your doorbell with this accessory.</p>

