

[Manuals.plus](#) /

> [HOMSCREENER](#) /

> HOMSCREENER 4 Panel-88" Black Room Divider Instruction Manual

## HOMSCREENER 4 Panel-88"

# HOMSCREENER 4 Panel-88" Black Room Divider Instruction Manual

Model: 4 Panel-88" | Brand: HOMSCREENER

## 1. INTRODUCTION

---

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your HOMSCREENER 4 Panel-88" Black Room Divider. Designed for versatility, this portable and folding privacy screen is ideal for creating distinct spaces within various indoor environments.

## 2. PACKAGE CONTENTS

---

Before assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, contact HOMSCREENER customer support for assistance.



Image: All components of the HOMSCREENER room divider, including fabric panels, metal poles, connectors, and feet, laid out for assembly.

- Fabric Panels (4 pieces)
- Metal Frame Poles (various lengths)
- Wider Base Feet (2 pieces)
- Triple Buckle Hinges/Connectors
- Assembly Hardware (screws, caps, etc.)
- Instruction Manual

### 3. ASSEMBLY INSTRUCTIONS

---

Assembly typically requires one person and can be completed within an hour. For optimal stability, ensure all connections are secure.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat

surface. Refer to the package contents list to ensure all pieces are present.

2. **Assemble Frame Sections:** Connect the metal frame poles using the provided triple buckle hinges and other connectors. Ensure each panel frame is securely formed.
3. **Attach Fabric Panels:** Slide the fabric panels onto the assembled frame sections. The fabric is designed to be wrinkle-free and water-resistant.
4. **Install Base Feet:** Attach the wider base feet to the bottom of the end panels. These feet are designed to enhance stability. Ensure they are firmly secured.
5. **Connect Panels:** Use the triple buckle hinges to connect the individual panels, allowing for flexible adjustment of the divider's configuration.
6. **Final Check:** Verify that all screws are tightened and connections are secure. Gently test the stability of the assembled room divider.



Image: Detail of the triple buckle hinges, which allow for flexible connection and adjustment of the room divider panels.



Image: A close-up view of the upgraded wider metal base, designed to provide increased stability for the room divider.

## 4. OPERATING INSTRUCTIONS

---

The HOMSCREENER room divider is designed for ease of use and flexibility.

### 4.1 Adjusting Panels

Each panel is connected by triple buckle hinges, allowing you to freely adjust the orientation of the screen. This enables you to create various shapes and configurations to suit your space and privacy needs.

### 4.2 Folding and Storage

The room divider can be easily folded for compact storage when not in use. Its lightweight design facilitates portability and space-saving storage in areas like a garage or closet.



Image: The room divider demonstrating its flexible and freestanding design, shown fully extended and compactly folded for storage in a bedroom.

#### 4.3 Recommended Usage Environments

This room divider is suitable for indoor use in various settings:

- Living Rooms
- Bedrooms
- Kids' Rooms
- Sunrooms
- Apartments
- Offices
- Meeting Rooms
- Hospitals
- Studios
- Restaurants
- Classrooms/Schools



Image: A collage illustrating the multi-purpose application of the room divider in diverse environments such as a hospital, office, dining room, living room, and school.

## 5. MAINTENANCE

To maintain the appearance and longevity of your room divider, follow these simple care instructions:

- **Cleaning:** The fabric panels are made from 240g polyester with PA coating, making them easy to clean. Simply wipe with a damp cloth to remove dust or spills.
- **Frame Care:** The steel frame has a powder coating that resists scratches and rust. Periodically check the frame for any signs of wear or damage.
- **Fabric Properties:** The upgraded fabric is designed to be non-see-through, wrinkle-resistant, wear-resistant, and water-resistant. Avoid harsh chemicals or abrasive cleaners that could damage the coating.

## 6. TROUBLESHOOTING

If you encounter any issues with your room divider, refer to the following common solutions:

- **Stability Issues:**

- Ensure all screws and connections are fully tightened. Periodically check and re-tighten if necessary.
  - Confirm the wider base feet are correctly installed and flat on the ground.
  - For high-traffic areas or uneven surfaces, consider placing the divider against a wall or furniture for added support.
  - This product is designed for indoor use. It is not intended to withstand strong winds outdoors.
- **Damaged or Missing Parts:** If any parts were missing or damaged upon arrival, please contact HOMSCREENER customer service for replacement.

## 7. SPECIFICATIONS

<b>Product Dimensions</b>	88"W x 71.3"H
<b>Brand</b>	HOMSCREENER
<b>Color</b>	Black
<b>Number Of Panels</b>	4
<b>Material</b>	Polyester (240g with PA coating)
<b>Item Weight</b>	14.93 pounds
<b>Special Features</b>	Adjustable Footpad, Foldable, Lightweight, Portable, Wrinkle Free
<b>Mounting Type</b>	Floor Mount
<b>Indoor/Outdoor Usage</b>	Indoor Only

## 8. WARRANTY AND SUPPORT

HOMSCREENER is committed to providing quality products and customer satisfaction. If you experience any issues or have questions regarding your room divider, please do not hesitate to contact our customer support team. We are available to assist with missing parts, damaged components, or any other product-related inquiries.

For support, please refer to the contact information provided with your purchase or visit the official HOMSCREENER website.