

[Manuals.plus](#) /

› [KOMFOTT](#) /

› KOMFOTT Metal Twin Over Full Bunk Bed User Manual

KOMFOTT 10382-HU-KT

KOMFOTT Metal Twin Over Full Bunk Bed User Manual

Model: 10382-HU-KT

1. INTRODUCTION

This manual provides detailed instructions for the assembly, safe operation, and maintenance of your KOMFOTT Metal Twin Over Full Bunk Bed. Please read all instructions carefully before assembly and use to ensure proper function and safety.

The KOMFOTT Metal Twin Over Full Bunk Bed features a robust metal frame designed for durability and stability. It includes an integrated ladder and full-length guardrails for user safety. This space-saving design is suitable for various living environments.



Image 1.1: Assembled KOMFOTT Metal Twin Over Full Bunk Bed.

2. SAFETY INFORMATION

Adherence to these safety guidelines is crucial for preventing injury and ensuring the longevity of your bunk bed.

- Always follow the provided assembly instructions precisely.
- Ensure all fasteners are securely tightened before use and periodically check for tightness.
- The maximum weight capacity for the upper bunk is 440 lbs (200 kg).
- The maximum weight capacity for the lower bunk is 660 lbs (300 kg).
- The mattress on the upper bed must be at least 5 inches (12.7 cm) below the top edge of the guardrail to prevent falls.
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit horseplay on or under the bed.
- Use the ladder for entering and exiting the upper bunk.

- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, or jump ropes.



Built-in Ladder

For easy and safe access to the top bunk



Full-Length Guardrails

Prevent accidental falls during the night



Underbed Storage

Store extra bedding, clothing, or other items

Image 2.1: Integrated ladder and full-length guardrails for safety.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Bunk Bed Frame Components (various metal tubes, rails, and slats)
- Hardware Pack (screws, bolts, washers, Allen wrench)
- Installation Manual

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Clear a spacious area for assembly and keep all parts organized. Refer to the

included printed installation manual for detailed step-by-step diagrams.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list in your printed manual to ensure everything is present and undamaged.
2. **Assemble Base Frames:** Begin by assembling the headboards and footboards for both the upper and lower bunks according to the manual's diagrams.
3. **Attach Side Rails:** Connect the side rails to the assembled headboards and footboards for both the twin and full frames.
4. **Install Support Slats:** Place and secure the metal slats onto both the upper twin frame and the lower full frame. Ensure the mute bar is correctly positioned to prevent noise.
5. **Connect Bunks:** Carefully lift and secure the upper twin bunk frame onto the lower full bunk frame using the designated connectors. This step often requires two people.
6. **Attach Ladder and Guardrails:** Install the integrated ladder and ensure all full-length guardrails are securely fastened to the upper bunk.
7. **Final Tightening:** Once fully assembled, go back and tighten all screws and bolts. Do not overtighten.



Image 4.1: The metal frame structure before mattress placement.

5. USAGE GUIDELINES

Proper usage ensures safety and extends the life of your bunk bed.

- **Mattress Requirements:**

- Recommended mattress thickness: 4-6 inches (10-15 cm).
- The top surface of the upper bunk mattress must be at least 5 inches (12.7 cm) below the top edge of the guardrail.

- **No Box Spring Needed:** The bed frame is designed with metal slats that provide sufficient support for mattresses, eliminating the need for a box spring.

- **Underbed Storage:** The 12.5 inches (31.75 cm) of clearance beneath the lower bunk provides space for storage.



Recommended Mattress Thickness

4"-6"
(not included)



NOTE:

The mattress on the upper bed must be at least 5" below the top edge of the guardrail.



Image 5.1: Mattress thickness and guardrail safety illustration.

6. MAINTENANCE

Regular maintenance helps preserve the condition and safety of your bunk bed.

- **Cleaning:** Wipe the metal frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the powder-coated finish.
- **Fastener Check:** Periodically inspect all screws, bolts, and connections to ensure they remain tight. Retighten as necessary to maintain stability.
- **Structural Integrity:** Regularly check for any signs of wear, damage, or loose components. Address any issues promptly.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.


- **Squeaking or Noise:**
 - Ensure all bolts and screws are securely tightened.
 - The bed frame includes a mute bar designed to minimize noise from slats. Verify its correct placement.
- **Wobbling:**
 - Confirm that the bed is assembled on a flat, level surface.
 - Check all connections and tighten any loose fasteners.
- **Difficulty with Ladder:**
 - Ensure the ladder is securely attached to the bunk bed frame.
 - For comfort, consider adding padding to the ladder rungs if needed.

8. SPECIFICATIONS

Product Specifications

Brand	KOMFOTT
Model Number	10382-HU-KT
Size	Twin-Over-Full
Product Dimensions (L x W x H)	77.5" x 59" x 71" (196.85 cm x 149.86 cm x 180.34 cm)
Color	White
Finish Type	Powder Coated
Furniture Finish	Metal
Upper Bunk Weight Capacity	440 lbs (200 kg)
Lower Bunk Weight Capacity	660 lbs (300 kg)
Ground to Item Distance (Underbed Clearance)	12.5 inches (31.75 cm)
Compatible Mattress Size	Twin (upper), Full (lower)

Assembly Required	Yes
Item Weight	80.5 pounds (36.5 kg)



Material	Overall Dimension	Weight Capacity
Metal	77.5" x 59" x 71"	Upper Bed: 440 lbs Lower Bed: 660 lbs

Image 8.1: Detailed product dimensions.

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical assistance, please contact KOMFOTT customer support directly. Refer to your purchase documentation for specific contact details or visit the official KOMFOTT website.

Always provide your model number (10382-HU-KT) and purchase date when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BQMSG1C5>

More documents and user manuals: <https://manuals.plus/>