Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RM-L05-HM002

Azwok RM-L05 Remote Control Instruction Manual

For Humax Freeview Play TV Recorder FVP-4000T Series (500GB, 1TB, 2TB)

Introduction

This document provides instructions for the Azwok RM-L05 replacement remote control, designed for use with Humax Freeview Play TV Recorders. This remote offers all major buttons and functions found on the original RM-L05 remote control. It is ready for immediate use without any programming required.

Compatible Models:

- Humax RML05
- Humax RM L05
- Humax FVP-4000T (500GB, 1TB, 2TB)

If your specific model number is not listed above, or if your original remote control differs significantly from the images provided, please contact customer support to confirm compatibility.

Setup

The Azwok RM-L05 remote control requires two AAA batteries for operation. No programming is needed; once batteries are installed, the remote is ready to function.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.





Image: Back of the remote control with the battery compartment open, showing the correct orientation for AAA battery insertion.





Image: Back of the remote control with the battery compartment cover securely closed.

Operating Instructions

The Azwok RM-L05 remote control uses infrared (IR) technology to communicate with your Humax Freeview Play TV Recorder. Ensure there is a clear line of sight between the remote control and the IR receiver on your recorder for optimal performance.

Basic Functions

- **Power Button (RED):** Press to turn the Humax recorder on or off.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (CH +/-):** Changes the television channel.
- **Mute:** Silences the audio output.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Home Button (HOME):** Accesses the main menu or home screen of your Humax recorder.
- **Guide Button (GUIDE):** Displays the electronic program guide (EPG).
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind):** Controls media playback.
- **Numeric Keypad (0-9):** Directly enters channel numbers or other numerical inputs.



Image: Front view of the Azwok RM-L05 remote control, highlighting the layout of buttons for various functions.



Image: A slightly different angled view of the remote control, showing the ergonomic design and button placement.

Maintenance

To ensure the longevity and proper functioning of your Azwok RM-L05 remote control, follow these maintenance guidelines:

- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades or it stops responding. Always replace both AAA batteries at the same time with new ones.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the surface or internal components.
- **Storage:** Store the remote control in a dry place, away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, such as dropping it, which can cause internal damage.

Troubleshooting

If you experience issues with your Azwok RM-L05 remote control, please refer to the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure the batteries are correctly inserted with the proper polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Check for any obstructions between the remote control and the Humax recorder's IR sensor.
  - Ensure you are within the effective operating range and pointing the remote directly at the recorder.
- **Specific Buttons Not Working:**
  - Clean around the unresponsive button to ensure no debris is preventing its proper function.
  - If only certain buttons are affected, and battery replacement does not resolve the issue, the remote may be defective.
- **Incompatibility:** If the remote control does not work with your Humax device despite following all setup and troubleshooting steps, please verify that your device model is listed under the 'Compatible Models' section.

Specifications

Model Number	AU-RM-L05-HM002
Product Dimensions	8.86 x 1.97 x 0.79 inches
Item Weight	3.63 ounces
Batteries Required	2 x AAA batteries (not included)
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Max Number of Supported Devices	1
Compatible Devices	Television (specifically Humax Freeview Play TV Recorders)

Warranty and Support

This Azwok RM-L05 remote control comes with a **12-month warranty**. This warranty covers manufacturing defects and ensures replacement or refund if the product fails to function as intended with compatible devices.
For warranty claims, technical assistance, or if you are unsure about the compatibility of this remote with your specific Humax model, please contact Azwok customer support. We are committed to assisting you in finding the correct remote control solution. Returns are accepted for refund or exchange if the remote control does not work with your specified devices, provided it is within the warranty period and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQN7S5XM

More documents and user manuals: **https://manuals.plus/**