

[Manuals.plus](#) /

› [Fmart](#) /

› Fmart T8Pro/T9 Window Cleaning Cloths User Manual

## Fmart T8Pro/T9

# Fmart T8Pro/T9 Window Cleaning Cloths User Manual

Essential instructions for the use and care of your Fmart T8Pro and T9 robot window cleaner replacement cloths.

## 1. PRODUCT OVERVIEW

---

These Fmart microfiber cleaning cloths are designed as replacement accessories for the Fmart T8Pro and Fmart T9 electric window cleaning robots. They are crafted to effectively remove dust and stains from glass surfaces, ensuring a streak-free clean. The cloths are fine, soft, reusable, and machine washable, providing a durable and efficient cleaning solution. This package includes 12 cleaning cloths.



Détachant puissant



Lavable en machine



Réutilisable

Microfibre




Image: A set of Fmart T8Pro/T9 microfiber cleaning cloths, highlighting their texture and quantity.

## 2. SETUP AND INSTALLATION


---

Follow these steps to properly prepare and install the cleaning cloths on your Fmart window cleaning robot:

1. **Connect Power:** Ensure your Fmart robot is connected to a power source.
2. **Attach Safety Rope:** Securely connect the safety rope to the robot and a stable anchor point. This is crucial for preventing falls, especially when cleaning exterior windows.
3. **Dampen Cleaning Cloth:** Lightly dampen the cleaning cloth with water or a suitable window cleaning solution. Avoid oversaturating the cloth.
4. **Install Mop Pad:** Attach the dampened cleaning cloth to the designated pad areas on the robot. Ensure it is securely fastened and covers the entire cleaning surface.
5. **Start Operation:** Press the power button on the robot to begin the cleaning process.



1. Connectez l'alimentation électrique



2. Connectez la corde de sécurité



3. Humidifiez le chiffon de nettoyage



4. Installez la serpillière

## 5. APPUYEZ SUR L'INTERRUPTEUR POUR COMMENCER L'UTILISATION



Image: A visual guide showing the five steps for connecting power, attaching the safety rope, dampening the cloth, installing the mop pad, and starting the robot.



Image: Depicts the Fmart T8Pro and T9 robots, illustrating how the cleaning cloths attach to their bases for proper fit and function.

## 3. OPERATING INSTRUCTIONS

Once the cleaning cloths are installed and the robot is powered on, it will begin its cleaning cycle. The microfiber material, combined with the robot's powerful suction, is designed for efficient removal of dirt and dust.

- **Effective Cleaning:** The fine and soft microfiber material is highly effective at trapping dust and lifting stains from glass surfaces.
- **Streak-Free Finish:** These cloths are designed to clean glass without leaving water marks, restoring the shine to your windows.
- **Optimal Usage:** For best results, it is recommended to replace the cleaning cloth with a fresh one for each cleaning session to maintain maximum effectiveness. For daily cleaning, a weekly replacement is suggested.



Image: An Fmart window cleaning robot actively cleaning a large window, demonstrating its operation.



Image: A close-up view of the robot's rotating cleaning pads, illustrating their movement during operation.

## 4. MAINTENANCE AND CARE

---

To ensure the longevity and effectiveness of your Fmart cleaning cloths, proper maintenance is essential.

- **Washing:** The microfiber cloths are machine washable. Use a gentle cycle with cold or warm water. Avoid using bleach or

- fabric softeners, as these can degrade the microfiber's cleaning properties.
- **Drying:** Air dry the cloths or tumble dry on a low heat setting. High heat can damage the microfiber.
  - **Reusability:** These cloths are designed for multiple uses. With proper care, they can be reused many times, making them an environmentally friendly option.




Image: A magnified view of the microfiber material, illustrating its fine texture designed for effective cleaning.

## 5. TROUBLESHOOTING

---

If you encounter issues while using the cleaning cloths, consider the following:

- **Leaving Traces/Streaks:**
  - Ensure the cloth is not oversaturated with cleaning solution. A lightly damp cloth is usually sufficient.
  - Replace the cloth with a clean, fresh one. Dirty or worn cloths can leave streaks.
  - Adjust the amount or type of window cleaning solution used. Some solutions may leave residues.
  - For optimal results, use a dry cloth for a final buffing pass if your robot supports it, or manually buff with a dry microfiber cloth.
- **Reduced Cleaning Effectiveness:**
  - Check if the cloths are clean. Heavily soiled cloths will not clean effectively.
  - Ensure the cloths are securely attached to the robot's pads.
  - Verify that the robot itself is functioning correctly and maintaining proper suction.

## 6. SPECIFICATIONS

---

| Attribute       | Detail                                       |
|-----------------|----------------------------------------------|
| Brand           | Fmart                                        |
| Compatibility   | Fmart T8Pro, Fmart T9 Window Cleaning Robots |
| Material        | Microfiber                                   |
| Item Form       | Wipe                                         |
| Scent           | Unscented                                    |
| Specific Uses   | Window, Glass                                |
| Number of Units | 12 cloths per pack                           |

|                   |                                          |
|-------------------|------------------------------------------|
| Reusability       | Reusable, Machine Washable               |
| Dimensions        | Approximately 16cm (6.3 inches) diameter |
| Country of Origin | China                                    |



Image: A Fmart cleaning cloth with a measurement indicating its 16cm (6.3 inch) diameter.

## 7. WARRANTY AND SUPPORT

Fmart is committed to providing quality products and customer satisfaction.

- **Warranty:** Products typically come with a warranty of up to 24 months. Please refer to your purchase documentation for specific warranty details.
- **Money-Back Guarantee:** A 30-day money-back guarantee is generally offered.
- **Customer Support:** For any questions or assistance, Fmart provides prompt 24-hour email support. Please contact customer service if you have any inquiries regarding your product.

### Customer Service

- Prompt 24 hour email support
- 30 day money back
- Up to 24 months warranty
- 1-3 Days Fast Shipping

Image: Information regarding Fmart's customer service, including 24-hour email support, a 30-day money-back guarantee, and up to 24 months warranty.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question