

[Manuals.plus](#) /

› [Sunslice](#) /

› Sunslice Cyclotron5000 3-in-1 Bike Phone Holder User Manual

Sunslice Cyclotron5000

Sunslice Cyclotron5000 3-in-1 Bike Phone Holder User Manual

Model: Cyclotron5000

1. INTRODUCTION

The Sunslice Cyclotron5000 is a versatile 3-in-1 device designed to enhance your cycling, motorcycling, or scooter experience. It functions as a secure phone holder, an integrated 5000 mAh wireless power bank, and a powerful LED bike light. This manual provides essential information for the safe and effective use of your Cyclotron5000.



Figure 1: The Sunslice Cyclotron5000 in use, highlighting its three main functions: phone holding, wireless charging, and integrated light.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Sunslice Cyclotron5000 3-in-1 Device (Phone Holder, Power Bank, Light)
- Micro-USB cable
- Mounting accessories for handlebar attachment

3. SETUP AND INSTALLATION

Follow these steps to securely attach the Cyclotron5000 to your bicycle, motorcycle, or scooter handlebar.

3.1. Handlebar Mounting

1. Identify the optimal position on your handlebar for visibility and accessibility.
2. Attach the mounting clamp to the handlebar. The clamp is designed for a secure, anti-slip fit. Use the provided tools if necessary to tighten the clamp firmly.
3. Connect the phone holder unit to the mounted clamp. The "Smart Fixing System" allows for quick and secure attachment. Ensure it clicks into place or is tightened appropriately.
4. Adjust the angle of the phone holder for optimal viewing. The adjustable system allows for various orientations.



SHOCK- RESISTANT

The robust and
anti-slip system
keeps your phone
well in place.

Figure 2: Exploded view of the Cyclotron5000 components and its smart fixing system.

SMART FIXING SYSTEM

EASY AND QUICK



Figure 3: Detailed view of the robust clamping mechanism for secure handlebar attachment.

3.2. Phone Placement and Compatibility

The Cyclotron5000 is designed for universal compatibility with most smartphones. Ensure your phone fits within the following dimensions:

- **Width:** 70 mm (min) - 105 mm (max)
- **Length:** 120 mm (min) - 200 mm (max)
- **Thickness:** Max 11 mm

Important Compatibility Note:

We advise against using this product with iPhone 13/14/15 series (including Pro/Pro Max models) as their cameras may protrude significantly, preventing the phone from sitting flush and potentially affecting wireless charging or stability. For other phones, a protective cover is recommended for optimum grip and protection.



Figure 4: Phone compatibility guidelines and dimensions.

4. OPERATING INSTRUCTIONS

4.1. Charging the Cyclotron5000 Power Bank

Before first use, fully charge the integrated 5000 mAh power bank using the provided Micro-USB cable. Connect the Micro-USB cable to the input port on the Cyclotron5000 and the other end to a standard USB power adapter (not included).

4.2. Wireless Phone Charging

Once your phone is securely placed in the holder and the Cyclotron5000 is charged, wireless charging will typically begin automatically if your phone supports it. Ensure your phone is centered on the charging pad for optimal performance. The power bank allows you to navigate without concern for battery depletion.

Alternatively, you can charge your phone via a USB cable using the USB 2.4A output port on the Cyclotron5000.



Figure 5: Phone securely mounted and charging wirelessly while navigating.

4.3. Using the Integrated LED Light

The Cyclotron5000 features a powerful built-in LED light for enhanced visibility and safety, especially during night rides. Locate the power button for the light, typically on the device itself. Press the button to cycle through light modes (e.g., on, flashing, off). Refer to the device for specific button functions.



EASY & STRONG CLAPING SYSTEM




Figure 6: The Cyclotron5000's integrated LED light in operation.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Sunslace Cyclotron5000, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the Cyclotron5000 in a cool, dry place.
- **Battery Care:** For optimal battery health, avoid fully discharging the power bank frequently. Recharge it periodically if stored for a long time.
- **Water Resistance:** Note that the device is **not water resistant**. Avoid exposure to heavy rain or submersion in water.

6. TROUBLESHOOTING

If you encounter issues with your Cyclotron5000, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone not charging wirelessly.	Phone not properly aligned on the charging coil. Phone case is too thick or contains metal. Cyclotron5000 power bank is discharged. Phone model is incompatible (e.g., protruding camera).	Adjust phone position to ensure proper alignment. Remove phone case or use a thinner, non-metallic case. Recharge the Cyclotron5000 power bank. Check phone compatibility (refer to Section 3.2).
LED light turns on unexpectedly or cannot be turned off.	Accidental button press. Device malfunction.	Press the light button repeatedly to cycle through modes until it turns off. If the issue persists, contact customer support.
Phone feels unstable or slips in the holder.	Holder not tightened sufficiently. Phone dimensions are at the edge of compatibility. No protective cover on the phone.	Ensure all clamps and adjustments are securely tightened. Verify phone dimensions against specifications (Section 3.2). Use a protective phone cover for better grip.
Device does not power on or charge.	Power bank is fully discharged. Faulty charging cable or adapter.	Connect the Cyclotron5000 to a power source using the Micro-USB cable and allow it to charge. Try a different Micro-USB cable and power adapter. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Cyclotron5000
Brand	Sunslice
Color	Black
Power Bank Capacity	5000 mAh
Charging Output	Wireless Charging, USB 2.4A Output
Light Feature	Integrated LED Light (Strong Headlight)
Mounting Type	Handlebar
Compatible Vehicle Types	Bicycle, Motorcycle, Scooter
Compatible Phone Width	70 mm (min) - 105 mm (max)
Compatible Phone Length	120 mm (min) - 200 mm (max)

Feature	Detail
Compatible Phone Thickness	Max 11 mm
Item Dimensions (L x W x H)	5.98 x 3.94 x 1.38 inches
Item Weight	480 Grams
Material	Acrylonitrile Butadiene Styrene (ABS)
Water Resistance Level	Not Water Resistant

8. WARRANTY INFORMATION

The Sunslice Cyclotron5000 comes with a **2 Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to water. Please retain your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Sunslice customer service through their official website or the retailer where you purchased the product.

Website: www.sunslice.eu (or relevant regional website)

Please have your model name (Cyclotron5000) and proof of purchase ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question