Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-KP3AS-MB004

Azwok KP3AS Remote Control User Manual

Replacement Remote for Mitsubishi Air Conditioners

1. Introduction

This manual provides instructions for the Azwok KP3AS replacement remote control, designed for use with various Mitsubishi Air Conditioner models. This remote offers the primary functions of your original remote control without requiring any programming.

Compatible Models: KP3AS, KP3BS, KM04B, KM04F, KG1F, KP1A, KPOA, KP06CS, KP06KS, KP07BS, KGIC2972, KGIC2853, KGIC2183P, KGIC0462, MS-07NV, MS-07RV, MS-09NV, MS-09NW.

2. Product Overview

The Azwok KP3AS remote control features a clear display and intuitive buttons for easy operation of your air conditioner.





Image 2.1: Front view of the Azwok KP3AS remote control, showing the display, ON/OFF button, and temperature adjustment buttons.



Image 2.2: The Azwok KP3AS remote control with its battery cover removed, revealing additional function buttons such as MODE, FAN, VANE, ECONO COOL, COOL, SLEEP, STOP, START, HR., MIN., and RESET CLOCK, alongside the battery compartment.

3. Setup

The Azwok KP3AS remote control is designed for immediate use without any programming. Simply install the batteries, and it will be ready to operate your compatible Mitsubishi Air Conditioner.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: Batteries are not included with the remote control.

4. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

4.1 Basic Functions

- **ON/OFF:** Press the orange **ON/OFF** button to turn the air conditioner on or off.
- **Temperature Adjustment:** Use the **TOO WARM (▼)** button to decrease the temperature and the **TOO COOL (▲)** button to increase the temperature.

4.2 Advanced Functions (Under Battery Cover)

Slide down the front panel to access additional control buttons:

- **MODE:** Cycles through operating modes (e.g., Auto, Cool, Dry, Fan, Heat).
- **FAN:** Adjusts the fan speed.
- **VANE:** Controls the direction of the airflow (louvre swing).
- **ECONO COOL:** Activates energy-saving cooling mode.
- **COOL:** Sets the air conditioner to cooling mode.
- **SLEEP:** Activates sleep mode for comfortable nighttime operation.
- **STOP/START:** Used for setting timer functions.
- **HR./MIN.:** Adjusts hours and minutes for timer settings.
- **RESET CLOCK:** Resets the internal clock of the remote control.

5. Maintenance

5.1 Battery Replacement

Replace batteries when the remote control's display dims or its response becomes sluggish. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries or different types of batteries.

5.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are installed correctly and are not depleted. Replace if necessary.

- Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.
- Verify that the air conditioner is powered on.

- **Remote functions are incorrect:**
  - Confirm that your air conditioner model is listed as compatible.
  - If your air conditioner model is not listed or your original remote differs significantly, contact customer support for assistance.

7. Specifications

- **Model Number:** AU-KP3AS-MB004
- **Product Dimensions:** 6.3 x 2.17 x 0.59 inches
- **Item Weight:** 2.86 ounces
- **Batteries Required:** 2 x AAA (not included)
- **Connectivity Technology:** Infrared
- **Compatible Devices:** Air Conditioner
- **Special Feature:** No Programming Required
- **Max Number of Supported Devices:** 1
- **Manufacturer:** Azwok

8. Warranty and Support

This Azwok remote control comes with a 12-month replacement warranty from the date of purchase. If you encounter any issues or have questions regarding compatibility or operation, please contact the seller or manufacturer's customer support for assistance.

If you cannot find your specific air conditioner model listed or are unsure about compatibility, it is recommended to contact customer support before purchase to ensure suitability.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQRSM34Q

More documents and user manuals: **https://manuals.plus/**