

[Manuals.plus](#) /

› [Bluey](#) /

› Bluey Vehicle and 4 Figure Pack, Escape Convertible with Four 2.5 Inch Figures, 9 Accessories and Sticker Sheet | Amazon Exclusive
Escape Convertible - Exclusive

Bluey 17589

Bluey Vehicle and 4 Figure Pack: Escape Convertible Instruction Manual

Comprehensive guide for assembly, play, and care of your Bluey Escape Convertible playset.

PRODUCT OVERVIEW

The Bluey Vehicle and 4 Figure Pack brings to life the iconic Escape Convertible from the beloved Bluey episode "Escape." This playset allows children to recreate imaginative, fast-paced adventures with Bluey and her family. The bright red convertible is designed to comfortably seat four figures, enabling dynamic play scenarios.

- Recreate scenes from the "Escape" episode with Bluey's iconic red convertible.
- The convertible features seating for all four included figures.
- Includes four special 2.5-3 inch figures: Cupcake Bluey, Sunglasses Chilli, Shuttershade Bandit, and Jerry Lee the Butler.
- Comes with a fun sticker sheet featuring drawings by Bluey and Bingo from the "Escape" episode.
- Nine accessories are included: 1 table, 4 chairs, food and drink for a road trip, and a camera.



Figure 1: Complete Bluey Vehicle and 4 Figure Pack with all included items.

WHAT'S IN THE BOX

Your Bluey Vehicle and 4 Figure Pack includes the following components:

- 1 x Red Convertible Vehicle
- 4 x Figures (Cupcake Bluey, Sunglasses Chilli, Shuttershade Bandit, Jerry Lee the Butler)
- 9 x Accessories (1 table, 4 chairs, food, drink, camera)
- 1 x Sticker Sheet



Figure 2: Detailed view of the included figures and accessories.

SETUP

Setting up your Bluey playset is quick and easy, allowing for immediate play.

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all 1 vehicle, 4 figures, 9 accessories, and 1 sticker sheet are present.
2. **Figure Placement:** The convertible has designated pegs in each seat to securely hold the figures. Align the holes on the bottom of the figures' feet with the pegs in the car seats and gently press down until they are seated firmly.
3. **Accessory Arrangement:** Arrange the table and chairs to create a cafe scene for the figures. The food, drink, and camera accessories can be placed with the figures to enhance imaginative play.
4. **Sticker Application:** Use the included sticker sheet to customize the convertible or other play surfaces as desired.

Your browser does not support the video tag.

Video 1: Official "Flip It & Gift It" video demonstrating the packaging and initial unboxing of the product. This video is provided by the seller.

OPERATING INSTRUCTIONS

The Bluey Escape Convertible playset is designed for open-ended imaginative play. Here are some ways to interact with the set:

- **Driving Adventures:** Place the figures in the convertible and push the car along smooth surfaces to simulate road trips and adventures. The wheels are free-rolling for easy movement.
- **Character Interaction:** The figures feature articulated bodies, allowing them to sit and stand. Chilli and Bandit's sunglasses can be slid up and down for varied play.
- **Cafe Play:** Use the table and chairs to set up a cafe scene. The food and drink accessories can be used for pretend meals or picnics.
- **Photography Fun:** The small camera accessory can be held by the figures to simulate taking pictures during their adventures.





Figure 3: Various views of the Bluey Escape Convertible for play reference.

MAINTENANCE

To ensure the longevity and cleanliness of your Bluey playset, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the vehicle, figures, and accessories with a soft, damp cloth. Use mild soap if necessary, then wipe clean with water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset and its components in a clean, dry place away from direct sunlight and extreme temperatures to prevent damage or discoloration.
- **Inspection:** Periodically inspect all parts for any signs of wear or damage. Discontinue use if any parts are broken or pose a safety risk.

TROUBLESHOOTING

If you encounter any issues with your Bluey playset, consider the following common solutions:

Issue	Possible Cause	Solution
Figures do not stay in seats.	Figures not properly aligned with pegs.	Ensure the holes on the figures' feet are aligned with the pegs in the car seats and press firmly.
Car wheels are not rolling smoothly.	Debris caught in wheels or on surface.	Check for and remove any debris from the wheels. Ensure play surface is clean and smooth.
Accessories are easily lost.	Small size of accessories.	Store all accessories in a designated container or the original packaging when not in use.

Safety Information

Please read and adhere to the following safety guidelines for safe play:

- **CHOKING HAZARD:** Small parts. Not for children under 3 years.
- Adult supervision is recommended during play, especially with younger children.
- Do not put any parts of the toy in the mouth.
- Keep packaging materials away from children to avoid suffocation hazards.

Specifications

Feature	Detail
Product Dimensions	3.39 x 8.78 x 4.25 inches
Item Weight	8.1 ounces
Model Number	17589
Manufacturer Recommended Age	36 months - 15 years
Country of Origin	Vietnam
Manufacturer	MOOSE TOYS LLC
Release Date	July 15, 2023

Warranty & Support

For any questions regarding product warranty, defects, or general support, please contact MOOSE TOYS LLC directly. You can also visit the official [Bluey Store on Amazon](#) for more information and product updates.