Ticktime TK1-Bl1

Ticktime Pomodoro Timer Cube TK1-Bl1 User Manual

Model: TK1-Bl1

1. Introduction

The Ticktime Pomodoro Timer Cube is a versatile digital timer designed to enhance productivity and time management. It features multiple timing modes, including preset countdowns, custom countdowns, and a dedicated Pomodoro mode, along with silent vibration and adjustable sound alerts. Its compact, magnetic, and rechargeable design makes it suitable for various scenarios, from work and study to cooking and workouts.

2. Package Contents

Upon opening your Ticktime Pomodoro Timer Cube package, you should find the following items:

- 1 x Ticktime Pomodoro Timer Cube
- 1 x User Manual
- 1 x Type-C Charging Cable



An exploded view of the Ticktime Cube's packaging, showing the timer itself, the user manual, and the Type-C charging cable.

3. Setup

3.1 Initial Charging

Before first use, charge the Ticktime Pomodoro Timer Cube for **12 hours**. For subsequent uses, a **4-hour** charge is recommended. The timer cannot be used while charging. Once charging is complete, unplug the charging cable and press the on/off button to power on the timer.



The Ticktime Cube connected to a USB-C charging cable, illustrating its rechargeable battery feature.


3.2 Water Resistance

Please note that the Ticktime Pomodoro Timer Cube is **not waterproof**. Avoid exposure to water or excessive moisture.

4. Operating Instructions

4.1 Basic Timer Operation (Flip to Start)

The timer features preset countdowns that are activated by simply flipping the cube to display the desired time on its top face. The available preset times are **1, 3, 5, and 10 minutes** Additional preset times of **15, 25, 45, and 60 minutes** can be activated by a long press on the fingerprint icon located on the side corresponding to the desired number.



The main view of the Ticktime Pomodoro Timer Cube, displaying the 5-minute preset countdown on its top face.

Your browser does not support the video tag.

An official product video demonstrating the Ticktime Cube's key features, including its patented gravitational innovation, built-in rechargeable battery, long battery life, flip-to-pause/play functionality, custom countdown setting, and versatile use in various environments like the kitchen, gym, office, and library.

Your browser does not support the video tag.

An official product video showcasing the Ticktime Cube's features, including its flip-to-start function for preset times, custom countdown setting, Pomodoro mode, and magnetic design for convenient placement.

4.2 Custom Countdown

To set a custom countdown time, use the two buttons located on the timer. The timer range for custom settings is from **00:01 to 99:59**.



The Ticktime Cube displaying a custom countdown, with the 'M+' and 'S+' buttons visible for adjusting minutes and seconds.

4.3 Pomodoro Mode

Activate the Pomodoro mode by long-pressing the fingerprint icon on the side of the timer marked with the number 5. In this mode, the timer will alert you after **25 minutes of work** and then for a **5-minute break**, helping to maintain focus and productivity.




A visual representation of the Pomodoro countdown feature, showing a cycle of 25 minutes of work followed by a 5-minute break, activated by long-pressing the fingerprint icon on the '5' side.

4.4 Pause & Resume

To pause the countdown, simply flip the timer over so the front screen faces upwards. To resume, flip it again. Alternatively, you can use the on/off button to pause or resume the timer.

4.5 Sound & Vibration Settings

The timer offers flexible alert options. You can choose between a silent vibration mode, an adjustable sound alert, or mute the alerts entirely. Adjust the sound volume to your preference.



The Ticktime Cube displaying its sound and vibration settings, indicated by respective icons on the screen.

Your browser does not support the video tag.

An official product video demonstrating the Ticktime Cube in black, highlighting its ease of use for various activities like cooking, studying, and exercising, and showcasing its sound and vibration alert options.

4.6 Count-Up Mode

To initiate the count-up mode, place the timer with its bottom face upwards. To stop the count-up, simply stand the screen

up.

5. Maintenance

Keep the device clean by wiping it with a soft, dry cloth. Avoid using abrasive cleaners or solvents. Ensure the device is not exposed to water or extreme temperatures.

6. Troubleshooting

If the timer is not responding, ensure it is fully charged. If issues persist, try turning the device off and on again. For further assistance, please refer to the contact information provided in the warranty section.

7. Specifications

Feature	Detail
Color	Black
Brand	Ticktime
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	1.7"D x 1.7"W x 1.7"H
Item Weight	1.6 ounces
Number of Preset Settings	4 (1/3/5/10 minutes) + 4 (15/25/45/60 minutes via long press)
Screen Size	1.7 Inches
Item Model Number	TK1-Bl1

8. Warranty and Support

For warranty information or technical support regarding your Ticktime Pomodoro Timer Cube TK1-Bl1, please visit the official Ticktime website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

© 2026 Ticktime. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question