

Furnulem TYDS-8D002-47

Furnulem Wide Dresser with 8 Fabric Drawers Instruction Manual

Model: TYDS-8D002-47

INTRODUCTION


Thank you for choosing the Furnulem Wide Dresser with 8 Fabric Drawers. This manual provides essential information for the safe assembly, operation, and maintenance of your new dresser. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- **Anti-Tip Kit:** For your safety, an anti-tip kit is included. Securely fasten the dresser to the wall using this kit to prevent accidental tipping.
- **Soft-Edged Drawers:** The fabric drawers are designed with soft edges to prevent accidental pinching.
- **Weight Capacity:** Do not overload drawers or the top surface. The wooden top is suitable for a TV up to 55 inches, but ensure the weight is evenly distributed and within the product's limits.
- **Assembly:** Ensure all screws and fasteners are tightened securely during assembly. Do not overtighten.



Adjustable Feet



Anti Tip Kit



X-Steel Frame

Adjustable feet for stability, anti-tip kit for wall mounting, and the X-steel frame for structural integrity.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. Refer to the included parts list in your package for detailed identification.

- Metal Frame Components
- Wooden Top Board
- 8 Fabric Drawers with Handles
- Assembly Hardware (screws, wrench, etc.)
- Anti-Tip Kit

SETUP AND ASSEMBLY

Assembly is designed to be quick and hassle-free, typically taking around 20 minutes. All necessary tools and accessories are provided.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the metal frame according to the step-by-step guide provided in your package. Ensure all connections are secure but do not fully tighten screws until the entire frame is assembled.
3. Attach the wooden top board to the assembled metal frame.
4. Assemble the fabric drawers by inserting the bottom board and attaching the handles.
5. Insert the assembled drawers into the frame.
6. Once the dresser is fully assembled, tighten all screws completely.
7. Install the anti-tip kit to secure the dresser to a wall.

Assembly Videos:

Furnulem 8 Drawer Dresser Installation Video

Your browser does not support the video tag.

Official installation video for the Furnulem 8-drawer dresser, demonstrating step-by-step assembly.

Furnulem 8 Drawers Fabric Dresser TV Entertainment Center

Your browser does not support the video tag.

A video showcasing the Furnulem 8-drawer fabric dresser as a TV entertainment center, highlighting its features and capacity.

Installation Video, WLIVE Dresser TV Stand

Your browser does not support the video tag.

An installation video for a similar dresser TV stand, providing general guidance on assembling this type of furniture.

11 Drawer Dresser Install Video

Your browser does not support the video tag.

A detailed installation video for an 11-drawer dresser, offering visual steps that may apply to your 8-drawer model.

Installation video of Dressers

Your browser does not support the video tag.

An assembly video demonstrating the installation process for dressers, useful for understanding the general construction.

11 Drawers Dresser

Your browser does not support the video tag.

A video showcasing an 11-drawer dresser, which can provide insight into the functionality and appearance of similar models.

OPERATING INSTRUCTIONS

Using the Fabric Drawers:

- The 8 fabric drawers are designed for organizing clothes, bedding, accessories, and other items.
- To open, gently pull the handle. To close, push the drawer back into the compartment until it is flush with the frame.
- Avoid forcing drawers open or closed if they encounter resistance. Check for obstructions.

- The drawers are removable for easy organization and cleaning.




The spacious fabric drawers offer ample storage for various items, keeping your space tidy.

Utilizing the Wood Top:

- The sturdy wooden top can serve as a TV stand for screens up to 55 inches, a console table, or a display area for decorative items.
- Ensure any items placed on the top are within the dresser's weight capacity and are stable to prevent falling.

PRODUCT DIMENSIONS



Product dimensions and scale, illustrating the dresser's capacity to hold a 55-inch TV.

MAINTENANCE

- **Cleaning:** Wipe the wooden top and metal frame with a dry cloth. For fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as needed.
- **Avoid Moisture:** Keep the dresser away from excessive moisture and direct sunlight to prevent damage to the wood and fabric.

TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the assembly video or contact customer support for assistance.

- **Wobbly Dresser:** Ensure all screws are fully tightened. Adjust the leveling feet on the bottom of the frame to stabilize the dresser on uneven floors.
- **Drawers Not Sliding Smoothly:** Check that the fabric drawers are correctly assembled and inserted. Ensure no items are obstructing the drawer's movement.

SPECIFICATIONS

Feature	Detail
Brand	Furnulem
Model Number	TYDS-8D002-47
Product Dimensions	11.82"D x 47.2"W x 31.5"H
Color	Black Oak
Material	Engineered Wood, Fabric Drawers, Metal
Number of Drawers	8
Item Weight	14.97 pounds
Assembly Required	Yes

WARRANTY

This product comes with a **12-month warranty** for quality-related issues. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

Should you have any questions, require assistance with installation, or need to report missing parts or technical difficulties, our dedicated customer support team is available 24/7. Please reach out via the easy-access messaging platform on the retailer's website for prompt guidance, replacement items, or expert solutions.