

[Manuals.plus](#) /

› [COMHOMA](#) /

› COMHOMA Recliner Chair Set Instruction Manual

COMHOMA H7134-3+1+1

COMHOMA Recliner Chair Set Instruction Manual

Model: H7134-3+1+1

Brand: COMHOMA

1. INTRODUCTION

Thank you for choosing the COMHOMA Recliner Chair Set. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new furniture. Please read this manual thoroughly before assembly and use to ensure safe and optimal performance.



Figure 1: The COMHOMA Recliner Chair Set, featuring a three-seater sofa, a two-seater loveseat, and a single recliner, all in black bonded leather.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Bonded leather upholstery may not meet flammability standards. Keep away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks, especially during reclining operations.
- Ensure all components are securely fastened before use. Regularly check and tighten any loose connections.
- Do not stand on the furniture or use it as a step stool.
- Avoid placing heavy or sharp objects on the reclining mechanisms.

3. SETUP AND ASSEMBLY

Your COMHOMA Recliner Chair Set is shipped in multiple boxes. Packages may arrive separately. Please ensure all boxes are received before beginning assembly.

3.1 Unpacking and Initial Inspection

Carefully unpack all components. It is normal for a small amount of folds to appear on the surface of the PU leather sofa when taken out due to vacuum-packing. Gently tapping, hot air, or normal use over a period of time will help reduce these folds. Generally, surface folds will gradually return to flat after 3-10 uses. Folds can also be removed by heating with a hair dryer (use appropriate temperature).

3.2 Assembly Steps

The recliner set is designed for easy assembly. The main components typically slide and hook together. For the multi-seater units, the individual seats connect to form the complete sofa or loveseat.

Easy to use

massage remote control



4 massage
Parts



5 massage
Modes



Heat function
For lumbar part



Vibration
Strength



Zero gravity
Regulation



360° Degrees
Swivel

Figure 2: Key components of the recliner, highlighting the padded headrest, cup holder, foot support board, and the durable metal frame designed to support up to 400 lbs.

Your browser does not support the video tag. Please download the video to view it.

Video 1: Official COMHOMA Recline Chair Set overview, demonstrating assembly and key features. This video illustrates how the individual pieces connect and the reclining mechanism operates.

4. OPERATING INSTRUCTIONS

The COMHOMA Recliner Chair Set offers various comfort features for an enhanced relaxation experience.

4.1 Reclining Function

The sofa and loveseat feature reclining capabilities on their end seats, while the single recliner offers full reclining. To recline, place your hands on the armrests and, in conjunction with pushing forward on the arms, lean backwards using your body weight to recline the chair up to 150 degrees. To retract the footrest, simply push down with your legs until it locks into place.

Size:(Inch)



Figure 3: Illustration of the recliner's various positions, including upright for reading, partially reclined for watching, and fully reclined for sleeping. The pull handle for reclining is also shown.

4.2 Single Recliner Special Features

Only the single recliner in the set includes rocking, massage, heating, and swivel functions for ultimate comfort.

- **Rocking Function:** Allows for gentle back-and-forth motion.
- **Massage Function:** Features 4 massage parts and 5 massage modes for targeted relaxation.
- **Heat Function:** Provides warmth for the lumbar area.
- **Swivel Function:** Enables 360-degree rotation for flexible positioning.



Figure 4: The easy-to-use massage remote control for the single recliner, detailing its various functions including massage, heat, and vibration. The chair's 360-degree swivel capability is also highlighted.

4.3 Additional Features

- **Built-in Drink Holders:** Conveniently located on the armrests for beverages.
- **Side Pockets:** Ideal for storing magazines, remote controls, or other small items.
- **Plush Padding:** Delivers support where needed most, featuring soft cushioning, excellent lumbar support, and full chaise seating.




Figure 5: A visual summary of the recliner's premium features, including its high back with thick sponge padding, durable steel structure, convenient side pockets, cup holders, and the remote-controlled massage and heating functions.

5. MAINTENANCE

To ensure the longevity and appearance of your COMHOMA Recliner Chair Set, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the bonded leather.
- **Folds:** For any folds that appear due to vacuum-packing, gently tap the surface, use a hair dryer on an appropriate temperature, or allow normal use to gradually smooth them out.
- **Mechanism:** Periodically check the reclining mechanism for smooth operation. Ensure no foreign objects obstruct its

movement.

- **General Care:** Avoid prolonged exposure to direct sunlight or extreme temperatures, which can cause the material to fade or crack.

6. TROUBLESHOOTING

If you encounter any issues with your recliner set, please refer to the following common solutions:

Problem	Possible Cause	Solution
Reclining mechanism is stiff or not engaging.	Obstruction in mechanism; lack of lubrication; damaged cable.	Check for obstructions under the chair. Apply silicone lubricant to moving parts. If cable is damaged, contact customer support.
Folds or wrinkles on leather surface.	Vacuum-packing during shipping; new product settling.	Gently tap the surface, use a hair dryer on low heat, or allow normal use (3-10 uses) for wrinkles to naturally diminish.
Sofa/Loveseat sections not securely joined.	Hooks not properly engaged.	Lift and re-align sections, ensuring the metal hooks on the sides slide fully into their corresponding slots.

7. SPECIFICATIONS

Detailed specifications for the COMHOMA Recliner Chair Set (Model H7134-3+1+1):

Feature	Detail
Model Number	H7134-3+1+1
Material	Bonded Leather (Upholstery), Metal (Frame)
Color	Black
Sofa Dimensions (L x W x H)	82.3 x 20.0 x 39.4 inches
Loveseat Dimensions (L x W x H)	59.0 x 20.0 x 39.4 inches
Single Chair Dimensions (L x W x H)	35.8 x 20.0 x 39.4 inches
Fully Reclined Length (Single Chair)	63 inches
Item Weight	99.5 pounds (for single chair, total weight varies by set configuration)
Recline Angle	Up to 150 degrees
Special Features (Single Chair Only)	Rocking, Massage, Heating, Swivel Functions
Manufacturer	COMHOMA

Feature	Detail
Product Care	Wipe clean



Figure 6: Detailed dimensional drawing of the single recliner chair, providing measurements for height, width, depth, and reclined length.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your COMHOMA Recliner Chair Set, please contact the seller or manufacturer directly.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for details.
- **Customer Support:** For assistance, you may contact the seller, Verona Sky, through the Amazon platform.
- **Protection Plans:** Extended protection plans may be available for purchase. Please check the product listing for options such as 2-Year or 3-Year Protection Plans.