azwok AU-PN012-PN

Instruction Manual

azwok Replacement Remote Control for Panasonic Air Conditioners

Model: AU-PN012-PN

Introduction

Thank you for choosing the azwok Replacement Remote Control for Panasonic Air Conditioners. This remote is designed to function as a direct replacement for your original Panasonic air conditioner remote, offering all primary buttons and functions. It is ready to use without any programming required, simply install the batteries.
Compatible Panasonic Models: A75C428, A75C559, A75C561, A75C598, A75C606.

1. Setup

1.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.**Batteries are not included.**
4. Close the battery cover securely.



Image: Back of the remote control with the battery compartment open, ready for AAA battery insertion.

1.2 Initial Use

This remote control is pre-programmed and requires no additional setup. Once batteries are installed, it is ready for immediate use with your compatible Panasonic air conditioner.

2. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions

between the remote and the unit.



Image: Front view of the remote control, displaying its buttons and LCD screen.

2.1 Button Functions

- **OFF/ON:** Powers the air conditioner on or off.
- **SLEEP:** Activates or deactivates the sleep mode for comfortable overnight operation.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP (Up/Down Arrows):** Adjusts the desired temperature setting.
- **FAN SPEED:** Changes the fan speed (e.g., Low, Medium, High, Auto).
- **SWING:** Controls the horizontal louver swing function.
- **AIR SWING:** Controls the vertical louver swing function.
- **MANUAL:** Used for specific manual operations, refer to your air conditioner's main manual for details.

3. Maintenance

3.1 Battery Replacement

Replace batteries when the remote control's display becomes dim or its response time slows. Always replace both AAA batteries simultaneously with new ones to ensure optimal performance.

3.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

4. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the right polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm you are within the maximum operating range (up to 10 meters).
- **Air conditioner not responding to specific functions:**
  - Verify that your air conditioner model is listed as compatible (A75C428, A75C559, A75C561, A75C598, A75C606).
  - Some advanced functions might be specific to the original remote or air conditioner model.
- **Remote display is blank or dim:**
  - Replace the batteries.

5. Specifications

Brand	azwok
Model Number	AU-PN012-PN
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Maximum Range	10 Meters
Battery Type	AAA (Alkaline recommended)
Number of Batteries Required	2
Item Weight	81 Grams
Special Feature	No programming required

6. Warranty Information

This azwok replacement remote control comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures replacement or refund if the product does not function with your compatible devices.
Returns are accepted for refund or exchange if the remote control does not work with your specified Panasonic air conditioner models.

7. Customer Support

If your air conditioner model is not listed as compatible, or if you are unsure about compatibility, please contact our customer support team for assistance. We are happy to help you find the correct remote control.
For support inquiries, please refer to the contact information provided by your retailer or on the product packaging.

© 2023 azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question