

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

CITOLEN 39"W x 72"H

CITOLEN Motorized Blinds

USER MANUAL

Model: 39"W x 72"H

Product Overview

The CITOLEN Motorized Blinds are advanced electric blackout roller shades designed for windows, offering convenience and modern aesthetics. These upgraded zebra blinds feature cordless operation and can be controlled via remote, voice, or app when integrated with a smart hub. They are battery-powered, eliminating the need for new wiring during installation.




Image: CITOLEN Motorized Blinds seamlessly integrated into a modern living space, demonstrating smart home compatibility with voice and app control.

Key Features

- **Adjustable Opacity:** Offers Light Filtering, Room Darkening, and Blackout options to control light and privacy.
- **Cordless Design:** Enhanced safety and a clean, modern window appearance.
- **Battery Powered:** Convenient installation without the need for electrical wiring.
- **Multiple Control Methods:** Remote control included, with optional voice and app control via a smart hub (sold separately).
- **Durable Material:** Made from polyester for longevity and ease of maintenance.





Image: Detailed view of the blinds highlighting their compact design and benefits such as energy efficiency, privacy protection, and child safety.

Setup and Installation

Proper measurement and installation are crucial for optimal performance of your motorized blinds. You can choose between inside mount or outside mount based on your window type and preference.

Measurement Guidelines:




Inside Mount

- **Width**= **Minimum** of the inside frame widths of the window(**W1,W2,W3**)
- **Height** = **Minimum** of the inside frame heights of the window(**H1,H2,H3**)

! Important

- Minimum 2 1/2" of window frame depth required
- You need to make a 1/4 deduction on the width; To make sure you get the best fit.
- Rounded down to the nearest 1/8"



Outside Mount

- **Width** =Width of the ideal area to be covered (**W**)
- **Height** =Height of the ideal area to be covered (**H**)

! Important

- Minimum clearance of 2" of flat surface above the window frame is required.
- We recommend adding at least 2" on each side of the window. For the maximum light blockage, add at least 4" to each side to the window frame's width and height.
- Round to the nearest 1/8"

You measure the actual width of the window, not the curtain size, and the fabric width is always 1 inch less than the shell. Contact us if you need further assistance with measuring.

Image: Visual guide for measuring windows for both inside and outside mount installations, showing critical dimensions.

• Inside Mount:

- Window frame depth should be **≥ 2 inches**.
- Order width should be **1/4 inch less** than the window width for a proper fit.
- Measure the minimum of the inside frame widths (**W1, W2, W3**) and heights (**H1, H2, H3**).
- Round down to the nearest 1/8 inch.

• Outside Mount:

- Minimum clearance of **2 inches** of flat surface above the window frame is required.
- Add at least **2 inches** on each side of the window for optimal light blockage. For maximum light blockage, add at least **4 inches** to each side.
- Order width should be at least **4 inches longer** than the window width.
- Round to the nearest 1/8 inch.

The height of the motorized blinds can be adjusted from 0 to 72 inches, regardless of the mounting type.

Battery Installation:

The motorized blinds are powered by 6 AA batteries. Ensure correct polarity when inserting the batteries into the motor device. A single battery replacement can last approximately 6 months.

Smart Battery Motor



New upgraded Integral Valance

Double-layer fabric 70% blackout

≤ 35db

- 6 AA batteries
- 6 months of use after one battery replacement

Control Methods


Voice Control



APP Control



Remote Control



Smart Control

- Voice Control
- Timing Control
- Location Control
- Sunrise & Sunset Control
- Offsite Control

AA Battery * 6

Image: Illustration of the smart battery motor, detailing the use of 6 AA batteries and various control methods available for the blinds.

Operating Instructions

Your CITOLEN Motorized Blinds offer flexible control options to suit your lifestyle.

Remote Control Operation:

Use the provided remote control to adjust the blinds. The remote allows you to raise, lower, and stop the blinds at any desired position, creating different levels of filtering, visibility, and privacy. The remote can control up to 15 blinds.

Smart Control (Voice & App - Requires Smart Hub):

To enable voice control (e.g., with Alexa or Google Home) and app control, a compatible smart hub is required (sold separately). Once connected, you can control your blinds remotely, set schedules, and integrate them into your smart home routines.



How to Make Your Remote Control Blinds to Be Smart Blinds? You Need Get A Smart Hub!

To Get a **Smart Hub** on our Product Page, Color Choose **Smart Hub** ; Size Choose **To Be Smart Blinds** .



Image: Depiction of how a smart hub facilitates app and voice control for the motorized blinds, allowing for advanced automation based on weather, humidity, location, and time.

Adjusting Opacity:

The zebra blinds feature alternating opaque and sheer fabric strips. By moving the blinds up and down, these strips stack on top of each other, allowing you to adjust the intensity of sunlight entering the room and the level of privacy.

- **Light Filtering:** Allows gentle diffusion of light, creating a warm glow.
- **Room Darkening:** Reduces light significantly, suitable for areas needing less light than full blackout.
- **Blackout:** Blocks most light, ideal for bedrooms, media rooms, or during daytime sleep.

Maintenance

To ensure the longevity and appearance of your CITOLEN Motorized Blinds, follow these simple cleaning guidelines:



Image: Visual guide demonstrating recommended cleaning methods for the blinds: using a feather duster, a damp sponge, or a damp towel.

- **Light Dusting:** Use a feather duster to remove loose dust and debris regularly.
- **Spot Cleaning:** For small marks, gently wipe with a damp sponge.
- **General Cleaning:** For more thorough cleaning, use a damp towel to wipe the fabric. Avoid harsh chemicals or abrasive cleaners.

Troubleshooting

This section provides solutions to common issues you might encounter with your motorized blinds.

- **Blinds not responding to remote:**
 - Check if the batteries in the remote control are fresh and correctly inserted.
 - Ensure the blinds' motor batteries are not depleted. Replace if necessary.
 - Verify that the remote is paired correctly with the blinds. Refer to pairing instructions (if applicable, not detailed)

in provided data).

- **Blinds moving unevenly or stopping mid-way:**

- This could indicate low battery power in the motor. Replace the AA batteries.
- Check for any obstructions in the blind's path.

- **Smart control (voice/app) not working:**

- Ensure your smart hub is properly connected to your home network and the blinds.
- Check the smart hub's app for connectivity status and error messages.
- Confirm that the blinds are correctly paired with the smart hub.

If you continue to experience issues, please refer to the Warranty and Support section for contact information.

Specifications

Attribute	Detail
Brand	CITOLEN
Model	Motorized Blinds, 39"W x 72"H (White-r72201)
Material	Polyester
Opacity Options	Light Filtering, Room Darkening, Blackout
Operation Mode	Automatic (Remote, Voice, App with Smart Hub)
Power Source	Battery Powered (6 x AA batteries)
Battery Life (Approx.)	6 months per replacement
Product Dimensions	182.9L x 99.1W Centimetres (72L x 39W inches)
Item Weight	2.27 kg
Special Features	Cordless, Self-Propelled, Smart Home Compatible (with hub)

Warranty and Support

CITOLEN provides a **2-year warranty** on these motorized shades. This warranty covers any issues related to the motor or remote control within the first two years from the date of purchase.

For warranty claims, technical support, or any questions regarding your motorized blinds, please contact CITOLEN customer service. Contact information can typically be found on the product packaging or the seller's page where the product was purchased.

Please have your purchase details and product model information ready when contacting support to expedite assistance.

Official Product Videos

No official product videos from the seller are available for embedding at this time. Please refer to the images and text descriptions for visual guidance.

© 2023 CITOLEN. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.