

[Manuals.plus](#) /

› [LEBENLANG](#) /

› LEBENLANG Ceramic Fan Heater LBE0279 User Manual

LEBENLANG LBE0279

LEBENLANG Ceramic Fan Heater LBE0279 User Manual

Model: LBE0279

1. INTRODUCTION

Thank you for choosing the LEBENLANG Ceramic Fan Heater LBE0279. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new heater. Please read it thoroughly before use and retain it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic precautions.

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This heater is equipped with a tip-over safety switch that automatically shuts off the unit if it is accidentally tipped over (from 45° inclination).
- The heater also features overheat protection, which will turn off the unit if it reaches an internal temperature above 75°C.
- The product is GS certified and conforms to European safety standards.

LA PLUS HAUTE SÉCURITÉ POUR VOTRE MAISON



Matériau
résistant au feu



Sécurité
testée



Conformité
européenne



Protection contre
le renversement
à partir d'une
inclinaison de 45°



Protection contre
la surchauffe à
partir de 75°C



Image Description: An illustration of the LEBENLANG heater's safety features, including fire-resistant materials, GS certification for tested safety, European conformity, automatic tip-over protection (from 45° inclination), and overheat protection (above 75°C).

3. PACKAGE CONTENTS

Please check the package for the following items:

- LEBENLANG Ceramic Fan Heater LBE0279
- Remote Control
- User Manual

4. PRODUCT DIAGRAM AND COMPONENTS



Image Description: The LEBENLANG LBE0279 ceramic fan heater, shown with its remote control and a smartphone displaying the control application. The heater features a black cylindrical design with a digital display on top.

Control Panel Overview

CONTRÔLE INTUITIF



Augmenter



Diminuer



Marche/arrêt



Mode



Oscillation



Minuteur



Image Description: A detailed view of the heater's intuitive control panel on top, featuring touch buttons for increasing/decreasing temperature, power on/off, mode selection, oscillation, and timer. The remote control is also visible, offering similar functionalities.

1. **Power Button:** Turns the heater On/Off.
2. **Mode Button:** Cycles through heating modes (e.g., ECO, Power).
3. **Oscillation Button:** Activates/deactivates 75-degree oscillation.
4. **Timer Button:** Sets the operating timer.
5. **Temperature Up/Down Buttons:** Adjusts the desired temperature.
6. **Digital Display:** Shows current temperature, mode, and timer settings.

5. SETUP

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clear space around the heater to allow for proper airflow and to prevent fire hazards. Do not place it near curtains, furniture, or other

obstructions.

3. **Power Connection:** Plug the power cord into a standard 230V AC electrical outlet. Ensure the outlet is in good condition and not overloaded.

6. OPERATING INSTRUCTIONS

6.1 Manual Control (Control Panel & Remote)

You can operate the heater using the touch controls on the top panel or the included remote control.

- **Power On/Off:** Press the **Power** button once to turn the heater on. Press again to turn it off.
- **Adjust Temperature:** Use the **Temperature Up (▲)** and **Temperature Down (▼)** buttons to set your desired room temperature. The digital display will show the set temperature.
- **Select Mode:** Press the **Mode** button to cycle through available heating modes (e.g., ECO, Power).
- **Activate Oscillation:** Press the **Oscillation** button to start the 75-degree oscillation function, distributing heat more widely. Press again to stop.
- **Set Timer:** Press the **Timer** button to set an auto-off timer. Each press typically increases the timer by one hour. The display will show the remaining time.



Image Description: A close-up of the heater's digital display showing '09h', indicating a 9-hour timer setting.

6.2 App Control (WiFi)

The LEBENLANG Ceramic Fan Heater can be controlled remotely via a smartphone application.

1. **Download App:** Search for and download the compatible smart home application (e.g., 'Smart Life' or 'Tuya Smart' app) from your device's app store (available for Android and iPhone).
2. **Register/Login:** Create an account or log in to the app.
3. **Add Device:** Follow the in-app instructions to add your LEBENLANG LBE0279 heater. This typically involves putting the heater into pairing mode (refer to app instructions for specific steps, often by holding a button on the heater) and connecting it to your home WiFi network.
4. **Remote Control:** Once connected, you can control all heater functions (On/Off, temperature, mode, oscillation, timer, weekly schedule) directly from your smartphone, even when away from home.

LEBENLANG SMART HOME

Profitez d'un confort optimal où que vous soyez grâce au contrôle intégré de l'application



Mise en marche/arrêt



Réglage de la température



Fonction de minuterie avec programme hebdomadaire



Image Description: A close-up of a smartphone screen showing the LEBENLANG Smart Home application interface. The app allows users to power on/off, adjust temperature, set timers, and manage weekly schedules for the heater.




Image Description: This image shows a person comfortably in bed, using a smartphone to program the heater's smart timer function with a weekly schedule through the dedicated mobile application.

7. MODES AND FEATURES

- **ECO Mode (1000W):** This energy-saving mode operates at 1000 Watts, providing efficient heating with lower power consumption. Ideal for maintaining warmth or heating smaller spaces.
- **Power Mode (2000W):** For rapid heating or larger spaces, the Power mode operates at 2000 Watts, quickly raising the room temperature.

**ÉCONOME ET EFFICACE
EN ÉNERGIE**

**ECO
MODE
1000W**



**POWER
MODE
2000W**

**DES BOISSONS CHAUDES EN
QUELQUES SECONDES**



Image Description: This image highlights the energy-saving ECO mode (1000W) and the rapid heating Power mode (2000W) of the LEBENLANG ceramic fan heater, demonstrating its versatile heating capabilities.

- **75-Degree Oscillation:** The heater can oscillate up to 75 degrees, ensuring even heat distribution across the room.

75° OSCILLATION GRAND ANGLE

Répartit la chaleur de manière efficace et économique
dans toute la pièce



Image Description: The LEBENLANG heater is shown in operation, demonstrating its 75-degree oscillation feature, which effectively distributes warm air throughout the room. A person is seen relaxing on the floor, benefiting from the evenly spread heat.

- **Digital Display:** Provides clear visual feedback on current settings and temperature.
- **Timer with Weekly Schedule:** Program the heater to turn on or off at specific times, including a customizable weekly schedule via the app, for optimal comfort and energy savings.

8. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents. Ensure no water enters the interior of the heater.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and exhaust grilles.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original

packaging to protect it from dust and damage.

9. TROUBLESHOOTING

If you encounter issues with your LEBENLANG Ceramic Fan Heater, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Tip-over switch activated. Overheat protection activated.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. Place the heater on a flat, stable surface. If it was tipped, stand it upright and restart. Unplug the heater, let it cool down for 30 minutes, then plug it back in and restart. Ensure air vents are not blocked.
No heat output.	Temperature setting too low. ECO mode selected for a large room.	Increase the desired temperature setting. Switch to Power mode (2000W) for faster heating or larger areas.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and heater.	Replace batteries with new ones, ensuring correct polarity. Remove any objects blocking the signal path. Ensure you are within range.
App connection issues.	Incorrect WiFi password. Heater not in pairing mode. Weak WiFi signal.	Double-check your WiFi password. Follow app instructions to put the heater into pairing mode. Move the heater closer to your WiFi router or ensure a strong signal.

If the problem persists after trying these solutions, please contact customer support.

10. SPECIFICATIONS

Feature	Detail
Brand	LEBENLANG
Model Number	LBE0279
Power	2000 Watts (Max)
Voltage	230 Volts (AC)
Noise Level	40 dB
Dimensions (L x W x H)	17 x 17 x 25.5 cm
Weight	1.6 Kilograms

Feature	Detail
Color	Black
Special Features	Digital Display, Wi-Fi Compatible, Energy Efficient, On/Off Timer, Remote Control, 75° Oscillation, Overheat Protection, Tip-over Protection
Compatibility	Android Phones, iPhone

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2025 LEBENLANG. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BQYY1V91>

More documents and user manuals: <https://manuals.plus/>