Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blooy KP269F

KP269F Binding Walking Foot Instruction Manual

Model: KP269F | Brand: Blooy

1. Product Overview

The Blooy KP269F Binding Walking Foot is a specialized accessory designed for specific industrial sewing machines. This foot is crucial for achieving consistent and professional binding results, especially when working with multiple layers of fabric or challenging materials. It ensures even feeding of both the top and bottom layers, preventing shifting and puckering.

This set includes both the inside and outside foot components, engineered for precise compatibility and optimal performance.



Main view of the KP269F Binding Walking Foot, showcasing its complete assembly.



The KP269F Binding Foot, indicating compatibility with Durkopp Adler 267 and 269 models.

2. Specifications

Attribute	Detail
Part Code	KP269F
Product Type	Binding Walking Foot (Inside + Outside Foot Set)
Outside Foot Width	15mm
Inner Foot Width	11.1mm
Compatibility	Durkopp Adler 69, 167, 267, 269 Compound Feed Sewing Machines
Product Dimensions	5 x 3 x 2 inches
Item Weight	1.28 ounces
Manufacturer	Blooy
Country of Origin	China
Batteries Required	No



Detailed view of the inner foot component, highlighting its 11.1 mm width.



Detailed view of the outside foot component.

3. Setup and Installation

Proper installation of the KP269F Binding Walking Foot is essential for optimal performance and to prevent damage to your sewing machine or the foot itself. Always refer to your specific Durkopp Adler sewing machine's manual for detailed instructions on changing presser feet.

Installation Steps:

1. **Power Off:** Ensure your sewing machine is turned off and unplugged from the power source before attempting any installation or removal of parts.
2. **Remove Existing Foot:** Loosen the screw that holds the current presser foot in place on your sewing machine's presser bar. Carefully remove the old foot.
3. **Attach KP269F:** Align the KP269F Binding Walking Foot with the presser bar. The U-shaped arm of the walking foot should sit over the needle clamp screw.
4. **Secure Foot:** Tighten the screw on the presser bar to firmly secure the KP269F foot in place. Ensure it is stable and does not wobble.
5. **Test Fit:** Manually lower the presser foot lever to ensure the foot sits flat on the needle plate and moves freely when the handwheel is turned.

Note: This walking foot is designed for compound feed machines. Ensure your machine model (Durkopp Adler 69, 167, 267, 269) is compatible before installation.

4. Operating Instructions

The KP269F Binding Walking Foot is specifically designed to facilitate the binding process on heavy-duty materials or multiple layers. Its unique feeding mechanism helps to move all layers of fabric evenly through the machine, preventing slippage and ensuring a smooth, consistent stitch.

Usage Tips:

- **Material Preparation:** Prepare your binding strip and main fabric layers as required for your project.
- **Placement:** Position the fabric and binding under the foot. The design of the foot helps guide the binding material.
- **Even Feeding:** Allow the walking foot to do its job. Avoid pulling or pushing the fabric excessively, as this can interfere with the foot's feeding mechanism.
- **Stitch Length:** Adjust your machine's stitch length as appropriate for the fabric thickness and desired binding

appearance.

- **Needle Selection:** Use a needle appropriate for the fabric type and thickness to prevent skipped stitches or needle breakage.



Side view of the binding walking foot, showing its robust construction.



Bottom view of the binding walking foot, illustrating the feeding mechanism.

5. Maintenance

Regular maintenance of your KP269F Binding Walking Foot will extend its lifespan and ensure continued optimal performance.

- **Cleaning:** After each use, especially when working with lint-producing fabrics, use a small brush or compressed air to remove any lint, dust, or thread fragments from the foot, particularly around the feeding mechanism.
- **Inspection:** Periodically inspect the foot for any signs of wear, bending, or damage. Ensure all components are securely attached.
- **Storage:** When not in use, store the walking foot in a clean, dry place, preferably in its original packaging or a protective case, to prevent dust accumulation and accidental damage.
- **Lubrication:** This specific foot does not require user lubrication. Refer to your sewing machine's manual for its lubrication requirements.

6. Troubleshooting

If you encounter issues while using the KP269F Binding Walking Foot, consider the following common problems and solutions:

- **Foot Not Feeding Evenly:**

- Ensure the foot is securely attached and the U-shaped arm is correctly positioned over the needle clamp screw.
- Check for any lint or debris obstructing the feeding mechanism.
- Verify that the fabric layers are properly aligned before starting to sew.

- **Skipped Stitches:**
  - Ensure you are using the correct needle size and type for your fabric.
  - Check that the needle is inserted correctly and is not bent or dull.
  - Re-thread your machine, ensuring proper tension.

- **Foot Does Not Fit Machine:**
  - Confirm your sewing machine model is one of the compatible Durkopp Adler models (69, 167, 267, 269). This foot is specifically designed for these industrial compound feed machines.
  - Ensure the presser foot screw is fully loosened before attempting to attach the foot.

If problems persist, consult your sewing machine's comprehensive manual or contact a qualified sewing machine technician.

© 2023 Blooy. All rights reserved.

For further assistance, please refer to your sewing machine's official documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQZ1B4S1

More documents and user manuals: **https://manuals.plus/**