

Severin CY 7106

SEVERIN CY 7106 Cyclonic Bagless Vacuum Cleaner

User Manual

INTRODUCTION

The SEVERIN CY 7106 bagless cyclonic vacuum cleaner combines traditional design with innovative technology for optimal floor cleaning. This lightweight and compact appliance eliminates the need for costly bags and filters, offering powerful and consistent suction thanks to its special cyclonic technology and HEPA 12 filter. It is designed for easy maintenance, with washable dust containers and filters, and provides a comfortable cleaning experience with its compact form, 9-meter operating radius, and rubberized wheels to protect floor coverings. Its integrated HEPA 12 filter makes it ideal for allergy sufferers by purifying the air of dust, pollen, and other particles.

IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage on the rating label corresponds to your mains voltage.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use and before cleaning.
- Do not use the vacuum cleaner to pick up water or other liquids, hot ashes, sharp objects, or flammable/explosive substances.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- This appliance is for household use only.

PRODUCT COMPONENTS


Familiarize yourself with the parts of your SEVERIN CY 7106 vacuum cleaner:



Main Unit: The compact body of the vacuum cleaner housing the motor and dust container.



Hose and Telescopic Tube: Flexible hose connecting to the main unit, and an adjustable telescopic tube for extended reach.



Dust Container: Transparent, bagless dust collection container with a 2-liter capacity.



HEPA 12 Filter: Integrated filter system located within the dust container, designed to capture fine particles and allergens.



Eco Premium Floor Brush: Main floor nozzle, switchable for hard floors and carpets.

Parquet Nozzle: Additional brush specifically designed for delicate hard floors.



Power Cord and Cord Rewind Button: 6-meter power cord with automatic rewind function.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Attach Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks into place.
3. **Assemble Telescopic Tube:** Connect the telescopic tube to the hose handle. Adjust the length of the telescopic tube by pressing the release button and extending or retracting it to a comfortable height.
4. **Attach Floor Nozzle:** Attach the desired floor nozzle (Eco Premium or Parquet) to the end of the telescopic tube.
5. **Check Dust Container:** Ensure the dust container is correctly installed and empty before first use.

OPERATING INSTRUCTIONS

1. **Power Connection:** Pull out the power cord to the desired length (max 6m) and plug it into a suitable electrical outlet.
2. **Power On/Off:** Press the On/Off button (usually marked with a power symbol) on the main unit to start or stop the vacuum cleaner.
3. **Adjust Suction Power:** Use the suction power regulator (if present, typically a slider or dial on the hose handle or main unit) to adjust the suction strength according to the surface being cleaned.
4. **Floor Nozzle Adjustment:** For the Eco Premium floor brush, use the foot switch to toggle between carpet mode (brush retracted) and hard floor mode (brush extended). Use the parquet nozzle for delicate floors.
5. **Cleaning:** Move the nozzle slowly and steadily over the surface to ensure thorough cleaning.
6. **After Use:** Turn off the vacuum cleaner, unplug the power cord, and press the cord rewind button to retract the cord.
7. **Storage:** Utilize the parking hook on the appliance and the accessory holder on the telescopic tube for compact storage.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying and Cleaning the Dust Container

1. **Detach Container:** Press the release button to detach the dust container from the main unit.
2. **Empty Dust:** Hold the container over a waste bin and press the bottom release button to open the flap and empty the contents.
3. **Rinse Container:** The dust container can be rinsed under running water. Ensure it is completely dry before reassembling.

Cleaning the HEPA 12 Filter

1. **Access Filter:** The HEPA 12 filter is located inside the dust container. Carefully remove it.

- 2. **Clean Filter:** Tap the filter gently to remove loose dust. The filter can also be rinsed under running water.
- 3. **Dry Thoroughly:** Allow the filter to air dry completely for at least 24 hours before placing it back into the vacuum cleaner. Do not use heat to dry.
- 4. **Reassemble:** Once dry, reinsert the filter into the dust container and reattach the container to the main unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; plug not inserted correctly; power outlet faulty.	Check power cord connection; try a different outlet; check circuit breaker.
Loss of suction power.	Dust container full; filter clogged; hose/tube/nozzle blocked.	Empty dust container; clean/wash filter; check for and remove blockages in hose, tube, or nozzle.
Unusual noise during operation.	Blockage in the hose or nozzle; foreign object in the fan.	Turn off and unplug the vacuum. Check for and remove any blockages. If noise persists, contact customer support.

SPECIFICATIONS

Brand: Severin

Model Number: CY 7106

Color: White, Silver, Red

Dimensions (L x W x H): 37 x 26 x 30 cm (14.57 x 10.24 x 11.81 inches)

Weight: 5.4 kg (11.9 lbs)

Capacity: 2 Liters (Dust Container)

Power: 850 Watts

Voltage: 230V

Sound Level: 78 dB

Special Features: Bagless, HEPA 12 Filter

Cord Length: 6 meters

Operating Radius: 9 meters

Filter Type: HEPA Filter







Surface Recommendation: All floors

WARRANTY AND SUPPORT

SEVERIN products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official SEVERIN website. If you encounter any issues or require technical assistance, please contact SEVERIN customer support. Keep your purchase receipt as proof of purchase. For further assistance, you may visit the [Severin Brand Store](#) on Amazon.



Related Documents - CY 7106

<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>BC 7047</p><table><tr><td>DE</td><td>Becken Bodenstaubsauger – Gebrauchsanleitung</td><td>2</td></tr><tr><td>GB</td><td>Bagged vacuum cleaner – Instruction manual</td><td>14</td></tr><tr><td>FR</td><td>Aspirateur sac – Mode d'emploi</td><td>26</td></tr><tr><td>IT</td><td>Aspirapolvere a sacco – Istruzioni per l'uso</td><td>38</td></tr><tr><td>ES</td><td>Aspiradora con bolsa – Manual de instrucciones</td><td>50</td></tr><tr><td>PT</td><td>Aspirador com saco – Manual de instruções</td><td>62</td></tr><tr><td>PL</td><td>Aspirator z workami – Instrukcja obsługi</td><td>74</td></tr><tr><td>RU</td><td>Система пылесоса с мешком – Инструкция по эксплуатации</td><td>86</td></tr></table></div>	DE	Becken Bodenstaubsauger – Gebrauchsanleitung	2	GB	Bagged vacuum cleaner – Instruction manual	14	FR	Aspirateur sac – Mode d'emploi	26	IT	Aspirapolvere a sacco – Istruzioni per l'uso	38	ES	Aspiradora con bolsa – Manual de instrucciones	50	PT	Aspirador com saco – Manual de instruções	62	PL	Aspirator z workami – Instrukcja obsługi	74	RU	Система пылесоса с мешком – Инструкция по эксплуатации	86	<h3>SEVERIN BC 7047 Bagged Vacuum Cleaner - User Manual</h3> <p>Comprehensive user manual for the SEVERIN BC 7047 bagged vacuum cleaner, covering operation, safety, maintenance, and troubleshooting. Discover how to effectively use and care for your SEVERIN appliance.</p>
DE	Becken Bodenstaubsauger – Gebrauchsanleitung	2																							
GB	Bagged vacuum cleaner – Instruction manual	14																							
FR	Aspirateur sac – Mode d'emploi	26																							
IT	Aspirapolvere a sacco – Istruzioni per l'uso	38																							
ES	Aspiradora con bolsa – Manual de instrucciones	50																							
PT	Aspirador com saco – Manual de instruções	62																							
PL	Aspirator z workami – Instrukcja obsługi	74																							
RU	Система пылесоса с мешком – Инструкция по эксплуатации	86																							
<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>HV 7168</p><table><tr><td>DE</td><td>2-in-1 Handstauger – Gebrauchsanleitung</td><td>2</td></tr><tr><td>GB</td><td>2-in-1 Handheld bagless vacuum cleaner – Instruction manual</td><td>14</td></tr><tr><td>FR</td><td>Aspirateur 2 en 1 – Mode d'emploi</td><td>26</td></tr><tr><td>IT</td><td>Aspiratore 2 in 1 – Istruzioni per l'uso</td><td>38</td></tr><tr><td>ES</td><td>Aspiradora 2 en 1 – Manual de instrucciones</td><td>50</td></tr><tr><td>PT</td><td>Aspirador 2 em 1 – Manual de instruções</td><td>62</td></tr><tr><td>PL</td><td>Aspirator 2 w 1 – Instrukcja obsługi</td><td>74</td></tr><tr><td>RU</td><td>2-в-1 ручная пылесос – Инструкция по эксплуатации</td><td>86</td></tr></table></div>	DE	2-in-1 Handstauger – Gebrauchsanleitung	2	GB	2-in-1 Handheld bagless vacuum cleaner – Instruction manual	14	FR	Aspirateur 2 en 1 – Mode d'emploi	26	IT	Aspiratore 2 in 1 – Istruzioni per l'uso	38	ES	Aspiradora 2 en 1 – Manual de instrucciones	50	PT	Aspirador 2 em 1 – Manual de instruções	62	PL	Aspirator 2 w 1 – Instrukcja obsługi	74	RU	2-в-1 ручная пылесос – Инструкция по эксплуатации	86	<h3>SEVERIN HV 7168 2-in-1 Akku-Staubsauger: Bedienungsanleitung & Tipps</h3> <p>Umfassende Anleitung für den SEVERIN HV 7168 Akku-Staubsauger. Erfahren Sie alles über die 2-in-1-Funktion, verschiedene Saugmodi, Sicherheit und Wartung für optimale Leistung.</p>
DE	2-in-1 Handstauger – Gebrauchsanleitung	2																							
GB	2-in-1 Handheld bagless vacuum cleaner – Instruction manual	14																							
FR	Aspirateur 2 en 1 – Mode d'emploi	26																							
IT	Aspiratore 2 in 1 – Istruzioni per l'uso	38																							
ES	Aspiradora 2 en 1 – Manual de instrucciones	50																							
PT	Aspirador 2 em 1 – Manual de instruções	62																							
PL	Aspirator 2 w 1 – Instrukcja obsługi	74																							
RU	2-в-1 ручная пылесос – Инструкция по эксплуатации	86																							
<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>HV 7166</p><table><tr><td>DE</td><td>2-in-1 Handstauger – Gebrauchsanleitung</td><td>2</td></tr><tr><td>GB</td><td>2-in-1 Handheld bagless vacuum cleaner – Instruction manual</td><td>14</td></tr><tr><td>FR</td><td>Aspirateur 2 en 1 – Mode d'emploi</td><td>26</td></tr><tr><td>IT</td><td>Aspiratore 2 in 1 – Istruzioni per l'uso</td><td>38</td></tr><tr><td>ES</td><td>Aspiradora 2 en 1 – Manual de instrucciones</td><td>50</td></tr><tr><td>PT</td><td>Aspirador 2 em 1 – Manual de instruções</td><td>62</td></tr><tr><td>PL</td><td>Aspirator 2 w 1 – Instrukcja obsługi</td><td>74</td></tr><tr><td>RU</td><td>2-в-1 ручная пылесос – Инструкция по эксплуатации</td><td>86</td></tr></table></div>	DE	2-in-1 Handstauger – Gebrauchsanleitung	2	GB	2-in-1 Handheld bagless vacuum cleaner – Instruction manual	14	FR	Aspirateur 2 en 1 – Mode d'emploi	26	IT	Aspiratore 2 in 1 – Istruzioni per l'uso	38	ES	Aspiradora 2 en 1 – Manual de instrucciones	50	PT	Aspirador 2 em 1 – Manual de instruções	62	PL	Aspirator 2 w 1 – Instrukcja obsługi	74	RU	2-в-1 ручная пылесос – Инструкция по эксплуатации	86	<h3>SEVERIN HV 7166: Anleitung für 2-in-1 Hand- und Bodenstaubsauger</h3> <p>Umfassende Gebrauchsanleitung für den SEVERIN HV 7166. Erfahren Sie mehr über die Funktionen, Sicherheitshinweise und Wartung dieses vielseitigen 2-in-1 Hand- und Bodenstaubsaugers.</p>
DE	2-in-1 Handstauger – Gebrauchsanleitung	2																							
GB	2-in-1 Handheld bagless vacuum cleaner – Instruction manual	14																							
FR	Aspirateur 2 en 1 – Mode d'emploi	26																							
IT	Aspiratore 2 in 1 – Istruzioni per l'uso	38																							
ES	Aspiradora 2 en 1 – Manual de instrucciones	50																							
PT	Aspirador 2 em 1 – Manual de instruções	62																							
PL	Aspirator 2 w 1 – Instrukcja obsługi	74																							
RU	2-в-1 ручная пылесос – Инструкция по эксплуатации	86																							
<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>WK 3472</p><table><tr><td>DE</td><td>Wasserkocher</td><td>4</td></tr><tr><td>GB</td><td>Electric kettle</td><td>16</td></tr><tr><td>FR</td><td>Bouilloire électrique</td><td>28</td></tr><tr><td>IT</td><td>Macinatore da caffè</td><td>40</td></tr><tr><td>ES</td><td>Electrolimón</td><td>52</td></tr><tr><td>PT</td><td>Electrolimón</td><td>64</td></tr><tr><td>PL</td><td>Electrolimón</td><td>76</td></tr><tr><td>RU</td><td>Electrolimón</td><td>88</td></tr></table></div>	DE	Wasserkocher	4	GB	Electric kettle	16	FR	Bouilloire électrique	28	IT	Macinatore da caffè	40	ES	Electrolimón	52	PT	Electrolimón	64	PL	Electrolimón	76	RU	Electrolimón	88	<h3>SEVERIN Wasserkocher WK 3472 - Bedienungsanleitung und Sicherheitshinweise</h3> <p>Finden Sie detaillierte Anleitungen und wichtige Sicherheitshinweise für den SEVERIN Wasserkocher WK 3472. Erfahren Sie mehr über Anschluss, Bedienung, Reinigung und Wartung.</p>
DE	Wasserkocher	4																							
GB	Electric kettle	16																							
FR	Bouilloire électrique	28																							
IT	Macinatore da caffè	40																							
ES	Electrolimón	52																							
PT	Electrolimón	64																							
PL	Electrolimón	76																							
RU	Electrolimón	88																							
<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>FKS 8841</p><table><tr><td>DE</td><td>Flaschenkühlschrank</td><td>2</td></tr><tr><td>GB</td><td>Refrigerator for bottles</td><td>14</td></tr><tr><td>FR</td><td>Refrigerateur pour bouteilles</td><td>26</td></tr><tr><td>IT</td><td>Refrigeratore per bottiglie</td><td>38</td></tr><tr><td>ES</td><td>Refrigerador para botellas</td><td>50</td></tr><tr><td>PT</td><td>Refrigerador para garrafas</td><td>62</td></tr><tr><td>PL</td><td>Refrigerator na zimno</td><td>74</td></tr><tr><td>RU</td><td>Холодильник для бутылок</td><td>86</td></tr></table></div>	DE	Flaschenkühlschrank	2	GB	Refrigerator for bottles	14	FR	Refrigerateur pour bouteilles	26	IT	Refrigeratore per bottiglie	38	ES	Refrigerador para botellas	50	PT	Refrigerador para garrafas	62	PL	Refrigerator na zimno	74	RU	Холодильник для бутылок	86	<h3>SEVERIN FKS 8841 Bedienungsanleitung und Produktdatenblatt</h3> <p>Entdecken Sie die detaillierte Bedienungsanleitung und das Produktdatenblatt für den SEVERIN FKS 8841 Flaschenkühlschrank. Erfahren Sie mehr über Installation, Bedienung, Sicherheitshinweise und technische Spezifikationen dieses hochwertigen Geräts von SEVERIN.</p>
DE	Flaschenkühlschrank	2																							
GB	Refrigerator for bottles	14																							
FR	Refrigerateur pour bouteilles	26																							
IT	Refrigeratore per bottiglie	38																							
ES	Refrigerador para botellas	50																							
PT	Refrigerador para garrafas	62																							
PL	Refrigerator na zimno	74																							
RU	Холодильник для бутылок	86																							
<div></div> <div><p>www.severin.com</p><p>SEVERIN</p><p>Friends for Life</p><p>SEPURO</p><p>HV 7184, HV 7185, HV 7186, HV 7187</p><table><tr><td>DE</td><td>Handstauger</td><td>4</td></tr><tr><td>GB</td><td>Handheld vacuum cleaner</td><td>16</td></tr><tr><td>FR</td><td>Aspirateur à main</td><td>28</td></tr><tr><td>IT</td><td>Aspiratore a mano</td><td>40</td></tr><tr><td>ES</td><td>Aspiradora a mano</td><td>52</td></tr><tr><td>PT</td><td>Aspirador a mão</td><td>64</td></tr><tr><td>PL</td><td>Aspirator ręczny</td><td>76</td></tr><tr><td>RU</td><td>Ручная пылесос</td><td>88</td></tr></table></div>	DE	Handstauger	4	GB	Handheld vacuum cleaner	16	FR	Aspirateur à main	28	IT	Aspiratore a mano	40	ES	Aspiradora a mano	52	PT	Aspirador a mão	64	PL	Aspirator ręczny	76	RU	Ручная пылесос	88	<h3>SEVERIN SEPURO Wireless Vacuum Cleaner (HV 7184-HV 7187) - Technical Overview</h3> <p>Detailed technical specifications and product overview for the SEVERIN SEPURO wireless vacuum cleaner, including models HV 7184, HV 7185, HV 7186, and HV 7187. Learn about power, weight, capacity, and components.</p>
DE	Handstauger	4																							
GB	Handheld vacuum cleaner	16																							
FR	Aspirateur à main	28																							
IT	Aspiratore a mano	40																							
ES	Aspiradora a mano	52																							
PT	Aspirador a mão	64																							
PL	Aspirator ręczny	76																							
RU	Ручная пылесос	88																							

