

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Year](#) /
- › [Year X ULTRA Smart Watch User Manual](#)

Year ULTRA Smart Watch

Year X ULTRA Smart Watch User Manual

Model: ULTRA Smart Watch

1. INTRODUCTION

Welcome to the user manual for your new Year X ULTRA Smart Watch. This device is designed to enhance your daily life with features such as NFC door access, Bluetooth calling, and comprehensive health monitoring, including a heart rate monitor. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your smart watch to ensure optimal performance and user experience.



Image 1.1: The Year X ULTRA Smart Watch displaying its main interface with time, date, battery level, and heart rate data.

2. SETUP

2.1. Charging the Device

Before initial use, fully charge your X ULTRA Smart Watch. The device supports wireless charging.

1. Place the smart watch on the wireless charging pad. Ensure the back of the watch is in full contact with the charger.
2. Connect the wireless charging pad to a power source.
3. The watch screen will indicate charging status. A full charge typically takes approximately 2 hours.

2.2. Powering On/Off

- **To Power On:** Press and hold the side button until the screen illuminates.

- **To Power Off:** Press and hold the side button, then select 'Power Off' from the options displayed on the screen.

2.3. Pairing with Your Smartphone

To access all smart features, pair your watch with a compatible smartphone via Bluetooth.

1. Download the dedicated companion application for the X ULTRA Smart Watch from your smartphone's app store. Refer to the packaging or quick start guide for the app name.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the companion app and follow the on-screen instructions to add a new device.
4. On your smart watch, navigate to the Bluetooth settings to make it discoverable.
5. Select your X ULTRA Smart Watch from the list of available devices in the app to complete the pairing process.

3. OPERATING INSTRUCTIONS

3.1. Screen Navigation

The 2.02-inch touch screen allows for intuitive interaction.

- **Swipe Up/Down:** Scroll through menus or notifications.
- **Swipe Left/Right:** Access different widgets or quick settings.
- **Tap:** Select an item or open an application.
- **Press Side Button:** Return to the home screen or access the app menu.



Image 3.1: The Year X ULTRA Smart Watch showcasing a customizable watch face with a horse design.

3.2. NFC Door Access

The X ULTRA Smart Watch supports NFC for convenient door access where compatible systems are available.

1. Ensure the NFC feature is enabled in your watch settings.
2. Follow the instructions provided by your NFC door access system administrator to register your watch.
3. To unlock, hold your watch near the NFC reader until the door unlocks.

3.3. Bluetooth Calls

Once paired with your smartphone, you can make and receive calls directly from your watch.

- **Making a Call:** Access the dialer or contacts list on your watch, select a contact, or dial a number.
- **Receiving a Call:** When a call comes in, the watch will display the caller ID. Tap the green icon to answer or the red icon to reject.

3.4. Heart Rate Monitor

The integrated heart rate monitor tracks your heart rate throughout the day.

- To view your current heart rate, navigate to the Heart Rate application on your watch.
- Ensure the watch is worn snugly on your wrist for accurate readings.
- Historical data can be viewed in the companion app on your smartphone.



Image 3.2: A detailed view of the watch face, highlighting the horse graphic and a small heart rate icon in the upper right corner.

4. MAINTENANCE

4.1. Cleaning Your Smart Watch

Regular cleaning helps maintain the watch's appearance and functionality.

- Wipe the screen and body with a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the charging contacts periodically to ensure efficient charging.

4.2. Battery Care

- Avoid exposing the watch to extreme temperatures, which can degrade battery life.
- If storing the watch for an extended period, charge it to approximately 50% to preserve battery health.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your X ULTRA Smart Watch.

- **Watch not powering on:** Ensure the watch is fully charged. If the issue persists, try performing a soft reset by holding the side button for 10-15 seconds.
- **Cannot pair with smartphone:**
 - Ensure Bluetooth is enabled on both devices.
 - Make sure the watch is discoverable.
 - Restart both the watch and the smartphone.
 - Clear previous Bluetooth connections on your phone if necessary.
- **Inaccurate heart rate readings:** Ensure the watch is worn snugly on your wrist, not too loose or too tight. Clean the sensor on the back of the watch.
- **NFC door access not working:** Verify NFC is enabled on the watch and that your watch is properly registered with the access system. Ensure the watch is held close enough to the reader.

6. SPECIFICATIONS

Feature	Detail
Model Name	ULTRA Smart Watch
Brand Name	Year
Screen Size	51 Millimeters (2.02 Inch equivalent)
Item Shape	Square
GPS	No GPS

Feature	Detail
Battery Cell Composition	Zinc
Wireless Communication Standard	Bluetooth
Connectivity Technology	Bluetooth
Special Features	Heart Rate Monitor
Operating System	Android
Product Dimensions	4.5 x 3.5 x 1.3 cm
Item Weight	210 g



Image 6.1: The Year X ULTRA Smart Watch presented with its packaging, showcasing various band color options.

7. SUPPORT

For further assistance, please refer to the manufacturer's official website or contact customer support. Contact details are typically found on the product packaging or the manufacturer's website.