DELUX KF10+MF10

DELUX PockCombo Wireless Foldable Keyboard and 2-in-1 Sliding Mouse Combo User Manual (Model KF10+MF10)

Your guide to setting up, operating, and maintaining your DELUX PockCombo.

1. Product Overview

The DELUX PockCombo is a portable wireless keyboard and mouse set designed for efficiency and convenience across multiple devices and operating systems. It includes a foldable keyboard, a 2-in-1 sliding mouse with presenter functionality, and a versatile protective case that doubles as a stand and mouse pad.



Image: The DELUX PockCombo set, showing the foldable keyboard, 2-in-1 sliding mouse, and the versatile protective case.

Your browser does not support the video tag.

Video: An overview of the DELUX Lightweight Slim Mouse and Keyboard Combo (MF10+KF10), demonstrating its compact design and functionality.

2. Setup and Connection

2.1 Unfolding the Keyboard

Gently unfold the keyboard until it lies flat. The magnetic hinges will secure it in the open position, ready for use.

2.2 Activating the Mouse

To activate the mouse, slide the top cover forward. This reveals the optical sensor and prepares the mouse for use. To switch to presenter mode, press the dedicated button on the side.



Image: The ultra-slim foldable keyboard, showing its compact folded state (13mm) and its thin unfolded state (6.6mm).

Image: The 2-in-1 sliding mouse, highlighting its compact design and dual functionality as a mouse and presenter.

2.3 Bluetooth Pairing

1. Ensure both the keyboard and mouse are charged and powered on.
2. On the keyboard, press the **Connect** button (usually near the BT1/BT2/BT3 indicators). The indicator light will flash.
3. On your device (laptop, tablet, smartphone), go to Bluetooth settings and search for "DELUX PockCombo" or similar.
4. Select the device to pair. Follow any on-screen prompts.
5. For multi-device connection, use **Fn + A/S/D** to switch between BT1, BT2, and BT3 channels. Pair each device to a different channel.



Image: Diagram illustrating the DELUX PockCombo's compatibility with multiple devices (tablet, smartphone, laptop) and operating systems (iOS, Android, Windows).

Your browser does not support the video tag.

Video: Demonstration of the DELUX PockCombo Portable Keyboard and Mouse Wireless, showcasing its ease of setup and use with various devices.

3. Operating Instructions

3.1 Keyboard Usage

The ultra-slim foldable keyboard features a standard QWERTY layout. Its scissor switches provide consistent and fast typing feedback. Use the **Fn** key in combination with other keys for special functions, such as switching between connected Bluetooth devices (Fn + A/S/D for BT1/BT2/BT3).



Image: A user typing on the DELUX PockCombo keyboard, emphasizing its silent operation and comfortable typing experience.

3.2 Mouse Usage (2-in-1 Functionality)

The sliding mouse offers two modes:

- **Mouse Mode:** Slide the top cover forward to reveal the optical sensor. Use the touch-sensitive surface for scrolling and navigation.
- **Presenter Mode:** With a single push of a button, the compact mouse transforms into a wireless presenter with a laser pointer. This allows for easy control of slides and highlighting points during presentations.



Image: Close-up of the DELUX PockCombo mouse in mouse mode, demonstrating the touch-sensitive scrolling surface.



Image: The DELUX PockCombo mouse in presenter mode, showing the activated laser pointer for presentations.

4. Versatile Protective Case

The included protective case is designed to accommodate both the keyboard and mouse, ensuring a tidy and organized workspace. It can be configured in multiple ways:

- **Tablet Stand:** Fold the case into an adjustable desk holder to prop up your tablet or smartphone at various viewing angles.
- **Mouse Pad:** The case can also be flattened to serve as a convenient mouse pad, providing a smooth surface for mouse operation.



Image: The DELUX PockCombo in use, with the protective case folded to support a tablet, and the keyboard and mouse positioned for work.

Your browser does not support the video tag.

Video: An unboxing and demonstration of the DELUX Pocket Combo Wireless Keyboard and Mouse MF10 (White), showing the protective case's functionality.

5. Charging and Battery Life

The PockCombo keyboard and mouse are rechargeable via USB Type-C. A single charge provides approximately 20 days of usage, depending on usage patterns.



Image: Illustration of the USB Type-C charging port and the extended battery life of the PockCombo combo.

6. Specifications

Feature	Detail
Brand	DELUX
Model	KF10+MF10
Color	White

Feature	Detail
Connectivity Technology	Bluetooth
Compatible Devices	Laptop, Smartphone, Tablet
Operating System Compatibility	Android, iOS, Windows
Keyboard Layout	QWERTY
Number of Keys (Keyboard)	104
Mouse Movement Detection	Optical
Mouse Hand Orientation	Ambidextrous
Power Source	Battery Powered (1 Lithium Polymer battery included)
Folded Keyboard Thickness	13 mm
Unfolded Keyboard Thickness	6.6 mm

7. Troubleshooting

7.1 Connection Issues

- **Device not connecting:** Ensure both the keyboard and mouse are fully charged and powered on. Check that Bluetooth is enabled on your host device and that the PockCombo is in pairing mode (indicator light flashing). Try re-pairing the devices.
- **Intermittent connection:** Ensure there are no obstructions between the PockCombo and your device. Move closer to your device. Other wireless devices might cause interference.

7.2 Keyboard Specific Issues

- **Keys not responding:** Check battery level. Ensure the keyboard is fully unfolded and locked into position. If using multi-device, ensure you are on the correct BT channel (Fn + A/S/D).

7.3 Mouse Specific Issues

- **Mouse not tracking:** Ensure the optical sensor is clean and unobstructed. Use on a suitable surface (the protective case can be used as a mouse pad). Check battery level.
- **Presenter mode not working:** Ensure the mouse is fully extended and the dedicated presenter button is pressed. Check battery level for laser functionality.

8. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the keyboard and slide the mouse into its compact form. Store them securely within the protective case to prevent damage.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the devices regularly, even if not used daily, to maintain battery health.

9. Warranty and Support

The DELUX PockCombo comes with a 1-year manufacturer's warranty. For warranty claims, technical support, or further assistance, please contact DELUX customer service. Refer to the contact information provided in your product packaging or visit the official DELUX website.