KAPOEFAN F3910-60-OWW

KAPOEFAN 60 Inch Wood Ceiling Fan User Manual

Model: F3910-60-OWW

1. Safety Information

Please read all instructions carefully before installation and use to ensure safe operation and to prevent injury or damage. Retain this manual for future reference.

- Ensure the power is disconnected at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- The fan must be mounted with a minimum of 7 feet (2.1 meters) clearance from the floor to the blades.
- Ensure the mounting structure can support the weight of the fan (approximately 15.4 lbs).
- Do not bend the fan blades when installing or cleaning the fan.
- This fan is suitable for both indoor and outdoor (covered patio) use.

2. Package Contents

Verify all components are present and undamaged before beginning installation.

- 1 x Reversible DC Motor
- 3 x Wooden Blades
- 1 x Receiver and Accessory Kit
- 1 x Remote Control
- Downrod (5"/10" options)
- Mounting Bracket
- Canopy
- Decorative Cover
- Small Cover



Image showing all components included in the KAPOEFAN 60 Inch Wood Ceiling Fan package, including the motor, wooden blades, remote control, downrods, and mounting hardware.

3. Setup and Installation

This section provides a general overview of the installation process. For detailed step-by-step instructions, please refer to the included instruction manual and the official installation videos.

3.1. Fan Blade Assembly

Attach the three wooden blades to the fan motor assembly using the provided screws. Ensure they are securely fastened.



Close-up view of the three natural wood blades being attached to the central motor hub, highlighting the secure screw points.

3.2. Downrod and Mounting

Select the appropriate downrod length (5" or 10") for your ceiling height. The fan can be installed on flat ceilings or tilted ceilings up to 15 degrees. Secure the mounting bracket to the ceiling joist or a suitable electrical box. Connect the fan assembly to the mounting bracket, ensuring all electrical connections are made correctly and safely.



Diagram illustrating the fan's dimensions (60-inch diameter, 12.5/17.5-inch height) and various applicable room types such as bedroom, corridor, kids room, and dining room, suitable for rooms 12-18 sq ft or larger.

3.3. Official Installation Videos

For a visual guide to the installation process, please watch the following official videos:

Your browser does not support the video tag.

Video: KAPOEFAN 60 Inch Wood Ceiling Fan Installation Video. This video provides a comprehensive guide to installing your ceiling fan, covering all necessary steps from unboxing to final setup.

Your browser does not support the video tag.

Video: How to install the solid wood ceiling fan? A detailed video tutorial demonstrating the installation process for the solid wood ceiling fan.

4. Operating Instructions

Your KAPOEFAN ceiling fan comes with a remote control for convenient operation of all its features.

4.1. Remote Control Functions

The remote control allows you to adjust fan speed, set timers, and change wind direction (reversible mode).

- **6 Wind Speeds:** Choose from 6 different fan speeds to suit your comfort needs. The fan operates quietly, with noise levels below 35dB.
- **Reversible Mode:** Change the wind direction for seasonal comfort. Downward airflow for cooling in summer, and upward airflow for circulating warm air in winter.
- **Timer Settings:** Set the fan to automatically shut off after 1, 2, 4, or 8 hours.
- **Natural Wind Pattern:** Activate a natural wind mode for varied airflow.



Illustration of the DC motor reversible function, showing downward airflow for cooling in summer and upward airflow for circulating air in winter.



Visual representation of the 6 wind speed settings, suggesting appropriate speeds for sleeping (1-2), working (3-4), and sport/active use (5-6).



Image highlighting the fan's quiet operation (Noise ext. The screws on the lid have been pre-installed on the bracket. Covered with a decorative cover to block the screws, more beautiful.