Youyu SRUDF10X2BK

Youyu 10.1 Inch Biuframe WiFi Digital Photo Frame User Manual

Model: SRUDF10X2BK

1. Introduction

The Youyu 10.1 Inch Biuframe WiFi Digital Photo Frame allows you to display your cherished photos and videos with ease. Featuring a 10.1-inch IPS touch screen with 1280x800 resolution, 32GB of internal storage, and Wi-Fi connectivity, this frame enables seamless sharing of memories from anywhere using the Biuframe app or email. This manual provides instructions for setting up, operating, and maintaining your digital photo frame.

Image 1.1: The Youyu 10.1 Inch Biuframe WiFi Digital Photo Frame.

2. Setup

2.1 Unboxing and Power Connection

1. Carefully remove the digital photo frame and all accessories from the packaging.
2. Connect the power adapter to the frame's power port and plug it into a wall outlet. The frame will automatically power on.
3. Attach the removable stand to the back of the frame for desktop display, or use the integrated hangable holes for wall mounting.

2.2 Initial Wi-Fi Setup

1. Upon first power-on, the frame will guide you through the initial setup process. Follow the on-screen prompts to select your language and time zone.

2. Connect the frame to your Wi-Fi network by selecting your network name and entering the password. Ensure a stable internet connection for optimal performance.

2.3 Biuframe App Download and Pairing

1. Download the "Biuframe" app from the Google Play Store (for Android devices) or the Apple App Store (for iOS devices).
2. Open the Biuframe app and create an account or log in.
3. Follow the in-app instructions to pair your smartphone with the digital photo frame. This typically involves scanning a QR code displayed on the frame or entering a unique frame ID.

Image 2.1: Easy setup process and cloud upload functionality.

3. Operating the Digital Photo Frame

3.1 Touch Screen Navigation

The frame features a responsive touch screen for intuitive navigation. Swipe left or right to browse photos, tap to access menus, and pinch to zoom (if supported by the software version). The 10.1-inch IPS display ensures clear and vivid image presentation from various viewing angles.

Image 3.1: Interacting with the 10.1-inch IPS touchscreen.

3.2 Sharing Photos and Videos

- **Via Biuframe App:** Open the Biuframe app on your smartphone, select the photos or videos you wish to share, and send them directly to your paired frame. You can invite friends and family to share their photos to your frame as well.
- **Via Email:** The frame has a unique email address. Send photos or videos to this address, and they will appear on your frame within seconds.
- **Video Playback:** The frame supports video clips, typically up to 15 seconds in length. These will play within the slideshow.



Image 3.2: Sending media to the frame using the Biuframe app or email.

3.3 Slideshow Mode and Settings

Once powered on, the frame will automatically begin playing photos in a slideshow. You can customize slideshow settings such as transition effects, display duration, and order (sequential or random) through the frame's settings menu.

3.4 Auto-Rotate Function

The frame features an auto-rotate function. Whether placed in portrait or landscape orientation, the frame will automatically adjust the photo display to fit the screen perfectly.

Image 3.3: The frame automatically adjusts orientation.

3.5 Memory Management

The frame comes with 32GB of built-in memory. You can expand storage by inserting a Micro SD card (up to 64GB, not included) into the designated slot. Manage stored media through the frame's settings or the Biuframe app.



Image 3.4: Information on memory capacity and expansion.

3.6 User Management and AI Features

The Biuframe app allows for user management, enabling you to control who can send photos to your frame. The frame also incorporates AI technology to intelligently match and complement similar photos for an enhanced viewing experience.

Image 3.5: Features for user management and intelligent photo organization.

3.7 Motion Sensor

The frame may include a motion sensor feature that automatically turns the screen on when motion is detected and off when the area is empty, saving energy.

Image 3.6: The frame's motion sensor functionality.

4. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the screen and frame. Avoid using abrasive cleaners or sprays directly on the screen.
- **Software Updates:** Ensure your frame's software is up to date for optimal performance and new features. The frame may prompt you for updates, or you can check for them in the settings menu.
- **Storage Management:** Periodically review your stored photos and videos. Delete unwanted media to free up space, especially if not using an external SD card.

5. Troubleshooting

- **Frame not connecting to Wi-Fi:**
  - Ensure your Wi-Fi password is correct.
  - Restart your Wi-Fi router and the digital photo frame.
  - Try connecting the frame to a different Wi-Fi network temporarily to rule out router-specific issues.
  - Ensure the frame is within range of your Wi-Fi signal.
- **Photos/Videos not appearing on the frame:**
  - Verify the frame is connected to Wi-Fi.
  - Check the Biuframe app or email for successful upload confirmation.
  - Ensure the frame's storage is not full.
  - Confirm that the sender has permission to send photos to your frame.
- **Videos not playing:**
  - Ensure the video format is supported by the frame.
  - Check the video length; the frame typically supports videos up to 15 seconds.
  - Ensure the video file is not corrupted.
- **Screen unresponsive or frozen:**
  - Perform a soft reset by unplugging the power adapter, waiting 10 seconds, and plugging it back in.
  - If the issue persists, a factory reset might be necessary (refer to settings menu), but this will erase all data on the frame.

6. Specifications

Feature	Detail
Model Number	SRUDF10X2BK
Display Size	10.1 inches
Resolution	1280 x 800
Display Type	IPS Touch Screen
Aspect Ratio	16:9
Internal Storage	32 GB
Expandable Storage	Micro SD card (max. 64GB, not included)
Connectivity	Wi-Fi
Control Method	App, Touch
Power Source	Corded Electric
Product Dimensions	27.94 x 20.32 x 2.51 cm
Item Weight	590 g
Frame Material	Plastic
Manufacturer	Youyu
Country of Origin	China

7. Warranty Information

This Youyu Digital Photo Frame comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

8. Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Youyu customer support. Refer to the contact information provided with your product packaging or visit the official Youyu website for support details.

© 2023 Youyu. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question