WAKHJAKT frg01

WAKHJAKT Interactive Cat Toy User Manual

Model: frg01

Introduction

Thank you for choosing the WAKHJAKT Interactive Cat Toy. This innovative toy is designed to provide endless entertainment and stimulation for your feline friend, promoting exercise and reducing loneliness. Featuring irregular movement, adjustable speeds, smart sound and touch activation, and a variety of interchangeable accessories, this toy will keep your cat engaged for hours.



Image: The WAKHJAKT Interactive Cat Toy, showcasing its main unit, interchangeable feather and worm attachments, and USB charging cables. A small orange kitten is visible in the background, observing the toy.

Key Features

- **Two Speed Modes:** Easily switch between high-speed for active cats and low-speed for kittens or timid cats.
- **Irregular Movement:** 360-degree unpredictable movement trajectory to keep cats engaged.
- **5-in-1 Interchangeable Heads:** Includes two feather toys, two bug strip toys with bells, and a rainbow tail toy with catnip for varied play.
- **Smart Activation:** Sound and touch control wake-up feature; the toy stops after three minutes of inactivity and reactivates with sound or touch.
- **USB Rechargeable:** Convenient USB charging with 5-7 hours of playtime on a 1-hour charge.
- **Durable Design:** Anti-collision silicone wheels reduce noise and protect surfaces.
- **LED Rainbow Lights:** Adds visual stimulation during play.

Setup Guide

1. **Unpack the Toy:** Carefully remove all components from the packaging. Ensure you have the main toy unit, five interchangeable attachments, and the USB charging cable.



Image: Contents of the WAKHJAKT Interactive Cat Toy package, including the main spherical toy, an instruction manual, a USB charging cable, and five distinct interchangeable attachments (feather, worm, and rainbow tail designs).

2. **Charge the Toy:** Before first use, fully charge the toy. Locate the Type-C charging port on the side of the toy. Connect the provided USB charging cable to the toy and a compatible USB power source (e.g., computer, wall adapter). The charging indicator light will show charging status. A full charge typically takes 1 hour.



Image: A detailed view of the WAKHJAKT cat toy's Type-C charging port, illustrating the connection of the USB charging cable for power replenishment.

3. **Attach an Accessory:** Choose one of the five interchangeable toy heads. Securely attach it to the designated hook or loop on the toy.



Image: A close-up demonstrating the process of attaching a feather accessory to the WAKHJAKT cat toy, highlighting the connection point.

Operating Instructions

1. **Power On/Off:** Press and hold the power button (usually located near the charging port) for a few seconds to turn the toy on or off. The LED lights will illuminate when powered on.



Image: A detailed view of the WAKHJAKT cat toy, highlighting the location of the power button for easy operation.

2. **Adjust Speed:** While the toy is on, short press the power button to cycle between the two speed modes:
    - **Speed 1 (Low):** Ideal for kittens, older cats, or timid cats.
    - **Speed 2 (High):** Suitable for active adult cats or puppies.




Image: A visual comparison of the two speed settings for the WAKHJAKT cat toy. Speed 1 depicts a black cat observing the toy moving slowly, while Speed 2 shows a grey kitten actively playing with the toy moving at a faster pace.

3. **Smart Wake-Up Feature:** The toy will automatically stop after approximately three minutes of inactivity. To reactivate it, your cat can touch it, or you can make a sound (e.g., clap your hands). This feature conserves battery life and keeps the toy engaging.



Image: Two scenarios demonstrating the smart activation of the WAKHJAKT cat toy: one showing a cat batting the toy to "Beat awake" and another showing a cat reacting to a "Voice awake" sound, indicating the toy's responsiveness to touch and sound.




Image: A person clapping their hands to activate the WAKHJAKT cat toy, which is shown on the floor near a sofa, illustrating the sound-activated wake-up feature.

4. **Movement and Obstacles:** The toy is designed with anti-collision silicone wheels to navigate various surfaces and reduce noise. It moves in an irregular pattern to keep play unpredictable.



Image: An orange cat engaging with the WAKHJAKT toy, which is depicted moving in an unpredictable, irregular path across a wooden floor, demonstrating its dynamic play pattern.



Image: The WAKHJAKT cat toy moving across a wooden floor, demonstrating its ability to navigate around furniture with its anti-collision silicone wheels, which also help reduce operational noise.

Maintenance

- **Cleaning:** Wipe the toy's surface with a soft, damp cloth. Do not submerge the toy in water or use harsh chemicals.
- **Accessory Care:** The interchangeable attachments can be gently cleaned with a damp cloth. Replace them if they become damaged or worn out.
- **Charging:** Always use the provided USB cable for charging. Avoid overcharging the battery.
- **Storage:** When not in use for extended periods, store the toy in a cool, dry place away from direct sunlight. Ensure it is fully charged before storing.

Troubleshooting

Problem	Possible Cause	Solution
Toy does not turn on.	Battery is low or depleted.	Charge the toy fully using the provided USB cable.
Toy stops moving frequently.	Toy is in standby mode.	Encourage your cat to touch the toy, or make a sound to reactivate it.
Toy moves too slowly or gets stuck.	Incorrect speed setting for surface; Obstruction in wheels.	Short press the power button to switch to a higher speed. Check wheels for hair or debris and clean if necessary.
Cat is not interested in the toy.	Needs variety; Cat's personality.	Try switching to a different interchangeable accessory. Some cats may take time to adjust or prefer different types of toys.

Product Specifications

- **Model:** frg01
- **Dimensions (LxWxH):** 2.87 x 2.36 x 4.17 inches
- **Weight:** 2.57 ounces
- **Material:** Acrylonitrile Butadiene Styrene, Silicone, Thermoplastic Polyurethane
- **Battery:** 1 Lithium Polymer battery (included)
- **Charging:** USB Type-C
- **Playtime:** 5-7 hours (after 1 hour charge)
- **Manufacturer:** WAKHJAKT

Warranty Information

The WAKHJAKT Interactive Cat Toy comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or support needs regarding your WAKHJAKT Interactive Cat Toy, please contact our customer service team. We are committed to providing satisfactory solutions.
Contact Information: Refer to the contact details provided on the product packaging or the official WAKHJAKT website.

© 2023 WAKHJAKT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question