

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Alxum](#) /

› [Alxum 8-in-1 Game Card Reader Instruction Manual for Nintendo Switch/Switch OLED](#)

## Alxum Switch Game Card Reader

# Alxum 8-in-1 Game Card Reader Instruction Manual

Model: Switch Game Card Reader

## INTRODUCTION

This manual provides detailed instructions for the Alxum 8-in-1 Game Card Reader, designed for use with Nintendo Switch and Switch OLED consoles. This device allows for quick switching between four game cards and provides storage for an additional four, enhancing your gaming experience by reducing the need for frequent card changes.



Image: The Alxum 8-in-1 Game Card Reader, showing its integration with the Nintendo Switch dock and its standalone form.

## PACKAGE CONTENTS

- 1 x Alxum Switch Game Card Reader
- 1 x USB A to USB C Cable

## SETUP INSTRUCTIONS

Follow these steps to properly install your Alxum Game Card Reader with your Nintendo Switch or Switch OLED console dock.

1. **Snap the Switcher into the Dock:** Carefully align and snap the Alxum Game Card Reader onto the top of your Nintendo Switch docking station.
2. **Connect the USB-C Cable:** Connect one end of the provided USB-C cable to the Alxum Game Card Reader and the other end to an available USB-C port on your Switch Dock.

- 3. Insert the Connecting Plug:** Locate the small connecting plug on the Alxum Game Card Reader. Insert this plug into the game card slot on your Nintendo Switch console.
- 4. Insert Game Cards:** Insert your desired game cards into the designated "GAME 1" through "GAME 4" reading slots on the Alxum Game Card Reader. Additional "STORAGE" slots are available for holding spare game cards.



Image: Visual guide demonstrating the four installation steps for the Alxum Game Card Reader.

The device features 3 anti-slip and anti-scratch clips on the bottom to ensure a firm attachment to the Switch dock without blocking ventilation.

## OPERATING INSTRUCTIONS

### Switching Games

The Alxum Game Card Reader allows for quick switching between up to four inserted game cards.

- To switch between games, press the LED switch button located on the device.

- The LED indicator lights will change color (red, orange, pink, yellow) to indicate which game card is currently active (Game 1-4).
- This feature eliminates the need to physically remove and insert game cards, protecting both the cards and the console's card slot from wear.



Image: The Alxum Game Card Reader's LED indicators for active games.

## Game Card Storage

In addition to the four active game card slots, the device includes four dedicated storage slots. These slots are designed to hold spare game cards, helping to keep your gaming area organized.

# 4 For Reading, 4 For Storage



Online Switch  
Game Easily

Store More  
Game Cards

Image: Overview of the Aixum Game Card Reader's 4 game reading slots and 4 storage slots.

## MAINTENANCE

To ensure the longevity and optimal performance of your Aixum Game Card Reader, follow these general maintenance guidelines:

- Keep the device clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer to customer support for assistance.
- Ensure game cards are inserted gently and correctly into the slots to prevent damage to the card or the reader.

## TROUBLESHOOTING

### Device Not Recognized / Game Not Switching

- Ensure all cables are securely connected.
- Verify that game cards are fully inserted into the reading slots (GAME 1-4).
- Try restarting your Nintendo Switch console.

## Console Wakes Up from Sleep Mode

If the Nintendo Switch console wakes up from sleep mode unexpectedly when the Alxum Game Card Reader is connected and drawing power from the Switch, it is recommended to remove the power supply connection to the Game Card Reader separately when the console is in sleep mode. This prevents unintended activation of the console.

## SPECIFICATIONS

Feature	Detail
Model	Switch Game Card Reader
Compatibility	Nintendo Switch, Nintendo Switch OLED
Game Card Slots	4 (for active games)
Storage Slots	4 (for spare game cards)
Product Dimensions	6.5 x 1.4 x 1.5 inches
Item Weight	7.4 ounces
Manufacturer	Alxum

## WARRANTY AND SUPPORT

Alxum provides a welcome guide and 24/7 friendly customer service. For any product-related inquiries, technical support, or warranty information, please contact Alxum customer service.

You can typically find contact information by visiting the Alxum store page on Amazon or by referring to the documentation included with your product.



© 2025 Alxum. All rights reserved.

## Related Documents - Switch Game Card Reader

<small>BY960 Alxum 说明书 1.28G双频 蓝牙双模 八国语言 小册子 (71页) 产品尺寸57*135mm</small>	<a href="#">Alxum BY960 Wireless CarPlay/Android Auto Adapter User Manual</a> User manual for the Alxum BY960 2-in-1 wireless adapter, providing setup, installation, troubleshooting, and FAQ for seamless Apple CarPlay and Android Auto connectivity in vehicles.
---	---

 <p>UNITEK Multi-port Switch Game Card Reader User Manual</p> <p>Thank you for choosing Unitek Multi-port Switch Game Card Reader. Please read this manual carefully before use of this device. If you need any help, please contact our product support. Unitek is a registered trademark of Unitek America Corporation.</p> <p>Product Diagram</p> 	<p><a href="#">Unitek D1100A Multi-port Switch Game Card Reader User Manual</a></p> <p>Official user manual for the Unitek D1100A Multi-port Switch Game Card Reader. Learn how to connect, use, and troubleshoot this 8-in-1 game card switcher accessory for Nintendo Switch and Switch OLED.</p>
	<p><a href="#">SuntoRSI SD Card Reader Instruction Manual for iPhone and iPad</a></p> <p>Comprehensive instruction manual for the SuntoRSI SD Card Reader, detailing specifications, compatibility, and step-by-step guides for transferring photos and videos between SD cards and iOS devices (iPhone/iPad).</p>
	<p><a href="#">GBFlash Quick Start Guide: Game Boy &amp; GBA Cartridge Backup and Programming</a></p> <p>Comprehensive guide to using the GBFlash device and FLASHGBX software for backing up and writing ROMs and save data for Game Boy and Game Boy Advance cartridges. Includes setup, software installation, and function descriptions.</p>
 <p>JOYROOM User Manual</p>	<p><a href="#">JOYROOM 4-in-1 Card Reader User Manual   Connect &amp; Transfer Files with iOS Devices</a></p> <p>Comprehensive user manual for the JOYROOM S-H142 4-in-1 Card Reader. Learn how to transfer photos, videos, and documents between SD/TF cards, USB drives, and your iOS devices (iPhone/iPad). Includes setup, operation, and troubleshooting.</p>
	<p><a href="#">AXAGON CRE-SM2 USB Smart Card Reader - Quick Guide</a></p> <p>Quick guide for the AXAGON CRE-SM2 USB Smart Card, ID Card, SD, microSD, and SIM Card Reader. Features include Plug and Play, USB 2.0, and broad OS support. Learn about supported card types and specifications.</p>

## Documents - Alxum – Switch Game Card Reader

Alxum

SKU: AX-D100-B

Multi-port Switch Game Card Reader with Wireless Remote Control

USER MANUAL

Alxum Electronics Avesonic USB

Product Schematic Diagram



LED Light Indicator  
A: 1 Game Card Slot Red

B: 2 Game Card Slot: Orange  
C: 3 Game Card Slot: Pink  
D: 4 Game Card Slot: Yellow  
E: Wireless Remote Control

#### Installation

- Step 1: Snap the Switch Game Card Switcher into the Switch Dock.
- Step 2: Connect the USB C cable to the Switch Dock.
- Step 3: Insert the connecting plug into the game card slot on Switch Console.
- Step 4: Insert the game cards you need into the card slots accordingly.

1

#### Tips

1. When multiple game cards are inserted into the switch game card reader, all games will show on the display or TV screen but it can read ONE game at one time.
2. When playing the game, please do NOT insert a new game card. Or else it will exit the current game and switch to the new game card automatically.
3. You can switch the different game by using the "switch" button or the attached wireless remote control. Press 3 time the game will be next.
4. Kindly be noted, the wireless remote control is including a CR2025 Li-ion battery. Alxum CANNOT replace it, please buy to replace from the online or offline store.

#### Note

If the wireless remote control cannot work for the game card reader, Please follow the steps:  
1. Long press the switch button of the game card switch;  
2. At the same time, plug the USB-C Power Cable, press and hold the switch button for 4s, at this time the LED lights up yellow.  
3. Press and hold the switch button of the remote control for about 2s for pairing when the LED of the card reader lights up green it means the pairing is successful.

2

#### Why does the Switch wake up in sleep mode?

The issue occurs exclusively in Switch Docks that use a USB HUB expansion chip set. The solution is to use an additional USB charger instead of plugging the USB cable into the Switch dock's USB port.

#### Package Content

- 1 x Alxum Switch Game Card Reader
- 1 x USB A to C Power Cable
- 1 x Wireless Remote Control

3

#### Customer Service

-  2-Year Warranty
-  Life Time Technical Support
-  24x7 Customer Service Support
-  support@alxum.com




Alxum

8 Ports Switch Game Card Reader

USER MANUAL

#### Product Schematic Diagram



##### LED Light Indicator

- A: Game 1: Red
- B: Game 2: Orange
- C: Game 3: Deep Pink
- D: Game 4: Yellow
- E: Game 5: Green
- F: Game 6: Blue/Violet
- G: Game 7: Blue
- H: Game 8: Cyan
- I: Switch Remote Control

1

#### Installation

- Step 1: Snap the Switch Game Card Switcher into the Switch Dock.
- Step 2: Connect the USB-C cable to the Switch Dock.
- Step 3: Insert the connecting plug into the game card slot on the Switch Console.
- Step 4: Insert the game cards you need into the card slots accordingly.

#### Tips

1. When multiple game cards are inserted into the switch game card reader, all games will show on the display or TV screen but it can read ONLY one game at one time.
2. When playing the game, please do NOT insert another game card. Or else it will switch the current game and switch to the new game card automatically.
3. You can switch the different games by using the "switch" button or the attached wireless remote control. Press 1 time the game will be next.
4. Kindly note, that the wireless remote control includes a CR2025 3.0V battery. Alxum CANNOT replace it, please buy to replace from the online or offline store.

#### Note

If the wireless remote control cannot work for the game card reader, Please follow these Steps:

1. Long press the switch button of the game card switcher;

2

2. At the same time, plug the USB-C Power Cable, press and hold the switch button for 4s, at this time the LED lights up yellow.
3. Press and hold the switch button of the remote controller for about 2s for pairing when the LED of the card reader lights up green it means the pairing is successful.

#### Why does the Switch wake up in sleep mode?

The issue occurs exclusively in Switch Docks that use a USB HUB expansion chip set. The solution is to use an additional USB charger instead of plugging the USB cable into the Switch dock's USB port.

#### Package Content

- 1 x Alxum Switch Game Card Reader
- 1 x USB A to C Power Cable
- 1 x Switch Remote C onto I

3

#### Customer Service

- 2-Year Warranty
- Life Time Technical Support
- 24x7 Customer Service Support
- support@alxum.com



### [pdf] User Manual Diagram

D1100A User Manual Switch Game Card Reader 8 In 1 Holder for Nintendo OLED Console Multi Switcher Quick Identification 4 For Storage Video Games A1nHPFddYrL m media amazon images I ||| SKUAX-D100A Multi-port **Switch Game Card Reader** USER MANUAL Alxum Electronics Awesome Life Product Schematic Diagram D C B A LED Light Indicator A: 1 Game Card Slot: Red B: 2 Game Card Slot: Orange C3 Game Card Slot: Pink D: 4 Game Card Slot: Yellow Installation Step 1: Snap the Switch Game Ca... lang:en score:39 filesize: 1.31 M page\_count: 1 document date: 2024-01-29



### [pdf]

D1100C v1m media amazon images I C1wAz8yN5 L ref dp product quick view ||| 8 Ports Switch Game kaartlezer **GEBRUIKERSHANDLEIDING** Alxum Electronics Awesome Life Productoverzi ... 4: Steek de gewenste gamekaarten in de kaartsleuven. Tips 1. Wanneer er meerdere spelkaarten in de **Switch Game Card Reader** worden gestoken, worden alle spellen weergegeven op het scherm of de tv, maar kan er maar één spel tegelijk worden gelezen. 2. Plaats tijdens het spelen **GEEN** nieuwe spelkaarten. Anders wordt het huidige spel afgestoten en wordt automatisch overgeschakeld op de nieuwe spelkaart. 3. Je kunt de verschillende spellen wisselen met de knop "Switch" of met de aangesloten draadloze afstandsbediening. 4. Geloof er rekening mee te houden dat de draadloze afstandsbediening een CR2032 li-ion batterij bevat, Alxum KAN deze NIET vervangen, koop om te vervangen van de online of offline winkel.

lang:nl score:21 filesize: 6.46 M page\_count: 1 document date: 2024-01-29

### OPMERKING

Als de draadloze afstandsbediening niet werkt voor de spelkaartlezer, volg dan deze stappen:

opstarten, volg dan deze stappen:

1. Druk lang op de schakelknop van de game card switcher;
2. Sluit tegelijkertijd de USB-C-stroomkabel aan en houd de schakeltoets 4s ingedrukt, op dat moment brandt de LED geel.
3. Houd de schakeltoets van de afstandsbediening ongeveer 2s ingedrukt voor het koppelen, wanneer de LED van de kaartlezer groen oplicht, betekent dit dat het koppelen is geslaagd.

#### Waarom wordt de Switch wakker in de slaapstand?

Dit probleem doet zich uitsluitend voor bij Switch Docks die gebruikmaken van een USB HUB-uitbreidingschipset. De oplossing is om een extra USB-oplader te gebruiken om de Game Card Switcher van stroom te voorzien in plaats van de USB-kabel in de USB-poort van het Switch-dock te steken.

#### Inhoud verpakking

1 x Switch Game kaartlezer  
1 x USB A naar C stroomkabel  
1 x Switch afstandsbediening

3

#### Customer Service

-  2-Year Warranty
-  Life Time Technical Support
-  24H-Customer Service Support
-  support@alkum.com



#### [\[pdf\]](#) User Manual Catalog

ALXUM G1002B A13UpHjqBKL ref dp product quick view m media amazon images I |||  
Switch TV Dock with Game Card Reader USER MANUAL Alxum Electronics  
Awesome Life Catalogue Englis ... Insert the game card and Start your game 2 Tips  
When multiple game cards are inserted into the **switch game card reader**, all games  
will show on the display or TV screen but it can read ONLY one ga...  
lang:en score:17 filesize: 1.33 M page\_count: 61 document date: 2024-10-20