Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tramontina 80143/034DS

Tramontina Primaware 15-Piece Nonstick Cookware Set Instruction Manual

Model: 80143/034DS | Brand: Tramontina

Introduction

This manual provides essential information for the proper use and care of your Tramontina Primaware 15-Piece Nonstick Cookware Set. Designed for both new and experienced cooks, this set offers a variety of pieces for diverse culinary tasks. Adhering to these instructions will help ensure the longevity and optimal performance of your cookware.



The complete Tramontina Primaware 15-Piece Nonstick Cookware Set, featuring various pots, pans, and utensils.

Included Components:

- 8-inch Fry Pan
- 11-inch Square Griddle
- 9-inch Open Deep Saute Pan
- 1-Quart Covered Sauce Pan
- 2-Quart Covered Sauce Pan
- 4-Quart Covered Dutch Oven
- 6 Nylon Utensils

Setup and First Use

Unpacking and Initial Cleaning:

1. Carefully remove all cookware pieces and accessories from the packaging.
2. Wash each piece thoroughly with warm, soapy water using a soft sponge or cloth.
3. Rinse completely and dry immediately to prevent water spots.

Conditioning the Nonstick Surface (Recommended):

1. Before first use, apply a small amount of cooking oil to the nonstick interior of each pan.
2. Heat the pan over low heat for 30 seconds.
3. Remove from heat and wipe away excess oil with a paper towel. This helps to optimize the nonstick performance.

Operating Instructions

General Cooking Guidelines:


- **Heat Settings:** Use low to medium heat for most cooking tasks. High heat can damage the nonstick coating and cause food to burn. The aluminum construction provides efficient and even heat distribution.
- **Compatible Cooktops:** This cookware set is designed for use on gas, electric, and ceramic glass cooktops. It is not compatible with induction cooktops.
- **Utensil Use:** Always use nylon, silicone, or wooden utensils to protect the nonstick surface. Metal utensils can scratch and damage the coating. The included nylon utensils are suitable for use with this cookware.
- **Oil/Butter:** While the nonstick surface allows for cooking with minimal oil, a small amount is recommended for flavor and to enhance browning.
- **Lids:** The glass lids allow for monitoring food without lifting, helping to retain moisture and heat.



This cookware is compatible with gas, electric, and ceramic glass cooktops.

Safety Precautions:

- **Handle Care:** The ergonomically designed handles are intended to stay cool during stovetop cooking. However, always use oven mitts or pot holders when handling hot cookware, especially if cooking for extended periods or if handles become hot.
- **Oven Use:** This cookware set is **not oven safe**. Do not place any pieces in an oven.
- **Children:** Keep children away from the cooking area to prevent accidents.
- **Empty Pans:** Do not heat empty pans for prolonged periods, as this can damage the nonstick coating and the pan itself.



Ergonomically designed handles provide a comfortable grip and are designed to stay cool during stovetop use.

Care and Maintenance

Cleaning:

- **Dishwasher Safe:** This cookware set is dishwasher safe for convenient cleanup.
- **Hand Washing:** For best results and to prolong the life of the nonstick coating, hand washing with warm, soapy water and a soft sponge is recommended.
- **Stubborn Food:** If food residue is difficult to remove, soak the pan in warm, soapy water for a short period before cleaning. Avoid using abrasive cleaners, steel wool, or scouring pads, as these can damage the nonstick surface.



The cookware set is dishwasher safe for easy cleaning.

Nonstick Coating Care:

- The cookware features Tramontina's proprietary Starflon MAX nonstick system for effortless food release.
- Avoid extreme temperature changes, such as plunging a hot pan into cold water, as this can warp the pan and degrade the nonstick coating over time.
- Do not use cooking sprays that contain propellants, as these can build up and leave a sticky residue that is difficult to remove and can affect nonstick performance.



The Starflon MAX nonstick interior ensures easy food release and cleaning.

Storage:

- When stacking cookware, place a soft cloth or paper towel between pieces to protect the nonstick surface from scratches.

Troubleshooting

This section addresses common issues you might encounter with your nonstick cookware.

Problem	Possible Cause	Solution
Food sticking to the pan.	High heat, insufficient oil, or damaged nonstick coating.	Ensure you are using low to medium heat. Add a small amount of cooking oil. Avoid metal utensils. If coating is severely damaged, replacement may be necessary.
Handles becoming hot during cooking.	Prolonged cooking at higher temperatures or flame extending up the sides of the pan.	Use oven mitts or pot holders. Adjust heat so flame does not extend beyond the base of the pan.
Pan warping or deforming.	Extreme temperature changes (e.g., hot pan into cold water).	Allow pans to cool completely before washing. Avoid sudden temperature shifts.
Discoloration on the exterior.	Exposure to high heat or certain foods.	This is typically cosmetic and does not affect performance. Ensure proper heat settings.

Specifications

Feature	Detail
Model Number	80143/034DS
Material	Aluminum
Color	Storm
Number of Pieces	15
Handle Material	Stainless Steel (riveted for durability)
Lid Material	Glass
Nonstick System	Starflon MAX
PFOA Free	Yes
Dishwasher Safe	Yes
Oven Safe	No
Compatible Cooktops	Gas, Electric, Ceramic Glass
Induction Compatible	No
Item Weight	11.22 pounds
Product Dimensions	18.62 x 7.24 x 12.52 inches
UPC	016017164529

Warranty Information

Tramontina products are manufactured to high-quality standards. For specific warranty details regarding your Primaware 15-Piece Nonstick Cookware Set, please refer to the warranty card included with your purchase or visit the official Tramontina website. Warranty coverage typically addresses manufacturing defects under normal household use.

Customer Support

Should you have any questions, require assistance, or need to report an issue with your Tramontina Primaware Cookware Set, please contact Tramontina customer service. You can find contact information on the official Tramontina website or through the retailer where the product was purchased.
For more information, visit the Tramontina Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRC39BKY

More documents and user manuals: **https://manuals.plus/**