

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TOR-OLE](#) /

› [TOR-OLE TG-365 Portable Bluetooth Speaker User Manual](#)

## TOR-OLE TG-365

# TOR-OLE TG-365 Portable Bluetooth Speaker User Manual

Model: TG-365

## INTRODUCTION

Thank you for choosing the TOR-OLE TG-365 Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.


## PRODUCT OVERVIEW

The TG-365 is a compact, durable, and versatile portable Bluetooth speaker designed for both indoor and outdoor use. It features advanced Bluetooth technology for stable connections and delivers powerful, clear audio.



This image displays the TOR-OLE TG-365 Portable Bluetooth Speaker from the front, showcasing its compact cylindrical design and the accessible control panel. The speaker features a durable mesh grille and a convenient carrying strap.

## Package Contents



The package includes the TG-365 Wireless Speaker, a packing box, and an audio line. This image shows the speaker's dimensions (6.7 inches tall, 2.6 inches wide) and the included accessories, highlighting the compact design and essential components.

- TG-365 Wireless Speaker
- Packing Box
- Audio Line (1x)

## Controls and Indicators



This image details the control panel of the TG-365 speaker. From left to right, the buttons are: Power Switch, Volume Down (-), Volume Up (+), and Mode Switch. The LED indicator light is also visible, which flashes for different modes.

Control	Function
<b>Power Switch</b> ( )	Turns the speaker on or off.
<b>Volume Down</b> (-)	Short press for previous song, long press to decrease volume.
<b>Volume Up</b> (+)	Short press for next song, long press to increase volume.
<b>Mode Switch</b> (M)	Press twice to switch modes (e.g., Bluetooth, AUX). Short press for LED flashing.

## SETUP

## Charging the Speaker

Before first use, fully charge the speaker. Connect the provided audio line to the charging port on the speaker and the other end to a compatible USB power source. The LED indicator will show charging status.

## Bluetooth Pairing



The TG-365 speaker is fully compatible with a wide range of devices, including Windows, Apple (iOS/macOS), and Android smartphones, tablets, and laptops. This image illustrates the broad compatibility, ensuring easy connection with most modern smart devices.

1. Ensure the speaker is charged and powered on.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light.
3. On your smart device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "TG-365" in the list of available Bluetooth devices.
5. Select "TG-365" to connect. A successful connection will be indicated by a solid LED light and an audible prompt.
6. The speaker supports automatic reconnection to the last paired device.

The advanced Bluetooth technology allows for a hassle-free connection up to 100 feet (approximately 30 meters) from the wireless speaker, providing excellent range and stability.

## OPERATING INSTRUCTIONS

### Playing Music

Once connected via Bluetooth or AUX, you can play audio from your device.

- **Volume Control:** Use the '+' and '-' buttons on the speaker, or your connected device, to adjust the volume.
- **Track Navigation:** Short press the '-' button for the previous song, and short press the '+' button for the next song.
- **Mode Switching:** Double-press the 'M' (Mode Switch) button to cycle through available input modes (e.g., Bluetooth, AUX).
- **LED Flashing:** Short press the 'M' button to control the LED flashing feature.

### Sound Modes (Indoor/Outdoor) and Usage Scenarios

The TG-365 offers optimized sound profiles for different environments and is suitable for various activities:



The TG-365 is ideal for outdoor activities such as picnics, camping, and gatherings, providing robust sound in open environments.



Its compact size and balanced sound make it perfect for indoor use, such as in a home, office, or retail environment.

- **Indoor Mode:** Provides full bass and balanced sound, ideal for enclosed spaces.
- **Outdoor Mode:** Delivers louder sound and extended usage time, suitable for open-air environments.

To switch between modes, refer to the device's specific instructions or the mode button functionality. The outdoor Bluetooth speaker is perfect for family gatherings, pool parties, beach parties, barbecues, cycling, hiking, camping, and more.

### Video Mode

For an enhanced indoor video experience, you can enable a dedicated video mode with ultra-low latency. Consult the speaker's interface or accompanying app (if applicable) for activation.

### True Wireless Stereo (TWS) Functionality



This graphic highlights the True Wireless Stereo (TWS) capability of the TG-365 speaker, indicating that two speakers can be paired together for a more immersive stereo sound experience. It also emphasizes the high-quality audio output.

The TG-365 supports True Wireless Stereo (TWS), allowing you to pair two TG-365 speakers together for a more immersive left and right channel stereo sound experience. Refer to the speaker's specific TWS pairing instructions for detailed steps.

## MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your TG-365 speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX6 water-resistant, meaning it can withstand splashes and rain. Do not submerge the speaker in water. Ensure charging port covers are securely closed when exposed to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Durability:** The speaker is designed to be shock-resistant and durable, but avoid excessive drops or impacts to prevent damage.

## TROUBLESHOOTING

If you encounter issues with your TG-365 speaker, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move device closer to speaker (within 100 ft).
No sound or low volume.	Volume too low on speaker or device; incorrect input mode.	Increase volume on both speaker and connected device. Press 'M' button to switch to correct input mode.
Sound distortion.	Volume too high; weak Bluetooth signal.	Decrease volume. Move device closer to speaker.

## SPECIFICATIONS

Feature	Detail
Model Name	TG-365
Brand	TOR-OLE
Product Dimensions	7.49 x 19 x 6.99 cm (approx. 2.95 x 7.48 x 2.75 inches)
Connectivity Technology	Bluetooth
Speaker Type	Portable Speaker
Audio Output Mode	Stereo
Maximum Speaker Output Power	5 Watts
Special Features	Wireless, Bluetooth, Portable, Water Resistant (IPX6)
Recommended Uses	Smartphones, Tablets, Computers, Outdoor Activities
Compatible Devices	Smartphone, Laptop, Tablet
Mounting Type	Tabletop
Manufacturer	shenzhenshiliangchengdianziyouxiangongsi
First Available Date	January 3, 2023

## SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the device or injury to yourself:

- Do not expose the speaker to extreme temperatures or direct flame.
- Do not disassemble, repair, or modify the device yourself. Contact qualified service personnel for assistance.
- Keep the speaker away from strong magnetic fields.
- Use only the specified charging cable and power source.
- Keep out of reach of children.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TOR-OLE website.