

[Manuals.plus](#) /

› [Yawpet](#) /

› Yawpet Electric Dog Training Collar B0BRCNR4LR User Manual

Yawpet B0BRCNR4LR

Yawpet Electric Dog Training Collar User Manual

Model: B0BRCNR4LR

INTRODUCTION

Thank you for choosing the Yawpet Electric Dog Training Collar. This manual provides essential information for the safe and effective use of your new training system. Please read it thoroughly before operation to ensure proper setup, usage, and maintenance. This device is designed to assist in training your dog with various modes, promoting better behavior through consistent and humane methods.

PACKAGE CONTENTS

- Remote Transmitter
- Receiver Collar
- Adjustable Nylon Strap
- USB Charging Cable
- Test Light Tool
- Long and Short Contact Points
- User Manual

PRODUCT OVERVIEW

The Yawpet Electric Dog Training Collar system consists of a remote transmitter and a receiver collar. It offers multiple training modes and features designed for effective communication with your dog.



Image: The Yawpet Electric Dog Training Collar system, showing the remote transmitter and the receiver collar with its adjustable strap.

Key Features:

- **4 Training Modes:** Beep (standard), Vibration (1-3 levels), Static Shock (1-99 levels), and Shock Boost (10% higher).
- **Adjustable Collar:** Fits dogs with neck sizes from 8 to 25 inches and weights from 8-110 lbs.
- **IPX7 Waterproof:** The receiver collar is fully waterproof, allowing use in wet conditions.
- **4-Channel Remote:** Capable of training up to four dogs simultaneously.
- **Security Keypad Lock:** Prevents accidental activation of commands.
- **Extended Range:** Up to 2680 feet (approximately 817 meters) remote control range.
- **Long Battery Life:** Fast-charging with extended standby times (35 days for collar, 45 days for remote).

2680FT Large Range

Easy training in the outdoor



Security Lock

Prevent any accident injuries



Image: Illustration of the 2680FT remote control range for outdoor training and the security lock feature on the remote to prevent accidental presses.

4 TRAINING MODES

UPGRADED VERSION



Beep
Mode



1-3level

Vibrate
Mode



0-99level

Safe
Shock



10% higher

Shock
Boost

Image: Visual representation of the four training modes: Beep, Vibrate (1-3 levels), Safe Shock (0-99 levels), and Shock Boost (10% higher static shock).



Image: Depiction of the IPX7 waterproof rating, showing dogs wearing the collar while bathing, swimming, and in the rain, indicating its suitability for various wet environments.

SETUP

1. Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. Connect the USB charging cable to the charging ports on both devices and a standard USB power adapter. Charging typically takes 2-3 hours. The indicator light will change when fully charged.

2. Pairing the Remote and Receiver

1. Turn on the remote transmitter.
2. Press and hold the power button on the receiver collar until the indicator light flashes rapidly.
3. Within 10 seconds, press any training mode button on the remote (e.g., Beep or Vibration).
4. If pairing is successful, the receiver collar will beep, and its indicator light will stop flashing and remain solid.

5. To pair additional collars (up to 4), select a different channel on the remote and repeat the process.

3. Fitting the Receiver Collar

- Ensure the contact points are appropriate for your dog's coat length. Use longer points for thicker coats.
- Place the receiver collar around your dog's neck so that the contact points touch the skin.
- The collar should be snug enough for the contact points to make reliable contact, but not so tight as to cause discomfort. You should be able to fit one finger snugly between the strap and your dog's neck.
- Avoid leaving the collar on for more than 12 hours per day to prevent skin irritation.

OPERATING INSTRUCTIONS

Remote Transmitter Functions:

- **Power Button:** Turns the remote on/off.
- **Channel Button:** Switches between dog channels (1-4).
- **Security Lock:** Slide the lock switch to prevent accidental button presses.
- **Beep Button:** Delivers an audible tone to the receiver collar.
- **Vibration Button:** Delivers a vibration stimulus. Adjust intensity levels (1-3) using the +/- buttons.
- **Static Shock Button:** Delivers a static shock stimulus. Adjust intensity levels (1-99) using the +/- buttons.
- **Shock Boost Button:** Delivers a static shock 10% higher than the currently set level.

Training Modes:

This system offers four distinct training modes to suit various training needs:

- **Beep Mode:** A gentle audible cue, often used for positive reinforcement or as a warning before other stimuli.
- **Vibration Mode:** A non-harmful tactile stimulus, useful for getting your dog's attention or as a mild correction. Levels 1-3 allow for intensity adjustment.
- **Static Shock Mode:** A corrective stimulus with adjustable intensity from 1 to 99. Start at the lowest effective level and increase only if necessary. This mode should be used responsibly and as a last resort.
- **Shock Boost Mode:** Provides a slightly stronger static shock (10% higher than the current setting) for situations requiring a more immediate response.

Always begin training with the lowest effective stimulation level and observe your dog's reaction. The goal is to communicate, not to punish.

MAINTENANCE

- **Cleaning:** Regularly clean the receiver collar and contact points with a damp cloth. Ensure the contact points are free of dirt or debris to maintain proper function.
- **Battery Care:** Recharge the devices when the battery indicator is low. Avoid fully depleting the battery frequently to prolong its lifespan. Store in a cool, dry place when not in use for extended periods.
- **Collar Strap:** Inspect the nylon strap for wear and tear. Replace if damaged to ensure secure fit.
- **Skin Health:** Regularly check your dog's neck for any signs of irritation or sores from the contact points. If irritation occurs, discontinue use and consult a veterinarian.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Collar not responding to remote	Low battery; Not paired; Out of range; Security lock engaged	Charge devices; Re-pair collar; Move closer to dog; Disengage security lock
No static shock/vibration	Contact points not touching skin; Intensity too low; Faulty contact points	Adjust collar fit; Increase intensity; Check/replace contact points; Use test light
Remote display is blank	Low battery; Remote is off	Charge remote; Turn on remote
Dog shows signs of irritation	Collar too tight; Worn for too long; Allergic reaction	Loosen collar; Limit wear time to 12 hours; Consult vet if irritation persists

SPECIFICATIONS

Feature	Detail
Brand	Yawpet
Model Number (ASIN)	B0BRCNR4LR
UPC	727198734547
Training Modes	Beep, Vibration (1-3 levels), Static Shock (1-99 levels), Shock Boost
Remote Range	Up to 2680 feet (approx. 817 meters)
Waterproof Rating	IPX7 (Receiver Collar)
Collar Fit	Neck sizes 8-25 inches, dogs 8-110 lbs
Battery Life (Standby)	Receiver: Up to 35 days; Remote: Up to 45 days
Charging Time	2-3 hours
Manufacturer	Shenzhen Kensonic Intelligent Technology Co.,Ltd.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit the official Yawpet website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question