



[Manuals.plus](#) /

› [FRTONYI](#) /

› FRTONYI Electric Salt and Pepper Grinder Set (Model KYMQ-15A) Instruction Manual

## FRTONYI KYMQ-15A

# FRTONYI Electric Salt and Pepper Grinder Set (Model KYMQ-15A) Instruction Manual

Model: KYMQ-15A

This manual provides essential information for the safe and effective use of your FRTONYI Electric Salt and Pepper Grinder Set.

## 1. INTRODUCTION

---

Thank you for choosing the FRTONYI Electric Salt and Pepper Grinder Set. This set is designed to provide a convenient and efficient way to grind your favorite spices, enhancing the flavor of your meals. Featuring automatic operation, adjustable coarseness, and a rechargeable design, these grinders are a practical addition to any kitchen.



Image 1: The FRTONYI Electric Salt and Pepper Grinder Set, showcasing its sleek design and the types of spices it grinds.

## 2. PRODUCT OVERVIEW AND FEATURES

- **Type-C Fast Charging:** Fully charges in approximately 1 hour. A 5-minute charge provides sufficient power for daily use. Supports operation while charging.
- **One-Handed Automatic Operation:** Grind spices effortlessly with a single button press. Designed for precision and ease of use.
- **5 Adjustable Coarseness Levels:** A bottom knob allows adjustment from fine to coarse grinding. Turn clockwise for fine, counterclockwise for coarse. Features a durable 304 stainless steel shaft.
- **70ml Transparent Spice Chamber:** Made from food-grade ABS material, the large capacity reduces refill frequency. The transparent body allows easy monitoring of spice type and quantity. Includes a dustproof lid.
- **Built-in LED Light:** Automatically illuminates during grinding for precise seasoning, even in low light conditions.
- **Dual Color Set:** Comes in a 2-pack (black and white) to easily distinguish between different spices like salt and pepper.

# Rapid USB-C Charging

A money-saving and effort-saving solution for daily seasoning.



Rechargeable



6 AAA Batteries



Image 2: Demonstrates the Type-C fast charging capability and the LED light feature during use.

## Automatic Grinder

ONE-HAND Operation  
Press Button to Start/Stop

## Manual Grinder

TWO-HAND Operation  
Twist Hard and Repeatedly



Image 3: Illustrates the convenience of one-handed automatic operation compared to traditional manual grinding.

### 3. SETUP

1. **Unpack:** Carefully remove the grinders and accessories from the packaging.
2. **Charge:** Before first use, fully charge both grinders using the provided Type-C USB cable. The charging port is located at the top of each grinder. A small indicator light will show charging status.
3. **Open Spice Chamber:** Locate the transparent window on the side of the grinder. Twist the small latch on the window to the 'unlock' position. Gently lift the plastic cover to reveal the spice chamber.
4. **Fill with Spices:** Fill the 70ml transparent chamber with your desired whole spices (e.g., whole peppercorns, coarse salt, rosemary, cumin, chili flakes). Do not overfill.
5. **Close Spice Chamber:** Replace the plastic cover and twist the latch back to the 'lock' position to secure the chamber.
6. **Adjust Coarseness:** Turn the knob located at the bottom of the grinder. Rotate clockwise for a finer grind and counterclockwise for a coarser grind.



Image 4: Visual guide for easy refilling and cleaning of the spice chamber.

#### 4. OPERATING INSTRUCTIONS

---

1. **Power On:** Ensure the grinder is charged and filled with spices.
2. **Grind:** Hold the grinder over your food or dish. Press and hold the button located on the top of the grinder. The grinder will automatically activate, and the LED light at the bottom will illuminate, dispensing freshly ground spices.
3. **Stop Grinding:** Release the button to stop the grinding process.
4. **Adjust Coarseness (if needed):** If you wish to change the grind size, turn the knob at the bottom of the grinder as described in the Setup section.

# 5-Level Coarseness

Grind spices freely from coarse to fine grains.



Image 5: Demonstrates the adjustable coarseness settings for various spice preferences.

Video 1: Official product video demonstrating the electric salt and pepper grinder set in use, including refilling and grinding.

## 5. MAINTENANCE

- **Cleaning the Spice Chamber:** To clean the transparent spice chamber, unlock and remove the plastic cover. Use a small brush (often included) to remove any residual spice particles. Wipe the interior with a dry cloth.
- **Exterior Cleaning:** Wipe the exterior of the grinder with a soft, damp cloth. Do not immerse the grinder in water or use abrasive cleaners.
- **Storage:** Store the grinders in a dry place. The dustproof lid helps keep spices fresh and prevents spills.
- **Dishwasher Safety:** The grinders are **not** dishwasher safe.

## 6. TROUBLESHOOTING

If you encounter any issues with your FRTONYI Electric Salt and Pepper Grinder Set, please consider the following:

- **Grinder not operating:** Ensure the grinder is fully charged. Check that the spice chamber is correctly closed and locked.
- **Inconsistent grind:** Verify that the coarseness adjustment knob is set to your desired level. Ensure the spice chamber is not overfilled.
- **No spices dispensing:** Check if the spice chamber is empty and requires refilling. Ensure no blockages are present in the grinding mechanism.

## 7. SPECIFICATIONS

---

Feature	Detail
<b>Model Number</b>	KYMQ-15A
<b>Material</b>	Stainless Steel, ABS Plastic
<b>Color</b>	Rechargeable-Black/Black 2PC (as per current product variant)
<b>Item Weight</b>	0.54 Kilograms (1.19 pounds)
<b>Operation Mode</b>	Automatic
<b>Capacity</b>	70 Milliliters
<b>Batteries</b>	1 Lithium Ion battery required (included)
<b>Dishwasher Safe</b>	No
<b>UPC</b>	785034541995

## 8. WARRANTY AND SUPPORT

---

For warranty information or product support, please contact FRTONYI customer service through the retailer where the product was purchased or visit the official FRTONYI store online.

Official FRTONYI Store: [FRTONYI Store](#)