

[Manuals.plus](#) /

› [Inandon](#) /

› Inandon Karaoke Machine 8T with 15.6 Inch Touch Screen User Manual

Inandon 8T

Inandon Karaoke Machine 8T with 15.6 Inch Touch Screen User Manual

Model: 8T

1. INTRODUCTION

Thank you for choosing the Inandon Karaoke Machine 8T. This all-in-one karaoke system features a 15.6-inch touch screen, advanced sound processing, and extensive song library access. This manual provides essential information for setting up, operating, and maintaining your device to ensure an optimal user experience.



Image 1.1: The Inandon Karaoke Machine 8T, showcasing the main unit with its 15.6-inch touch screen, two wireless microphones, and a smartphone demonstrating the mobile app control interface.

2. WHAT'S IN THE BOX

Please check the contents of your package. If any items are missing or damaged, contact customer support.

- Inandon Karaoke Machine (15.6-inch touch screen unit)
- Wireless Microphones (2 units)
- 8TB Hard Disk Drive (HDD) - pre-installed
- HDMI HD Cable
- RCA Audio Cable
- RCA to AUX Cable
- Power Adapter
- Built-in WiFi Adapter (USB dongle)
- Microphone Covers (2 units)
- User Manual (this document)

8TB HDD
170,000 Songs

15.6 Touch Screen White



HDMI HD Cable



RCA Audio Cable



RCA to AUX Cable



Power Adapter



Built-in WIFI



Microphone Cover

Image 2.1: An overview of the Inandon Karaoke Machine 8T package contents, including the main unit, two microphones, HDMI cable, RCA audio cable, RCA to AUX cable, power adapter, built-in WiFi adapter, and microphone covers.

3. SETUP GUIDE

Follow these steps to set up your Inandon Karaoke Machine.

3.1. Placement

Place the karaoke machine on a stable, flat surface. Ensure adequate ventilation around the unit.

3.2. Connecting to Power

1. Connect the power adapter to the DC IN port on the back of the karaoke machine.
2. Plug the power adapter into a standard electrical outlet.

3.3. Connecting to a Display (TV/Monitor)

Use the HDMI cable to connect the machine to your TV or monitor for video output.

1. Connect one end of the HDMI cable to the HDMI OUT port on the karaoke machine.
2. Connect the other end to an available HDMI input on your TV or monitor.
3. Select the corresponding HDMI input on your TV/monitor.

3.4. Connecting to an Audio System (Optional)

For enhanced sound, connect the karaoke machine to an external amplifier or sound system.


- **RCA Audio Output:** Use the RCA Audio Cable to connect the L/R audio output ports on the machine to the audio input ports on your amplifier.
- **Digital Optical Output:** Use an optical cable (not included) to connect the Digital Optical Output port to a compatible audio receiver.

3.5. Network Connection

The machine supports both wired Ethernet and wireless Wi-Fi connections for accessing online features and song downloads.

- **Wi-Fi:** The machine has a built-in WiFi adapter. On first boot, navigate to the system settings to connect to your wireless network.
- **Ethernet:** Connect an Ethernet cable (not included) from your router to the NETWORK port on the back of the machine.

The 8-Core Chip Runs Smoothly



Rich interface to easily handle a variety of usage scenarios




Image 3.1: The rear panel of the Inandon Karaoke Machine 8T, illustrating the various connectivity options including HDMI output, digital optical output, USB interface, RCA audio output, network port, and power switch.

3.6. Microphone Setup

The included wireless microphones are pre-paired with the system.

1. Insert batteries (not included) into each microphone.
2. Turn on the microphones using their power switches.
3. The machine will automatically detect and connect to the microphones.

4. OPERATING INSTRUCTIONS

4.1. Powering On/Off

Press the POWER button on the back of the machine to turn it on. To power off, press and hold the POWER button until the system shuts down, or use the software shutdown option from the touch screen interface.

4.2. Touch Screen Interface

The 15.6-inch touch screen provides the primary interface for navigating the system, selecting songs, and adjusting settings. The interface is intuitive and designed for ease of use.

4.3. Song Selection Methods

The Inandon Karaoke Machine offers four convenient ways to select songs:

- **Touch Screen:** Directly browse and select songs using the integrated touch display.
- **Mobile App:** Download the dedicated Inandon app on your smartphone to control the machine remotely.
- **WeChat Scan Code:** Use WeChat to scan a QR code displayed on the screen for song ordering.
- **Intelligent Voice Assistant:** Use voice commands to search for and select songs.

FOUR DIFFERENT WAYS TO ORDER SONGS



By Wechat
Scan Code



By Mobile
App



By Intelligent
Voice Assistant



By Touch
Screen




Image 4.1: Visual representation of the four song ordering methods: WeChat scan code, mobile app, intelligent voice assistant, and direct

touch screen interaction.

4.4. Adjusting Audio Settings

The machine features a DSP digital reverb microphone system, allowing for detailed audio adjustments.

1. Access the 'Sound' or 'Settings' menu on the touch screen.
2. Adjust microphone volume, music volume, and various sound effects (e.g., reverb, echo).
3. Customize the equalizer settings for music and microphone to suit your preferences.
4. The system also allows for adjusting the key (high/low) of songs and switching between original and backing vocals.

DSP DIGITAL REVERB MICROPHONE

Multiple Sound Effect Modes, Free Sound Effect Settings




Image 4.2: The user interface for adjusting DSP digital reverb microphone settings, including music tone, microphone volume, and various sound effects and equalizer options.

4.5. Cloud Song Library and Downloads

The Inandon Karaoke Machine provides access to a vast cloud-based song library.

- Connect the machine to the internet via Wi-Fi or Ethernet.

- Browse the cloud library for new songs.
- Songs can be downloaded to the internal 8TB HDD for offline playback. The library is updated weekly.
- The system supports multiple languages for song selection and interface.

500,000 Songs Downloaded for Free On The Cloud



革命歌曲



经典怀旧



情歌对唱



劲爆DJ



热门综艺



Chinese Song: 256,000

Cantonese: 25,600

Hokkien: 15,200

English: 29,600

Japanese: 20,320

Korean: 22,000

Vietnamese: 20,200

Thai Song: 40,000

Malaysian Song: 36,480

Image 4.3: The cloud song download interface, displaying the availability of over 500,000 songs across various languages including Chinese, Cantonese, English, Japanese, and Korean.

4.6. Multi-Language Support

The system supports 16 national languages for the user interface, ensuring accessibility for a diverse user base.

MULTI-LANGUAGE FREE SWITCHING

Built-In 16 Languages to Meet Your Multiple Needs



Image 4.4: The multi-language selection screen, showing options for 16 different languages to customize the user interface.

4.7. Additional Features

- **Real-time Scoring:** Get instant feedback on your singing performance.
- **Dual Android System:** Allows for installation of various apps, including YouTube for online viewing, office applications, and games.
- **Background Customization:** Change the visual background during karaoke sessions.

PANORAMIC HOME ENTERTAINMENT MODE



Image 4.5: The panoramic home entertainment mode, displaying various applications such as YouTube, music apps, live online TV, and options for casting games to a TV.

5. MAINTENANCE

5.1. Cleaning

- Ensure the device is powered off and unplugged before cleaning.
- Use a soft, dry cloth to wipe the exterior of the machine and touch screen.
- For stubborn marks on the screen, use a screen-specific cleaning solution applied to a cloth, not directly to the screen.
- Do not use abrasive cleaners or solvents.

5.2. Software Updates

Periodically check for software updates through the system settings to ensure optimal performance and access to the latest features and song library updates.

6. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty.	Check power cable connection; try a different outlet.
No display on TV	HDMI cable loose; incorrect TV input selected.	Ensure HDMI cable is securely connected; select correct HDMI input on TV.
No sound output	Audio cables loose; volume too low; external audio system off.	Check RCA/optical cable connections; increase volume on machine and external system; ensure external system is on.
Microphones not working	Microphones off; low batteries; out of range.	Turn on microphones; replace batteries; ensure microphones are within range of the machine.
Cannot connect to internet	Incorrect Wi-Fi password; router issue; Ethernet cable loose.	Verify Wi-Fi password; restart router; check Ethernet cable connection.
System slow or unresponsive	Too many apps running; temporary software glitch.	Close unnecessary applications; restart the machine.

7. SPECIFICATIONS

Feature	Detail
Model	8T
Display	15.6 Inch Touch Screen
Storage	8TB HDD (approx. 170,000 songs capacity)
Song Library	500,000+ cloud songs (free download, weekly updates)
Operating System	Dual Android System
Processor	8-Core Chip
Memory	8GB
Connectivity	Wi-Fi, Ethernet
Input/Output Ports	HDMI, USB, RCA Audio, 3.5mm Jack, Digital Optical Output, MIC Input
Control Methods	Touch Screen, Mobile App, WeChat, Voice Assistant
Special Features	DSP Digital Reverb Microphone, Real-time Scoring, Multi-language Support (16 languages)

Feature	Detail
Item Weight	11 pounds
Product Dimensions	9.5 x 9.6 x 6.6 inches
Power Source	Battery Powered (for microphones), AC Adapter (for main unit)
Compatible Devices	Smartphone

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact Inandon customer service directly. Keep your purchase receipt as proof of purchase.

© 2023 Inandon. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BRD4BQ79>

More documents and user manuals: <https://manuals.plus/>