

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [StyleCraft](#) /

› [Stylecraft Instinct Professional IN2 Vector Motor Cordless Hair Clipper User Manual SC607M](#)

StyleCraft SC607M

Stylecraft Instinct Professional IN2 Vector Motor Cordless Hair Clipper

MODEL: SC607M

Introduction

This manual provides detailed instructions for the safe and effective use of your Stylecraft Instinct Professional IN2 Vector Motor Cordless Hair Clipper. The Instinct clipper features a patented IN2 Vector motor with Intuitive Torque Control, designed for precision cutting, seamless fades, and flawless blending.



The Stylecraft Instinct clipper, showcasing its ergonomic design and charging base.

Key Features

- **IN2 Vector Motor with Intuitive Torque Control:** Delivers consistent power and speed, automatically adjusting torque for optimal cutting performance.
- **Black Diamond DLC Taper Blade:** Fixed blade with a Black Diamond Carbon DLC shallow tooth 2.0 cutter for superior blending, fading, and bulk removal.
- **Customizable Click or Freestyle Levers:** Offers 5 detent positions for precise taper control.
- **Lithium-Ion Battery:** Provides up to 2 hours of cordless run-time on a single charge.
- **USB-C Rechargeable:** Convenient charging capability.
- **3 Modular Lids:** Interchangeable lids for customization.
- **Ergonomic Design:** Lightweight and balanced for comfortable handling during extended use.

S | C

INSTINCT

PROFESSIONAL VECTOR MOTOR CLIPPER



An annotated diagram highlighting key features: Black Diamond Faper Blade, High-Power IN2 Vector Motor, Customizable Click or Freestyle Levers, 3 Modular Lids, Up to 2 Hours of Run-Time, and USB-C Rechargeable port.

IN VECTOR MOTOR - POWER & PERFORMANCE

Unmatched power for maximum performance with **11,500** strokes per minute and a noticeably **louder**, more robust sound. Designed for professionals who demand precision and strength, this high-torque motor outperforms regular motors, delivering the ultimate cutting experience. **Feel the power, hear the difference, and elevate your craft with IN Vector.**

INTUITIVE TORQUE CONTROL

A visual representation detailing the IN Vector Motor's capabilities, including 11,500 strokes per minute and intuitive torque control.

What's in the Box

Your Stylecraft Instinct Professional IN2 Vector Motor Cordless Hair Clipper package includes the following items:

- Stylecraft Instinct Clipper
- Charging Stand
- 3 Modular Lids (Black, Blue, Red)
- 8 Double Magnetic Guards
- Cleaning Brush
- Blade Oil
- Mini Screwdriver
- USB-C Charging Cable and Adapter



A comprehensive view of all items included in the package: the clipper, charging stand, 3 modular lids, various guards, cleaning brush, oil, and screwdriver.

Setup

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 2 hours. Connect the USB-C charging cable to the clipper or the charging stand, then plug the adapter into a power outlet. The indicator light will show charging status.
2. **Blade Alignment (Zero-Gap):** The clipper blades are factory-set. If adjustment is desired for a closer cut (zero-gap), use the included mini screwdriver to carefully loosen the two screws on the fixed blade. Align the moving blade with the fixed blade, ensuring the top edge of the moving blade is slightly below the top edge of the fixed blade. Tighten the screws securely.
3. **Attaching Modular Lids:** To customize the clipper's appearance, select one of the three modular lids. Align the lid with the clipper body and gently press until it clicks into place.
4. **Attaching Guards:** Select the desired magnetic guard size. Align the guard with the clipper blade and attach it securely. Ensure the guard is firmly in place before operation.



The Stylecraft Instinct clipper displayed with its three modular lids (black, blue, red), offering customization options.



A detailed view of the clipper's Black Diamond Faper Blade and the adjustable taper lever mechanism.

Operating Instructions

1. **Power On/Off:** Press the power button located on the front of the clipper to turn it on or off.
2. **Using the Taper Lever:** The taper lever allows for precise length adjustments. Move the lever up for a shorter cut and down for a longer cut. The clipper offers both click-lever and freestyle operation.
3. **Cutting Technique:** For optimal results, always use the clipper on clean, dry hair. Guide the clipper against the direction of hair growth, using smooth, even strokes.
4. **Blending and Fading:** Utilize the adjustable taper lever and various guard sizes to achieve desired blending and fading effects.

**CUSTOMIZABLE CLICK or FREESTYLE
LEVER TAPER CONTROL** with 5 detent
positions for consistent fades and blending.



An illustration of the clipper's customizable lever, offering 5 detent positions for precise fading and blending.



LITHIUM-ION BATTERY
delivers up to 2 hours
of cordless run-time
based on intuitive
torque control use

3 MODULAR LIDS.

The Stylecraft Instinct clipper in use, highlighting its 2-hour lithium-ion battery run-time and the inclusion of 3 modular lids for personalization.

Maintenance

- Cleaning Blades:** After each use, turn off the clipper and remove any attached guards. Use the included cleaning brush to remove loose hair from the blades. For a more thorough cleaning, the blades can be carefully removed (refer to blade alignment instructions in Setup) and rinsed under running water, ensuring the clipper body remains dry. Allow blades to air dry completely before reattaching.
- Oiling Blades:** Regularly apply 2-3 drops of the included blade oil across the teeth of the blades after cleaning and before storage. Turn the clipper on for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and prevents rust.
- Storage:** Store the clipper in a cool, dry place, away from direct sunlight and moisture. Ensure the clipper is turned off before storing.



The Black Diamond Faper Blade and its corresponding shallow tooth 2.0 cutter, designed for precision cutting.

Troubleshooting

Problem	Possible Cause	Solution
Clipper not turning on	Low battery; Power button not fully pressed	Charge the clipper; Ensure power button is fully engaged
Reduced cutting performance	Dull blades; Hair buildup; Insufficient oiling	Clean and oil blades; Consider blade replacement if dull
Clipper pulling hair	Dull blades; Improper technique; Hair buildup	Clean and oil blades; Use proper cutting angle; Ensure hair is clean and dry
Excessive vibration or noise	Loose blade screws; Debris in motor area	Tighten blade screws; Clean any visible debris (do not disassemble motor)

Specifications

- **Model Number:** SC607M
- **Motor Type:** IN2 Vector Motor with Intuitive Torque Control
- **Blade Type:** Black Diamond DLC Taper Blade with Shallow Tooth 2.0 Cutter
- **Run-Time:** Up to 2 hours (Lithium-Ion Battery)
- **Charging:** USB-C
- **Product Dimensions:** 11.75 x 3 x 7.25 inches
- **Weight:** 2.29 Pounds
- **UPC:** 810069131641

Warranty and Support

For warranty information, product support, or service inquiries, please contact StyleCraft customer service directly. Refer to the product packaging or the official StyleCraft website for the most current contact details.

Manufacturer: STYLECRAFT