Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BN59-01055A

ZdalaMit BN59-01055A Replacement Remote Control User Manual

For Samsung TVs

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit BN59-01055A replacement remote control. This remote is designed to function as a direct replacement for various Samsung TV models, offering seamless operation without the need for complex programming. Please read this manual carefully to ensure proper use and longevity of your remote control.



Image 1: ZdalaMit BN59-01055A Replacement Remote Control, angled view. This image displays the remote control from an elevated, angled perspective, showcasing its full button layout and sleek design.

2. Compatible TV Models

The ZdalaMit BN59-01055A remote control is compatible with the following Samsung TV models:

- UN55C8000, UN46C8000, UN55C7000, UN65C8000
- UN55C8000XF, UN46C8000XF, UN65C8000XF
- UN40C7000, UN46C7000, UN46C7100, UN55C7100
- UN55C7100WF, UN46C7100WF, UN55C7000WF, UN40C7000WF, UN46C7000WF
- UN46C7100WFXZA, UN55C7100WFXZA, UN55C8000XFXZA, UN46C8000XFXZA, UN65C8000XFXZA
- UN55C7000WFXZA, UN40C7000WFXZA, UN46C7000WFXZA

- PN50C8000YF, PN58C8000YF, PN63C8000YF
- PN50C8000, PN58C8000, PN63C8000

3. Setup

3.1 Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Important: No programming is required. Once batteries are installed, the remote is ready for immediate use with compatible Samsung TVs.

4. Operating Instructions

4.1 Basic Functions

This remote control provides all standard functions for your compatible Samsung TV. Simply point the remote towards your television and press the desired button.





Image 2: ZdalaMit BN59-01055A Replacement Remote Control, top-down view. This image provides a clear, direct overhead view of the remote control, highlighting the layout and labels of all buttons for easy identification.

Key buttons and their functions include:

- **POWER ON/OFF:** Turns the TV on or off.
- **SOURCE:** Selects input sources (HDMI, AV, etc.).
- **Number Buttons (0-9):** Direct channel selection.
- **VOL +/-:** Adjusts volume up or down.
- **CH +/-:** Changes channels up or down.
- **MUTE:** Mutes or unmutes TV audio.
- **MENU:** Accesses the TV's main menu.
- **TOOLS:** Opens quick settings or context menu.
- **INFO:** Displays current channel or program information.
- **Directional Pad (Up, Down, Left, Right) & ENTER:** Navigates menus and confirms selections.
- **RETURN:** Goes back to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **Colored Buttons (A, B, C, D):** Functionality varies by TV model and application.

- **MEDIA.P, YAHOO!, 3D:** Dedicated buttons for specific features or apps (functionality depends on TV model support).
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind):** Controls media playback.

5. Maintenance

5.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

5.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

6. Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

- **Remote not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Verify that the remote control is pointed directly at the TV.
- **Some buttons not working:**
  - This could indicate low battery power. Try replacing the batteries.
  - Ensure the remote is clean and there is no debris lodged under the buttons.
- **TV not responding to specific functions:**
  - Confirm that your TV model is listed in the compatibility section.
  - Some advanced functions or smart TV features may require the original smart remote or specific TV settings.

7. Specifications

Feature	Detail
Model Number	BN59-01055A
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries
Dimensions	Approximately 5 x 1.5 x 0.5 inches
Item Weight	Approximately 2 ounces (without batteries)
Color	Black

Compatible Devices	Samsung Televisions (specific models listed above)

8. Warranty and Support

For any queries, technical assistance, or support regarding your ZdalaMit BN59-01055A replacement remote control, please contact the manufacturer or your retailer. Refer to your purchase documentation for specific warranty information and contact details.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRKJ52N2

More documents and user manuals: **https://manuals.plus/**