

[Manuals.plus](#) /

› [Satisfyer](#) /

› Satisfyer Pro 2 Generation 3 Clitoral Stimulator User Manual

Satisfyer Pro 2 Generation 3 (051895SF)

Satisfyer Pro 2 Generation 3 Clitoral Stimulator User Manual

Model: Pro 2 Generation 3 (051895SF)

1. INTRODUCTION

Thank you for choosing the Satisfyer Pro 2 Generation 3. This device is designed for clitoral stimulation, combining innovative Liquid Air Technology with traditional pressure wave stimulation. Please read this manual carefully before first use to ensure safe and optimal operation.

Pro 2

Generation 3

Tecnología
Liquid Air

NUEVO
TAPA

- + Tecnología Liquid Air
- + Vibración
- + Silicona completa



Image 1.1: Satisfyer Pro 2 Generation 3 overview, highlighting Liquid Air Technology and Air Pulse.

2. PRODUCT FEATURES

- **Dual Stimulation Technology:** The Pro 2 Gen 3 offers two interchangeable attachments: one for pressure wave technology and another for Liquid Air. This allows you to choose between classic stimulation and a gentle, pulsating caress.
- **Body-Safe Silicone:** The attachments are made from high-quality, body-safe silicone. Their ergonomic design ensures a comfortable and realistic sensation during use.
- **Waterproof Design (IPX7):** The device is fully waterproof (IPX7 rated), making it suitable for use in the shower or bath for enhanced relaxation and pleasure.
- **Rechargeable Battery:** Equipped with a rechargeable battery, the device can be quickly charged using a standard USB-C cable, minimizing downtime.
- **Quiet Operation:** An ultra-quiet motor ensures discreet and pleasant use, allowing you to focus entirely on your experience without distracting noises.

- **No App Connectivity:** This specific model does NOT feature Bluetooth or app connectivity. It operates independently without requiring a smartphone app.

CARACTERISTICAS DEL PRODUCTO



Image 2.1: Product features diagram, showing Liquid Air accessories and other components.



Image 2.2: The device with its two interchangeable stimulation caps.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your Satisfyer Pro 2 Generation 3. The device comes with a USB-C charging cable.

1. Connect the magnetic end of the USB-C charging cable to the charging contacts on the device.
2. Plug the USB-C end of the cable into a standard USB power adapter (not included) or a computer's USB port.
3. The device's indicator light will show charging status (refer to device for specific light patterns).
4. Allow the device to charge completely before its first use. Charging time may vary.



Image 3.1: USB-C charging cable.

3.2 Attaching the Head

The device comes with two interchangeable heads. To attach a head, simply align it with the device's opening and gently push until it is securely in place. Ensure it is firmly attached before use.

4. OPERATING INSTRUCTIONS

The Satisfyer Pro 2 Generation 3 features intuitive controls for easy operation.




Image 4.1: Control buttons and their functions.

1. **Power On/Off:** Press and hold the power button () for 3 seconds to turn the device on or off.
2. **Air Pulse Intensity Control:** Once the device is on, use the- button to decrease the air pulse intensity and the+ button to increase it.
3. **Vibration Control:** Press the wave button () to cycle through 12 different vibration intensities and programs.

5. MAINTENANCE AND CARE

Proper care ensures the longevity and hygiene of your Satisfyer Pro 2 Generation 3.

- **Cleaning:** Always clean the device thoroughly before and after each use. Use warm water and a mild, toy-friendly soap or a specialized toy cleaner.
- **Drying:** Pat the device dry with a lint-free cloth. Allow it to air dry completely before storing.

- **Storage:** Store the device in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.
- **Lubricants:** Only use water-based lubricants with this device. Oil-based or silicone-based lubricants can damage the silicone material.




Image 5.1: Device showing waterproof feature.

6. TROUBLESHOOTING

If you encounter any issues with your Satisfyer Pro 2 Generation 3, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB-C cable.
Device turns off unexpectedly.	Low battery or internal issue.	Ensure the device is fully charged. If the problem persists after charging, contact customer support.
Weak or no stimulation.	Incorrect attachment, low intensity setting, or air pulse opening blocked.	Ensure the attachment is correctly seated. Increase intensity using the '+' button. Check that the air pulse opening is clear of debris or skin.
Charging indicator light not working.	Cable not connected properly or faulty cable/charger.	Ensure the magnetic charging cable is securely connected to both the device and the power source. Try a different USB power adapter.

If these solutions do not resolve the issue, please contact Satisfyer customer support for further assistance.

7. SPECIFICATIONS

- **Model Number:** 051895SF
- **Dimensions:** 4.6 x 6.5 x 16.4 cm
- **Weight:** 203 g
- **Material:** Silicone
- **Water Resistance:** IPX7 (Waterproof)
- **Battery:** 1 Lithium Ion (included)
- **Charging:** USB-C (cable included)
- **Manufacturer:** Quality Fragrances Spain_Dummy code for NIS, es_personal_care_appliances, 8X3VA
- **Country of Origin:** China

8. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the device:

- This device is intended for external use only.
- Do not use the device if it appears damaged or if the silicone is torn.
- Discontinue use immediately if you experience any pain, discomfort, or irritation.
- Keep out of reach of children.
- Do not expose the device to extreme heat or direct sunlight.
- Only use the provided charging cable.
- Consult a healthcare professional if you have any medical conditions or concerns before using this product.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please visit the official Satisfyer website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

You can find more information and contact details on the [Satisfyer Brand Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BRL4RV3J>

More documents and user manuals: <https://manuals.plus/>