

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lenovo](#) /
- › [Lenovo ThinkPad T14s Gen 2 Laptop User Manual](#)

## Lenovo 20XF

# Lenovo ThinkPad T14s Gen 2 Laptop User Manual

Model: 20XF

## 1. INTRODUCTION

---

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo ThinkPad T14s Gen 2 laptop. Please read this manual thoroughly to ensure proper use and to maximize the performance and longevity of your device.



This image shows the Lenovo ThinkPad T14s Gen 2 laptop from the front, highlighting its 14-inch Full HD display. The screen features the AMD Ryzen 7 Pro and Windows 11 logos, along with a fingerprint icon, indicating key features of the device.

## 2. SETUP

---

### 2.1 Unpacking

Carefully remove your laptop and all accessories from the packaging. Verify that all components listed in the 'What's in the Box' section are present.

### 2.2 Connecting Power

1. Connect the power adapter to the power connector on your laptop.
2. Plug the power cord into an electrical outlet.
3. Allow the battery to charge fully before initial use, though you can begin using the laptop immediately while it charges.

### 2.3 Initial Boot-up

Press the power button located on the side or top of the keyboard deck. The laptop will guide you through the initial setup process for Windows 11 Pro, including language selection, network connection, and user account creation.

## 3. OPERATING YOUR LAPTOP

---

### 3.1 Keyboard and Touchpad

The ThinkPad T14s Gen 2 features a backlit keyboard and a multi-touch touchpad for navigation. The TrackPoint pointing device, located in the center of the keyboard, offers an alternative method for cursor control.



A top-down view of the laptop's keyboard and touchpad. This image illustrates the layout of the backlit keyboard, the TrackPoint pointing device, and the multi-touch touchpad, essential for navigation and input.

- **Backlit Keyboard:** Press Fn + Spacebar to cycle through backlight brightness levels.
- **Touchpad:** Supports multi-touch gestures for scrolling, zooming, and more. Refer to Windows settings for customization.
- **TrackPoint:** Use the red cap to move the cursor and the three buttons below the spacebar for clicking and scrolling.

### 3.2 Fingerprint Reader

The integrated fingerprint reader provides secure and convenient login. During initial setup or via Windows Hello settings, you can enroll your fingerprints.

### 3.3 Display Features

Your laptop is equipped with a 14-inch FHD (1920 x 1080) IPS Anti-Glare display. Adjust brightness using the function keys (F5/F6) or through Windows display settings.



An angled view of the open laptop, emphasizing the slim bezels of the 14-inch display and the ergonomic design of the keyboard. This view provides a good sense of the laptop's profile during use.

### 3.4 Ports and Connectivity

The laptop offers various ports for connecting peripherals and external displays.



This side view of the ThinkPad T14s Gen 2 demonstrates the available ports, including USB-C, USB-A, and HDMI, which are crucial for connecting external devices and displays.

- 2 x USB 3.2 Gen 1 Type-A
- 2 x USB-C (supports power delivery and DisplayPort)
- 1 x HDMI
- 1 x Headphone / mic combo jack
- 1 x Kensington Security Slot
- **Wireless:** Wi-Fi 6 and Bluetooth for network and peripheral connections.

### 3.5 Windows 11 Pro Basics

Your laptop comes pre-installed with Windows 11 Pro. Familiarize yourself with the new interface, including the Start menu, Taskbar, and Snap Layouts for enhanced productivity. Regular updates are recommended for security and feature enhancements.

## 4. MAINTENANCE

---

### 4.1 Cleaning

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to clean the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals.
- Ensure the laptop is powered off and unplugged before cleaning.

### 4.2 Battery Care

- To prolong battery life, avoid extreme temperatures.
- Periodically allow the battery to discharge to below 20% before recharging.

- If storing the laptop for an extended period, ensure the battery is charged to approximately 50-60%.

## 4.3 Software Updates

Regularly check for and install updates for Windows 11 Pro and Lenovo drivers. These updates provide security patches, performance improvements, and new features.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter.

### 5.1 Power Issues

- **Laptop not turning on:** Ensure the power adapter is securely connected and the outlet is functional. Check if the battery has sufficient charge.
- **Battery not charging:** Verify the power adapter and cable are not damaged. Try a different outlet.

### 5.2 Display Problems

- **No display:** Connect an external monitor to check if the issue is with the laptop's internal display. Restart the laptop.
- **Dim display:** Adjust brightness using function keys (F5/F6) or Windows display settings.

### 5.3 Connectivity Issues

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Check for updated Wi-Fi drivers.
- **Bluetooth device not pairing:** Ensure the Bluetooth device is in pairing mode and within range. Check Bluetooth settings on the laptop.

## 6. SPECIFICATIONS

---

Detailed technical specifications for the Lenovo ThinkPad T14s Gen 2 (Model 20XF).



The rear view of the closed laptop, showcasing its sleek design and the Lenovo branding on the lid. This perspective highlights the overall compact form factor.

Feature	Specification
Processor	AMD Ryzen 7 Pro 5850U (8 Cores, 16 Threads, up to 4.4 GHz)
Graphics	AMD Radeon Graphics (Integrated)
RAM	16GB DDR4 SDRAM
Storage	1TB PCIe NVMe M.2 SSD
Display	14" FHD (1920 x 1080) IPS, Anti-Glare, 300 nits
Operating System	Windows 11 Pro
Wireless Connectivity	Wi-Fi 6, Bluetooth
Ports	2x USB 3.2 Gen 1 Type-A, 2x USB-C, 1x HDMI, 1x Headphone/Mic Combo, 1x Kensington Security Slot
Webcam	FHD IR/RGB Hybrid with ThinkShutter
Security	Fingerprint Reader
Keyboard	Backlit
Dimensions (LxWxH)	12.94 x 8.89 x 0.63 inches

Feature	Specification
Weight	2.83 lbs
Color	Black


## 7. WARRANTY AND SUPPORT

Your Lenovo ThinkPad T14s Gen 2 laptop is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official Lenovo support website. For technical assistance, driver downloads, or service requests, please contact Lenovo customer support.

**Lenovo Support Website:** [support.lenovo.com](https://support.lenovo.com)

### Related Documents - 20XF

 <p>ThinkPad E14 Gen 6 / ThinkPad E16 Gen 2</p>	<p><a href="#">Lenovo ThinkPad E14 Gen 6 and E16 Gen 2 Setup Guide</a></p> <p>A comprehensive setup guide for Lenovo ThinkPad E14 Gen 6 and ThinkPad E16 Gen 2 laptops, covering initial setup, overview of features, Lenovo Vantage software, and regulatory information.</p>
 <p>ThinkPad T14s Gen 4</p>	<p><a href="#">Lenovo ThinkPad T14s Gen 4 Quick Start Guide</a></p> <p>Get started with your Lenovo ThinkPad T14s Gen 4. This guide covers initial setup, key features, software utilities, and technical specifications, including SAR information.</p>
 <p>ThinkPad Z13 Gen 1</p>	<p><a href="#">Lenovo ThinkPad Z13 Gen 1 Quick Start Guide and Specifications</a></p> <p>Concise guide to the Lenovo ThinkPad Z13 Gen 1, covering product features, connectivity, and regulatory information including SAR and radio frequency specifications.</p>
 <p>ThinkPad T14 Gen 6 / ThinkPad P14s Gen 6 AMD ThinkPad T16 Gen 4 / ThinkPad P16s Gen 4 AMD</p>	<p><a href="#">Lenovo ThinkPad T14 Gen 6 / P14s Gen 6 AMD &amp; T16 Gen 4 / P16s Gen 4 AMD Quick Start Guide</a></p> <p>This document provides essential information for setting up and using your Lenovo ThinkPad T14 Gen 6, ThinkPad P14s Gen 6 AMD, ThinkPad T16 Gen 4, and ThinkPad P16s Gen 4 AMD laptops, including connectivity, feature overviews, and regulatory compliance information.</p>
 <p>ThinkPad T14 Gen 5 / ThinkPad P14s Gen 5 AMD</p>	<p><a href="#">Lenovo ThinkPad T14 Gen 5 / ThinkPad P14s Gen 5 AMD Setup Guide</a></p> <p>Get started, overview, features, and SAR information for Lenovo ThinkPad T14 Gen 5 and ThinkPad P14s Gen 5 AMD laptops. Includes setup instructions, software features, and technical specifications.</p>



[Lenovo IdeaPad Pro 5 16AKP10 Specifications and Overview](#)

Detailed specifications and overview of the Lenovo IdeaPad Pro 5 16AKP10 laptop, including performance, design, connectivity, security, operating requirements, and certifications.