

[Manuals.plus](#) /

› [ELEPHAS](#) /

› ELEPHAS BL108 Mini Projector 1080p Full HD User Manual

## ELEPHAS BL108

# ELEPHAS BL108 Mini Projector 1080p Full HD User Manual

Model: BL108 | Brand: ELEPHAS

## 1. INTRODUCTION

Thank you for purchasing the ELEPHAS BL108 Mini Projector. This manual provides essential information for setting up, operating, and maintaining your projector. Please read it thoroughly before use to ensure proper function and to maximize your viewing experience. Keep this manual for future reference.

### Safety Precautions

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Avoid placing the projector in dusty, humid, or extremely hot environments.
- Use only the power adapter supplied with the projector.
- Do not attempt to repair the projector yourself. Contact qualified service personnel.

## 2. PACKAGE CONTENTS

Please check that all items are present in your package:

- ELEPHAS BL108 Mini Projector
- Power Cord
- HDMI Cable
- Remote Control
- User Manual

## 3. PRODUCT OVERVIEW

Familiarize yourself with the projector's components and interfaces.

### Projector Front and Top View



**Figure 3.1:** Front and top view of the ELEPHAS BL108 Mini Projector, showing the lens, control panel, and included remote control.

The front of the projector features the projection lens. The top panel includes control buttons for power, navigation, and input selection. The remote control provides convenient operation from a distance.

### **Projector Rear and Side View (Ports)**



**Figure 3.2:** Rear and side view of the projector, highlighting the available input and output ports.

The rear and side panels house various connectivity options, including HDMI, USB, AV, and audio output ports, allowing connection to a wide range of devices.

## 4. SETUP

### 4.1 Placement

Place the projector on a stable, flat surface. For optimal viewing, ensure the projector is positioned directly in front of the projection screen or wall. The projector supports projection sizes from 33 to 200 inches, with optimal projection distances between 1.1m and 6m.

**Fire TV Stick / Roku Stick Connection**

YouTube NETFLIX HBO max SHOWTIME Disney+  
nick prime video hulu IMDb abc

**Note: All Sticks are not included**

Figure 4.1: Recommended projection distances for different screen sizes.

## 4.2 Power Connection

1. Connect the power cord to the projector's power input port.
2. Plug the other end of the power cord into a power outlet.

3. The power indicator light on the projector will illuminate.

## 4.3 Focus and Keystone Adjustment

- **Focus:** Rotate the focus ring near the lens until the projected image is clear and sharp.
- **Keystone:** If the image appears trapezoidal, adjust the keystone correction dial (if available) or use the remote control to correct the image shape. The screen can be reduced to 75% by adjusting the display without moving the projector.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power On/Off

- **Power On:** Press the power button on the projector or the remote control.
- **Power Off:** Press the power button again. Confirm shutdown if prompted.

### 5.2 Input Source Selection

After powering on, select the desired input source using the "Source" button on the projector or remote control. Options typically include HDMI, USB, and AV.

### 5.3 Connecting External Devices

#### HDMI Connection (PC, Laptop, Game Console, TV Stick)

1. Connect one end of the HDMI cable to the HDMI port on your device.
2. Connect the other end to the HDMI port on the projector.
3. Select "HDMI" as the input source on the projector.

# Fire TV / Roku / Chromecast



**Note: All Sticks are not included**

**Figure 5.1:** Connecting a streaming stick (e.g., Fire TV Stick) via HDMI. Streaming sticks are not included.

## USB Connection (USB Drive)

1. Insert your USB drive into the USB port on the projector.
2. Select "USB" as the input source.
3. Navigate through the files on your USB drive using the remote control or projector buttons to play media.

## Smartphone/Tablet Connection

To connect a smartphone or tablet, an additional HD adapter cable is required (not included).

- **For iOS devices (iPhone/iPad):** You will need a Lightning to HD Adapter cable.
- **For Android devices:** You will need a Micro USB/Type-C to HD Adapter cable.



Figure 5.2: Connection methods for iOS and Android smartphones/tablets. HD Adapter cables are not included.

## 5.4 Audio Output

The projector has built-in speakers. For enhanced audio, you can connect external speakers via the audio output port. Note that Dolby sound is not supported by this mini projector.

## 6. MAINTENANCE

### 6.1 Cleaning the Lens

Use a professional lens cleaning cloth or lens paper to gently wipe the lens. Avoid using abrasive cleaners or cloths that could scratch the lens surface.

### 6.2 Cleaning the Projector Body

Wipe the projector's exterior with a soft, dry cloth. Do not use liquid cleaners directly on the projector.

### 6.3 Ventilation

Ensure the ventilation vents are clear of obstructions to prevent overheating. The projector features a high-efficiency cooling technology designed to minimize fan noise and extend lamp life to over 65,000 hours.

## 7. TROUBLESHOOTING

| Problem                    | Possible Cause                                                                                                                                                               | Solution                                                                                                                                                                                                                  |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No image displayed         | <ul style="list-style-type: none"><li>• Power cable not connected</li><li>• Input source not selected correctly</li><li>• Device not connected properly</li></ul>            | <ul style="list-style-type: none"><li>• Check power connection</li><li>• Select the correct input source (HDMI, USB, AV)</li><li>• Ensure cables are securely connected</li></ul>                                         |
| Blurry image               | <ul style="list-style-type: none"><li>• Focus not adjusted</li><li>• Keystone not adjusted</li><li>• Projector too close/far from screen</li></ul>                           | <ul style="list-style-type: none"><li>• Adjust the focus ring</li><li>• Adjust the keystone correction</li><li>• Refer to placement guidelines for optimal distance</li></ul>                                             |
| No sound                   | <ul style="list-style-type: none"><li>• Volume too low or muted</li><li>• Audio cable not connected (for external speakers)</li><li>• Source device audio settings</li></ul> | <ul style="list-style-type: none"><li>• Increase volume on projector and source device</li><li>• Ensure external speakers are connected and powered</li><li>• Check audio output settings on your source device</li></ul> |
| Remote control not working | <ul style="list-style-type: none"><li>• Batteries are dead or inserted incorrectly</li><li>• Obstruction between remote and projector</li></ul>                              | <ul style="list-style-type: none"><li>• Replace batteries and check polarity</li><li>• Ensure a clear line of sight to the projector's IR receiver</li></ul>                                                              |

## 8. SPECIFICATIONS

| Feature                 | Detail                                                    |
|-------------------------|-----------------------------------------------------------|
| Brand                   | ELEPHAS                                                   |
| Model Number            | BL108                                                     |
| Color                   | White                                                     |
| Display Resolution      | 1920 x 1080 (Full HD Supported)                           |
| Brightness              | 8500 Lux                                                  |
| Contrast Ratio          | 9500:1                                                    |
| Lamp Life               | 65,000 hours                                              |
| Aspect Ratio            | 4:3 / 16:9                                                |
| Projection Size         | 33 - 200 inches                                           |
| Projection Distance     | 1.1m - 6m (optimal)                                       |
| Connectivity Technology | HDMI, USB, AV, Audio                                      |
| Compatible Devices      | PC, Laptop, Smartphone, Tablet, TV Stick, Game Consoles   |
| Special Features        | Lightweight, Integrated Cooling System, Built-in Speakers |
| Dolby Sound Support     | Not supported                                             |

## 9. WARRANTY AND SUPPORT

ELEPHAS provides lifetime technical support for all its projectors. If you encounter any issues or have questions regarding your BL108 Mini Projector, please contact ELEPHAS customer service for assistance. Contact information can typically be found on the official ELEPHAS website or through your purchase platform.

© 2023 ELEPHAS. All rights reserved.

**ASK A QUESTION ABOUT THIS MANUAL**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question