Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Breezary 23001-BLK

Breezary 20 Inch Caged Ceiling Fan with Light and Remote User Manual

Model: 23001-BLK

Introduction

Thank you for purchasing the Breezary 20 Inch Caged Ceiling Fan with Light and Remote. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and keep them for future reference.

Important Safety Information

- Always turn off the power at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Ensure the installation site can support the fan's weight.
- Do not bend the blade holders during installation or cleaning.
- Keep children away from the fan during operation.

Package Contents

Verify that all components are present before beginning installation:

- 1 x 20 inch Caged Ceiling Fan
- 1 x Remote Control
- 1 x 6" Downrod
- 1 x 10" Downrod
- 1 x User Manual



Figure 1: Product dimensions and included components. The diagram illustrates the fan's 20-inch diameter, 14.1/18.1-inch height options with different downrods, and the remote control layout.

Setup and Installation

Mounting Options

The fan comes with two downrods (6 inches and 10 inches) to accommodate various ceiling heights. It also supports sloped ceiling installations up to 15 degrees. Choose the appropriate downrod length for your ceiling height.

Bulb Installation

This fandelier requires 5 E12 screw-in bulbs (not included). The maximum power for each bulb is 9W. Ensure to use strictly certified E12 explosion-proof bulbs for safety and optimal performance.



Figure 2: Detail of the fan's light sockets. This image shows the five E12 bulb sockets within the caged design, ready for bulb installation.

Operating Instructions

Remote Control Functions

The included remote control allows for convenient operation of both the fan and the light. The fan and light can be controlled separately.

- **Light ON/OFF:** Controls the light independently.
- **Fan & Light ON/OFF:** Turns both the fan and light on or off simultaneously.
- **6-Speed Settings:** Adjusts the fan speed from 1 (gentle breeze) to 6 (strong airflow).
- **Natural Wind:** Activates a mode that simulates natural breeze by varying fan speed.
- **Reverse:** Changes the direction of the fan blades for summer or winter mode.
- **Timer Setting:** Sets the fan to turn off automatically after 1, 2, 4, or 8 hours.



Figure 3: Remote control functions. This image details the buttons and their corresponding actions for controlling the fan and light.

Fan Speed Adjustment

The fan offers 6 adjustable speeds to suit your comfort needs:

- **Levels 1-2:** Gentle breeze, ideal for sleeping.
- **Levels 3-4:** Natural wind, suitable for daily activities and leisure.
- **Levels 5-6:** Strong wind, provides powerful cooling airflow.



Figure 4: Fan speed settings. This graphic explains the different fan speed levels and their recommended uses.

Reversible DC Motor

The fan features a reversible DC motor, allowing you to change the direction of airflow for year-round comfort:

- **Summer Mode (Downward Airflow):** Creates a cooling effect.
- **Winter Mode (Upward Airflow):** Helps distribute warm air evenly throughout the room.



Figure 5: Reversible motor function. This image visually demonstrates how the fan's airflow can be reversed for seasonal comfort.

Quiet Operation

The fan is designed with a super silent DC motor, operating at less than 35dB, ensuring a peaceful environment suitable for bedrooms and other quiet spaces.




Figure 6: Quiet operation. This image highlights the fan's low noise level, making it suitable for quiet environments.

Light Functionality

The fan's light can be turned on or off independently using the remote control. Please note that this fandelier ceiling fan does not have a dimmable function.



Figure 7: Light operation. This image demonstrates the light being off, on during the day, and on at night.

Product Video

Your browser does not support the video tag.

Video 1: Breezary 20" Caged Ceiling Fan with Light Remote. This video demonstrates the fan's features and operation, including the light and fan speed controls.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents that may damage the finish or electrical components.
- **Dusting:** Periodically dust the blades and housing to prevent dust buildup, which can affect performance and appearance.

- **Tightening Screws:** Check all screws and connections annually to ensure they are secure.
- **Bulb Replacement:** Ensure the power is off before replacing any E12 bulbs.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery dead.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Bulb(s) faulty or loose; No power to the light; Loose wire connections.	Replace bulb(s) or tighten; Check circuit breaker; Verify light wire connections.
Fan wobbles	Loose mounting screws; Unbalanced blades.	Ensure all mounting screws are tight; Check for bent blade holders; Use a balancing kit if necessary.
Remote control not working	Battery dead or incorrectly inserted; Remote not paired.	Replace battery, ensuring correct polarity; Refer to remote pairing instructions in the full manual (if applicable).

Specifications

Brand	Breezary
Model Number	23001-BLK
Dimensions (D x W x H)	20"D x 20"W x 18.1"H
Motor Type	DC Motor
Number of Blades	5
Blade Material	ABS Plastic
Light Type	E12*5 (bulbs not included, max 9W per bulb)
Fan Speed Settings	6 Speeds
Noise Level	35 dB
Mounting Type	Downrod Mount (6" and 10" downrods included)
Sloped Ceiling Support	Up to 15°
Wattage	40 watts
Air Flow Capacity	787 cfm
Voltage	24 volts

Control Method	Remote Control
Indoor/Outdoor Usage	Indoor
Material	Acrylonitrile Butadiene Styrene, Alloy Steel
Certification	ETL
Item Weight	7.72 LBS

Warranty Information

This Breezary ceiling fan is covered by a**2-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Breezary customer service. We are committed to providing friendly customer service and support.
Please refer to the contact information provided with your purchase or visit the official Breezary website for support details.

© 2023 Breezary. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRP73J2S

More documents and user manuals: **https://manuals.plus/**