

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EagleStone](#) /

› [EagleStone Automatic Pitching Machine Baseball Toy Set ES33 User Manual](#)

## EagleStone ES33

# EagleStone Automatic Pitching Machine Baseball Toy Set ES33 User Manual

Model: ES33

## 1. INTRODUCTION

Thank you for purchasing the EagleStone Automatic Pitching Machine Baseball Toy Set ES33. This manual provides detailed instructions for the safe and effective use of your new baseball toy set. Please read this manual thoroughly before assembly and operation, and retain it for future reference.



*Image: The complete EagleStone Automatic Pitching Machine Baseball Toy Set ES33.*

## 2. PRODUCT COMPONENTS

Ensure all the following components are included in your package:

- Baseball Balls: 6 pieces (5.5 cm diameter)
- Bat: 1 piece (Lightweight plastic)
- Pitching Machine Base: 1 piece
- Batting Tee Pole: 1 piece
- Driver (for assembly): 1 piece

- Connector Pipe: 1 piece
- Ball Feeder Mechanism: 1 piece



*Image: All components of the baseball toy set.*

### 3. SETUP INSTRUCTIONS

The EagleStone ES33 set is designed for easy assembly and disassembly for convenient storage. Follow these steps to set up your baseball pitching machine:

#### 1. Step 1: Attach the Base Plate

Connect the base plate to the main blue base unit. Ensure it clicks securely into place.



*Image: Connecting the base plate.*

#### 2. Step 2: Insert the Connector Pipe

Insert the white connector pipe into the designated opening on the main base unit. Twist to secure.



*Image: Inserting the connector pipe.*

### 3. Step 3: Attach the Ball Feeder

Attach the red ball feeder mechanism to the top of the white connector pipe. Ensure it is firmly attached.



*Image: Attaching the ball feeder.*

### 4. Step 4: Insert the Batting Tee Pole

If using the manual batting tee mode, insert the red and blue batting tee pole into the designated slot on the base.



*Image: Inserting the batting tee pole.*

## 5. Step 5: Final Assembly Check

Verify all parts are securely connected. Your pitching machine is now ready for use.



*Image: Fully assembled pitching machine and batting tee.*

## Assembly and Usage Demonstration Video

Your browser does not support the video tag.

*Video: This video demonstrates the assembly process and various play modes of the EagleStone Automatic Pitching Machine Baseball Toy Set, including automatic ball launching and manual batting tee usage.*

## 4. OPERATING INSTRUCTIONS

### 4.1. Automatic Pitching Mode

This mode simulates a real pitching experience, allowing users to practice their batting timing and accuracy.

- **Loading Balls:** Place up to three baseballs into the red ball feeder. The set includes 6 baseballs for extended play.
- **Launching Balls:** Step on the pedal located at the front of the base unit. The ball will automatically launch into the air.
- **Batting:** Swing the bat to hit the launched ball. Practice controlling your swing timing for accurate hits.
- **Consecutive Shots:** The design allows for three consecutive ball launches without reloading, enhancing continuous practice.



*Image: Child using the automatic pitching function.*

### Adjusting Automatic Pitching Height

The height at which the ball is launched can be adjusted to suit different skill levels and user heights. This feature is ideal for challenging yourself and improving batting skills.

- Locate the adjustment mechanism on the pitching machine.
- Adjust the mechanism to set the desired launch height, ranging from approximately 80 cm to 120 cm.



*Image: Automatic pitching height adjustment mechanism.*

## 4.2. Manual Batting Tee Mode

This mode is suitable for beginners and younger children to practice their swing mechanics and develop arm and wrist strength.

- **Setup:** Place a baseball on top of the batting tee pole.
- **Batting:** Hit the ball directly from the tee. This helps improve hitting accuracy and build confidence.



Image: Child using the manual batting tee.

### Adjusting Manual Batting Tee Height

The height of the batting tee can be freely adjusted to accommodate users of various ages and heights, ensuring a comfortable and effective practice session for everyone.

- Adjust the height of the batting tee pole to match the user's preference.

# 固定ティ 高さの調整

子供の年齢や身長に合わせて調整できる



*Image: Manual batting tee height adjustment.*

## 5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your EagleStone ES33 baseball toy set.

- Cleaning:** Wipe down all plastic components with a damp cloth after use. Avoid harsh chemicals that may damage the material.
- Storage:** The set is designed for easy disassembly. After use, take apart the components and store them in the original packaging or a suitable container to save space and protect them from damage.
- Inspection:** Periodically check all parts for wear and tear. Replace any damaged components immediately to ensure safe operation.



Image: Disassembled bat for compact storage.

## 6. TROUBLESHOOTING

If you encounter any issues with your EagleStone ES33 baseball toy set, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ball does not launch automatically.	Pedal not fully pressed; mechanism jammed; ball improperly loaded.	Ensure the pedal is fully depressed. Check for any obstructions in the launching mechanism. Verify balls are correctly placed in the feeder.
Batting tee is unstable.	Components not securely connected; uneven ground.	Re-check all connections during assembly. Ensure the set is placed on a flat, stable surface.
Balls are damaged or lost.	Normal wear and tear; misplaced during play.	The set includes 6 balls. Additional replacement balls may be available from the manufacturer or retailer.

If the problem persists after attempting these solutions, please contact customer support.

---

## 7. SPECIFICATIONS

- **Model Number:** ES33
- **Recommended Age:** 6 years and up
- **Number of Players:** 1
- **Battery Required:** No
- **Product Dimensions (Packaged):** 43.79 x 19.5 x 16.2 cm
- **Product Weight (Packaged):** 980 g
- **Ball Diameter:** 5.5 cm
- **Automatic Pitching Height Range:** Approx. 80 cm to 120 cm
- **Material:** Durable Plastic

---

## 8. SAFETY INFORMATION

Please observe the following safety guidelines to ensure a safe play experience:

- **Adult Supervision:** Always ensure children are supervised by an adult during play.
- **Appropriate Use:** Use the product only as intended for baseball practice. Do not use it for other purposes.
- **Clear Area:** Ensure there is ample clear space around the play area to prevent accidents and injuries.
- **Inspect Before Use:** Before each use, check all components for damage or loose parts. Do not use if any part is broken or compromised.
- **No Throwing:** Do not throw the bat or balls at people or animals.
- **Small Parts:** Keep small parts away from young children to prevent choking hazards.





---

## 9. WARRANTY AND SUPPORT

EagleStone is committed to providing quality products. If you have any questions, concerns, or require assistance with your ES33 Automatic Pitching Machine Baseball Toy Set, please do not hesitate to contact our customer service team. We are dedicated to providing appropriate support.

For customer service inquiries, please refer to the contact information provided with your purchase or visit the official EagleStone website.

### Related Documents - ES33

 <p>PRODUCT ASSEMBLY INSTRUCTION</p> <p>service@eaglenstone.com</p>	<p><a href="#"><u>EagleStone Dinosaur Shooting Toy Assembly Instructions</u></a></p> <p>Comprehensive assembly and operation guide for the EagleStone Dinosaur Shooting Toy, detailing package contents, battery installation, gun assembly, shooting mechanics, and product modes.</p>
	<p><a href="#"><u>EagleStone Pool Basketball Hoop: Assembly and User Manual</u></a></p> <p>Detailed instructions for assembling and using the EagleStone Pool Basketball Hoop, including accessory list, step-by-step assembly guide, and air pump installation. Suitable for kids and adults.</p>
	<p><a href="#"><u>EagleStone Pool Basketball Hoop Installation Guide</u></a></p> <p>Step-by-step instructions for assembling the EagleStone Pool Basketball Hoop and installing the air pump. Includes accessories list and assembly diagrams.</p>
	<p><a href="#"><u>Vivitar Floatie Speaker ES33-SF-TA User Manual and Guide</u></a></p> <p>Comprehensive user manual for the Vivitar Floatie Speaker (ES33-SF-TA). Learn about specifications, charging, Bluetooth pairing, TWS function, safety precautions, and warranty information.</p>