

Herneum FC

Herneum FC Portable CD Player Boombox User Manual

Model: FC

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Herneum FC Portable CD Player Boombox. Please read this manual thoroughly before using the device and retain it for future reference.

PRODUCT FEATURES

- **Portable CD Player:** Top-loading CD player with play/pause, skip, and repeat functions.
- **FM Radio:** Built-in FM radio with telescopic antenna for enhanced reception.
- **Dual Stereo Sound System:** High-performance speakers for clear audio.
- **Rechargeable Battery:** Integrated 2000mAh battery providing 4-5 hours of playback.
- **Bluetooth Connectivity:** Wireless audio streaming from compatible devices.
- **Multiple Inputs:** Supports USB and AUX-in for versatile audio sources.
- **Headphone Output:** For private listening.
- **Remote Control:** Convenient operation from a distance, including sleep timer function.

PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- Herneum FC Portable CD Player Boombox
- Remote Control
- User Manual
- Power Cable



Image: The Herneum FC Portable CD Player Boombox, remote control, power cable, and user manual are neatly packaged in a box, illustrating the complete set of items included with the product.

SAFETY INFORMATION

- Do not expose the device to rain or moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not open the device casing; refer servicing to qualified personnel.
- Keep out of reach of children.
- Use only the provided power adapter.

SETUP

1. Powering the Device

The Herneum FC can be powered by its internal rechargeable battery or by connecting it to an AC power outlet.

- **AC Power:** Connect the provided power cable to the "Power socket" (19) on the back of the unit and then to a wall outlet.
- **Rechargeable Battery:** The unit has a built-in 2000mAh rechargeable battery. It charges automatically when connected to AC power. A full charge provides approximately 4-5 hours of playback.



Image: The boombox is shown in two scenarios: indoors, connected to a power outlet for charging, and outdoors, highlighting its portability with the built-in rechargeable battery.

2. Antenna Adjustment

For optimal FM radio reception, extend the telescopic antenna fully and adjust its position.



Image: The Herneum FC Portable CD Player Boombox is displayed with its telescopic antenna extended, ready for FM radio reception.

OPERATING INSTRUCTIONS

1. General Controls

The device features various controls on its top panel and a remote control for convenient operation.



- | | | |
|------------------|----------------------|------------------|
| ① Volume +/- | ⑥ Tuning +/- | ⑪ USB PORT |
| ② Previous Track | ⑦ Mode | ⑫ Aux In |
| ③ Next Track | ⑧ Repeat | ⑬ HeadPhone jack |
| ④ Play/Pause | ⑨ Stop | ⑭ Power switch |
| ⑤ FM | ⑩ Open/Close CD comp | ⑮ Power socket |

Image: A detailed diagram of the boombox's control panel, showing buttons for volume, track navigation, play/pause, stop, mode, repeat, tuning, and the CD compartment. Also visible are the USB, AUX-in, and headphone jack ports, each with a corresponding number.

- **Power Switch (18):** Located on the back of the unit.
- **Volume +/- (1):** Adjusts the audio output level.
- **Mode (7):** Switches between CD, FM, Bluetooth, USB, and AUX modes.
- **Display (14):** Shows current mode, track number, and FM frequency.

2. CD Playback

1. Open the CD compartment (10) by gently lifting the lid.
2. Place a CD with the label side facing up.
3. Close the CD compartment.
4. Press the **Mode** button (7) to select CD mode.
5. Press **Play/Pause** (4) to start playback.
6. Use **Previous Track** (2) and **Next Track** (3) to navigate tracks.
7. Press **Repeat** (8) for single track or all track repeat.
8. Press **Stop** (9) to end playback.

Your browser does not support the video tag.

Video: This video demonstrates the CD playback functionality of the Herneum FC Portable CD Player Boombox, showing the process of inserting a CD and initiating playback.

3. FM Radio Operation

1. Extend the telescopic antenna.
2. Press the **Mode** button (7) to select FM radio mode.
3. Use **Tuning +/-** (6) to manually tune to a station.
4. For automatic scanning, press and hold **Tuning +/-** (6).

Your browser does not support the video tag.

Video: This video demonstrates the FM radio functionality of the Herneum FC Portable CD Player Boombox, showing how to tune to different stations and highlighting the clear audio output.

4. Bluetooth Connectivity

1. Press the **Mode** button (7) to select Bluetooth mode. The display will show "BT" and flash, indicating it's ready for pairing.

2. On your mobile device, enable Bluetooth and search for "Herneum FC" (or similar device name).
3. Select the device to pair. Once connected, the "BT" indicator will stop flashing.
4. You can now stream audio from your device to the boombox.

6 Playback Source



Image: The boombox is depicted alongside a smartphone, illustrating the Bluetooth pairing process and the various playback sources available, including USB, AUX-in, headphone jack, and FM radio.

5. USB Playback

1. Insert a USB drive containing MP3/WMA files into the USB PORT (11).
2. Press the **Mode** button (7) to select USB mode.
3. Playback will start automatically. Use track navigation buttons to select songs.

6. AUX-in Connection

1. Connect an external audio device (e.g., smartphone, MP3 player) to the AUX-in jack (12) using a 3.5mm audio cable.
2. Press the **Mode** button (7) to select AUX mode.

3. Control playback and volume from your external device.

7. Headphone Use

Plug headphones into the Headphone jack (13) for private listening. The speakers will automatically mute.

8. Remote Control

The included remote control allows for convenient operation of all functions from a distance. Insert 2 x AAA batteries (not included) into the remote.

- **Mute/Unmute:** Temporarily silences or restores audio.
- **Skip Track:** Navigates to the next or previous track.
- **Change Radio:** Adjusts FM frequency.
- **Control Volume:** Increases or decreases volume.
- **Stop Playing:** Halts current playback.
- **EQ Mode:** Adjusts sound equalization settings.
- **Sleep Timer:** Set preferred running time (15, 30, 45, 60, or 90 minutes).



Image: The Herneum FC Portable CD Player Boombox is shown with its remote control, illustrating the convenience of operating the device from a distance.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Clean dirty CDs with a soft, lint-free cloth, wiping from the center outwards.
- **Storage:** When not in use for extended periods, store the boombox in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; battery drained; power switch off.	Check power cable connection; charge battery; ensure power switch (18) is ON.

Problem	Possible Cause	Solution
CD not playing/skipping	CD dirty or scratched; CD inserted incorrectly; CD compartment not closed.	Clean or replace CD; ensure CD is label-side up; close compartment firmly.
Poor FM reception	Antenna not extended/adjusted; weak signal.	Extend and adjust antenna; try moving the unit to a different location.
Bluetooth not pairing	Device not in pairing mode; Bluetooth disabled on external device.	Ensure boombox is in Bluetooth mode; enable Bluetooth on your device and search again.
Remote control not working	Batteries drained or inserted incorrectly; obstruction between remote and unit.	Replace remote batteries; ensure correct polarity; remove obstructions.

SPECIFICATIONS


- **Model:** FC
- **Brand:** Herneum
- **Product Dimensions:** 12.6 x 8.66 x 5.9 inches
- **Item Weight:** 4.36 pounds
- **Connectivity Technology:** Bluetooth, CD, USB, AUX-in, FM Radio
- **Color:** Black
- **Speaker Type:** Dual Speaker
- **Battery:** Built-in 2000mAh rechargeable battery
- **Playback Time (Battery):** 4-5 hours






WARRANTY AND SUPPORT

The Herneum FC Portable CD Player Boombox comes with an 18-month warranty. For warranty claims, technical support, or any inquiries, please contact Herneum customer service. Visit the official Herneum store for more information:[Herneum Store](#)



Related Documents - FC

	<p>EMS FireCell FC-610-001 Wireless Dual Input/Output Unit Installation Guide</p> <p>Comprehensive installation guide for the EMS FireCell FC-610-001 Wireless Dual Input/Output Unit. Covers pre-installation checks, component identification, wiring procedures for inputs and outputs, wall mounting, power connection, configuration, and LED status indicators. Includes specifications and regulatory information.</p>
---	---

	<p>EMS FireCell FC-610-001 Wireless Input Output Unit Installation Guide</p> <p>Installation guide for the EMS FireCell FC-610-001 Wireless Dual Input/Output Unit, detailing pre-installation steps, component identification, wiring instructions for inputs and outputs, power device setup, LED operation, specifications, and regulatory information.</p>
	<p>Alilo Big Bunny G7 Manual: Features, Operations, and Specifications</p> <p>Comprehensive user manual for the Alilo Big Bunny G7, detailing its features, functions, operations, specifications, and troubleshooting tips.</p>
	<p>OUZEY X2 TV Game Box User Manual - Retro Gaming Console</p> <p>Comprehensive user manual for the OUZEY X2 TV Game Box, detailing setup, operations, game play, settings, troubleshooting, and hardware specifications for this retro gaming console.</p>
	<p>AUTDER Wireless Portable Air Compressor FC-368 User Manual</p> <p>This manual provides instructions and safety precautions for the AUTDER Wireless Portable Air Compressor, model FC-368. Learn how to charge the battery, connect and use the device, and understand its technical specifications.</p>
	<p>ARGO MULTISPLIT AIR CONDITIONERS: Features, Specifications, and Unit Matchings</p> <p>Comprehensive guide to ARGO MULTISPLIT AIR CONDITIONERS, detailing main features, low ambient cooling/heating capabilities, outdoor and indoor unit specifications, and unit matching information for cooling and heating modes.</p>