**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**ACEFAST T8**

# ACEFAST T8 Wireless Earbuds User Manual

Model: T8

## Introduction

Thank you for choosing the ACEFAST T8 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before using the product.

The ACEFAST T8 earbuds feature Bluetooth 5.3 connectivity, a unique transparent design with an LED power display, touch controls, and a wireless charging case. They are designed to provide a high-quality audio experience with clear calls and comfortable fit.

## Package Contents

- ACEFAST T8 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L, XL)
- User Manual

## Setup

### 1. Charging the Earbuds and Case

Before first use, fully charge the charging case and earbuds. The charging case has a 480mAh battery capacity and can provide multiple full charges for the earbuds. The case supports fast charging via its USB-C port and can be fully charged in approximately 2 hours.

1. Connect the provided USB-C cable to the charging port on the case and to a power source.
2. Place the earbuds into the charging case. Ensure they are correctly seated.
3. The LED digital display on the charging case will show the current battery status. When the charging box is fully charged, the display will show "OK".




Image: The ACEFAST T8 charging case displaying battery life and indicating fast charging capabilities. The image highlights the '30H' total battery life with the charging case and quick charge times.

## 2. Pairing with Your Device

The ACEFAST T8 earbuds utilize advanced Bluetooth 5.3 technology for a stable and efficient connection.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and pick up both earbuds. They will automatically enter pairing mode.

3. On your device, search for Bluetooth devices and select "T8" from the list.
4. Once connected, the earbuds will automatically pair with your device for future use.

The earbuds are compatible with iOS, Android, and Windows devices that support Bluetooth.




Image: A visual representation of the ACEFAST T8 earbuds highlighting the Advanced Bluetooth 5.3 chip for strong performance and stable signal.

## 3. Wearing the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears. The package includes four different sizes (S, M, L, XL).

1. Gently insert each earbud into your ear canal.
2. Rotate the earbud slightly until it feels secure and comfortable.





Image: A person wearing the ACEFAST T8 earbuds, illustrating a natural and pleasant fit for comfortable listening.

# Operating Instructions

## Touch Controls

The ACEFAST T8 earbuds feature smart touch controls for easy management of audio playback and calls without needing to access your phone.

| Function | Action |
| --- | --- |
| Play/Pause Music | Single tap on either earbud |
| Next Song | Double tap on the right earbud |
| Previous Song | Double tap on the left earbud |
| Volume Up | Triple tap on the right earbud |
| Volume Down | Triple tap on the left earbud |
| Answer/End Call | Single tap on either earbud |
| Reject Call | Press and hold either earbud for 2 seconds |
| Activate Voice Assistant | Press and hold either earbud for 3 seconds |




Image: A close-up of an ACEFAST T8 earbud, illustrating the touch control area and the concept of fingertip control over music and calls.

## Audio Quality and Calls

The T8 earbuds are equipped with 10mm and 6mm vibrating diaphragms, delivering powerful bass, stunning treble, and clear mids for an immersive stereo sound experience. Each earbud includes a built-in microphone for clear phone calls.





Image: An exploded view of an ACEFAST T8 earbud, highlighting the 10+6mm double moving coil drivers and Dual Mic ENC (Environmental Noise Cancellation) technology for enhanced sound and call clarity.

## Maintenance

### Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.

- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using abrasive materials or harsh chemicals.

## Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures.

## Water Resistance

The ACEFAST T8 earbuds are rated as Waterproof (IPX4 equivalent, based on product description). This means they are resistant to splashing water from any direction. They are suitable for sports and light rain exposure but should not be submerged in water.




Image: The ACEFAST T8 earbuds and charging case placed on a wet, rocky surface, visually representing their IPX4 waterproof rating.

## Troubleshooting

### Common Issues and Solutions

- **Earbuds not pairing:**
  - Ensure both earbuds are charged.

- Place earbuds back in the case, close it, then open it again and try pairing.
- Turn off and on your device's Bluetooth.
- Forget "T8" from your device's Bluetooth list and re-pair.

- **No sound from one earbud:**
  - Ensure both earbuds are charged.
  - Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise place back in case and re-pair).
- **Charging case not charging:**
  - Check the USB-C cable and power adapter for damage.
  - Try a different USB-C cable or power source.
- **Poor sound quality:**
  - Ensure earbuds are clean and ear tips fit properly.
  - Move closer to your connected device to avoid interference.
  - Check audio settings on your device.

## Specifications

| Feature | Detail |
|---|---|
| Brand | ACEFAST |
| Model Name | T8 |
| Connectivity Technology | Wireless (Bluetooth) |
| Bluetooth Version | 5.3 |
| Bluetooth Range | Up to 10 meters |
| Ear Placement | In Ear |
| Control Type | Touch Control |
| Audio Driver Type | Dynamic Driver (10mm + 6mm) |
| Frequency Response | 20Hz - 20000Hz |
| Impedance | 2 Ohms |
| Noise Control | Active Noise Cancellation (ENC for calls) |
| Earbud Battery Life | Up to 6 hours (single charge) |
| Total Battery Life (with case) | Up to 30 hours |
| Charging Case Battery Capacity | 480mAh |
| Charging Case Charge Time | Approx. 2 hours (USB-C) |
| Water Resistance Level | Waterproof (IPX4 equivalent) |
| Earbud Weight | Approx. 11 Grams (per earbud) |

| Feature | Detail |
| --- | --- |
| Material | Plastic (earbuds), Silicon (case) |

© 2026 ACEFAST. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0BRQ2JRJG**

More documents and user manuals: **https://manuals.plus/**