

## HOSEOKA VM8031

# HOSEOKA VM8031 Black Nightstand with Charging Station User Manual

## INTRODUCTION

---

Thank you for choosing the HOSEOKA VM8031 Black Nightstand with Charging Station. This manual provides essential information for the proper assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

## SAFETY INFORMATION

---

### Important Safety Warnings:

- Do not overload the nightstand. The maximum weight recommendation for the tabletop is 44 lbs (20 kg), and for each drawer, it is 11 lbs (5 kg).
- Secure the nightstand to the wall using appropriate anti-tip hardware (if included) to prevent tipping, especially in households with children or pets.
- Keep the nightstand away from direct heat sources, open flames, and excessive moisture to prevent damage or warping.
- Ensure all electrical connections for the charging station are properly secured and not exposed to liquids.

## PACKAGE CONTENTS

---

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact HOSEOKA customer service.

- Nightstand components (panels, drawers, hardware)
- Integrated Charging Station (2 AC Outlets, 2 USB Ports)
- Instruction Manual
- Assembly Hardware (screws, dowels, cam locks, drawer slides, handles)

## SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly of the HOSEOKA VM8031 Nightstand is designed to be straightforward. For detailed, step-by-step instructions, please refer to the included instruction manual or download the PDF version [here](#).

**Recommended Tools:** A screwdriver is recommended for assembly.

**General Assembly Steps:**

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels provided in the instruction manual.
3. Assemble the main frame of the nightstand according to the diagrams.
4. Install the drawer slides onto the side panels and the drawers. Ensure they are correctly oriented for smooth operation.
5. Assemble the drawers and attach the handles.
6. Insert the assembled drawers into the nightstand frame.
7. Install the integrated charging station into the designated slot on the top panel.
8. Connect the power cord and ensure all connections are secure.
9. Place the nightstand in its desired location and, if necessary, attach anti-tip hardware to a wall stud.



**Figure 1:** Product Dimensions. This diagram illustrates the overall dimensions of the nightstand, including width, depth, and height, along with internal drawer measurements and power cable length.



**Figure 2:** Nightstand with Drawers Extended. This image displays the nightstand with its three drawers fully extended, revealing the drawer slides and internal storage capacity, useful for understanding drawer assembly.

## OPERATING INSTRUCTIONS

The HOSEOKA VM8031 Nightstand features an integrated charging station for convenient power access.

### Using the Charging Station:

1. Ensure the nightstand's power cord (5ft long) is securely plugged into a functional wall outlet.
2. The charging station includes two standard 125V/12A AC outlets and two 5V/2A USB ports.
3. Plug your electronic devices (e.g., phone, tablet, lamp, game console) directly into the appropriate AC or USB ports on the top surface of the nightstand.
4. The charging station is designed for indoor use only.



**Figure 3:** Charging Station Detail. This image provides a close-up view of the integrated power strip, highlighting the two AC outlets and two USB ports available for charging devices.



**Figure 4:** Nightstand in Use. This image shows the nightstand in a bedroom setting, with a smartphone actively charging via the integrated USB port, demonstrating its practical application.

## MAINTENANCE

---

To ensure the longevity and appearance of your HOSEOKA Nightstand, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining or moisture damage to the engineered wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to maintain stability. Do not overtighten.
- **Charging Station:** Keep the charging ports free of dust and debris. Do not attempt to disassemble or repair the electrical components yourself.

## TROUBLESHOOTING

---

If you encounter any issues with your HOSEOKA Nightstand, please refer to the following common solutions:

- **Wobbly Nightstand:** Ensure all assembly screws are tightened. Check that the nightstand is placed on a level surface. Adjust glides if present.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are installed correctly and are free of obstructions. Apply a silicone-based lubricant to the slides if necessary.
- **Charging Station Not Working:** Check if the main power cord is securely plugged into a wall outlet. Test the wall outlet with another device. Ensure your device's charging cable is functional.
- **Missing Parts:** If you discover missing parts during assembly, do not proceed. Contact HOSEOKA customer service for assistance.

## SPECIFICATIONS

Feature	Specification
Brand	HOSEOKA
Model Number	VM8031
Product Dimensions (D x W x H)	13.78"D x 15.75"W x 23.62"H
Item Weight	32.05 Pounds (14.54 kg)
Maximum Weight Recommendation (Tabletop)	44 Pounds (20 kg)
Maximum Weight Recommendation (Drawer)	11 Pounds (5 kg)
Color	Black
Material Type	Engineered Wood, Particle Board
Number of Drawers	3
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Power Cord Length	5.0 Feet
Indoor/Outdoor Usage	Indoor Only
UPC	614160524704

## WARRANTY INFORMATION

HOSEOKA products are manufactured to high-quality standards. For specific warranty details regarding your VM8031 Nightstand, please refer to the documentation included with your purchase or contact HOSEOKA customer service directly. Keep your proof of purchase for any warranty claims.

## SUPPORT

If you have any questions, require assistance with assembly, or encounter any problems with your HOSEOKA VM8031 Nightstand, please do not hesitate to contact the HOSEOKA service team. We are committed to providing support and ensuring your satisfaction.

Contact information can typically be found on the packaging, in the included instruction manual, or on the official HOSEOKA website.

